



**Reservdelskatalog
Parts Catalogue**

PARK 2002HST


13-1318-11 - Season 1989

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
 - The contents described in the parts list may change due to improvement.
 - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
 - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

© Copyright 2014 Global Garden Products


All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.

www.stiga.com




STIGA
160E
SPARE PARTS

Utgåva Issue 32 - 2014		Frame			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-2215-01	Motorlucka5-01	Engine Cover (Black)	
4	1	1134-3215-01	Motorhuv 1-00	Engine Hood	
5	3	9632-0516-00	Popnit Tap/D/Bs 416 Gf9.5	Pop Rivet	
6	3	9405-0029-00	Knopp	Knob	
7	3	1134-9028-01	Gummistropp (3 St)	Rubber Strap (3 Pcs)	
8	3	9699-0087-02	Bricka	Washer	
9	3	9849-8013-16	Skruv	Screw	
14	8	9739-0831-22	Mutter	Nut	
15	2	9942-0620-16	Skruv	Screw	
16	4	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
17	1	1134-1757-07	Midjegaffel M Ledaxel 5-01 H-10	Clevis	
18	1	1134-0031-00	Ledaxelstopp	Pivot Shaft Stop	
19	1	9595-0262-00	Spännstift	Locating Pin	
20	16	9942-0816-16	Skruv	Screw	
21	2	9959-0816-16	Skruv	Screw	
22	4	1134-0225-00	Stödplåt	Support Plate	
23	5	9959-0820-16	Skruv	Screw	
26	2	9849-8013-16	Skruv	Screw	
28	1	1134-2332-02	Instrumentpanel	Instrument panel	
29	1	1134-2174-02	Framskärm Höger1-00	Mudguard,Rh (Yellow)	
30	1	1134-2174-01	Framskärm Vänster1-00	Mudguard,Lh (Yellow)	
31	1	9959-1025-16	Skruv	Screw	
32	1	1134-2171-01	Fjäder	Spring	
33	1	9959-1020-16	Skruv	Screw	
34	1	9699-0035-02	Bricka	Washer	
35	1	1134-0057-00	Centrumaxel	Centre Shaft	
36	2	9547-0001-00	Ledlager Ge17Es	Bearing	
37	2	9595-0258-00	Spännstift	Locating Pin	
38	2	1134-0075-01	Framaxeltapp	Front Axle	
39	4	1134-0341-01	Bricka	Washer	
44	1	1134-2039-01	Värmeisol.matta	Heat insulation	
45	1	1134-3252-02	Sitskonsol-gul	Seat Bracket-Yellow	
46	1	1134-2951-01	Huvstöd Par	Engine Cover Support	
47	1	1134-3535-01	Durkmatta Park	Floor Mat	
48	1	1134-2833-05	Frontdekor	Front Trim Plate	
49	2	9545-0103-00	Däck	Tyre	
49A	2	9545-0116-00	Däck	Tyre	
50	2	9545-0500-00	Ventil	Valve Assy.	
51	2	1134-2668-01	Fälg kpl	Rim assy	
51A	2	1134-9026-01	Bussning	Bearing	
52	2	1134-1183-04	1134-3710-01+9599-0080-02	1134-3710-01+9599-0080-02	
53	2	9598-0003-02			
54	2	9699-0042-02	Bricka	Washer	
55	2	9599-0085-02	SaxSprint 4X30 Fz	Split Pin	
57	2	9699-0056-02	Bricka	Washer	
65	2	1134-0070-00	Bricka	Washer	
66	1	9997-0670-12	Skruv	Screw	
67	1	9747-0631-02	Mutter Låsmutter	Nut	
99	1	1134-3558-01	Dekalsats	Label Kit	




STIGA
160E
SPARE PARTS


Utgåva Issue 32 - 2014		Frame			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
53	2	9598-0003-02			
18	1	1134-0031-00	Ledaxelstopp	Pivot Shaft Stop	
35	1	1134-0057-00	Centrumaxel	Centre Shaft	
65	2	1134-0070-00	Bricka	Washer	Ej Finland
38	2	1134-0075-01	Framaxeltapp	Front Axle	
22	4	1134-0225-00	Stödplåt	Support Plate	
39	4	1134-0341-01	Bricka	Washer	
52	2	1134-1183-04	1134-3710-01+9599-0080-02	1134-3710-01+9599-0080-02	
17	1	1134-1757-07	Midjegaffel M Ledaxel 5-01 H-10	Clevis	
44	1	1134-2039-01	Värmeisol.matta	Heat insulation	
32	1	1134-2171-01	Fjäder	Spring	
30	1	1134-2174-01	Framskärm Vänster1-00	Mudguard,Lh (Yellow)	
29	1	1134-2174-02	Framskärm Höger1-00	Mudguard,Rh (Yellow)	
1	1	1134-2215-01	Motorlucka5-01	Engine Cover (Black)	
28	1	1134-2332-02	Instrumentpanel	Instrument panel	
47	1	1134-2792-01	Durkmatta	Floor mat	
48	1	1134-2833-05	Frontdekor	Front Trim Plate	
68	1	1134-2864-01	Täckbricka Kpl.5-01	Instrument panel	
51	2	1134-2888-01	Fälg kpl	Rim assy	
46	1	1134-2951-01	Huvstöd Par	Engine Cover Support	
4	1	1134-3215-01	Motorhuv 1-00	Engine Hood	Inkl. 5,6
45	1	1134-3252-02	Sitskonsol-gul	Seat Bracket-Yellow	
99	1	1134-3558-01	Dekalsats	Label Kit	Ej ill/not ill
7	3	1134-9028-01	Gummistropp (3 St)	Rubber Strap (3 Pcs)	
6	3	9405-0029-00	Knopp	Knob	
16	4	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
49	2	9545-0103-00	Däck	Tyre	
49A	2	9545-0116-00	Däck	Tyre	Frankrike (F)
49A	1	9545-0203-00	Innerslang	Inner Tube	
50	2	9545-0500-00	Ventil	Valve Assy.	
36	2	9547-0001-00	Ledlager Ge17Es	Bearing	
51A	2	9549-0036-00	Kullager	Ball Bearing	
37	2	9595-0258-00	Spännstift	Locating Pin	
19	1	9595-0262-00	Spännstift	Locating Pin	
55	2	9599-0085-02	SaxSprint 4X30 Fz	Split Pin	
5	3	9632-0516-00	Popnit Tap/D/Bs 416 Gf9.5	Pop Rivet	
34	1	9699-0035-02	Bricka	Washer	
54	2	9699-0042-02	Bricka	Washer	
57	3	9699-0056-02	Bricka	Washer	
69	2	9699-0060-02	Bricka	Washer	
8	3	9699-0087-02	Bricka	Washer	
70	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
14	8	9739-0831-22	Mutter	Nut	
67	1	9747-0631-02	Mutter Låsmutter	Nut	
9	3	9849-8013-16	Skruv	Screw	
26	2	9849-8013-16	Skruv	Screw	
15	2	9942-0620-16	Skruv	Screw	
20	16	9942-0816-16	Skruv	Screw	
21	2	9959-0816-16	Skruv	Screw	



Utgåva Issue 32 - 2014		Frame			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
23	5	9959-0820-16	Skruv	Screw	
33	1	9959-1020-16	Skruv	Screw	
31	1	9959-1025-16	Skruv	Screw	
66	1	9997-0670-12	Skruv	Screw	




Utgåva Issue 32 - 2014		Engine - Brake System		Engine - Brake System	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	9997-0835-12	Skruv	Screw	
2	1	9997-0865-12	Skruv	Screw	
3	1	9600-0250-00	Kil	Key	
4	6	9739-0831-22	Mutter	Nut	
5	1	1134-0433-00	Packning	Gasket	
6	1	1134-2013-01	Avgasrör	Exhaust Pipe	
7	2	1134-0345-00	Distans	Spacer	
8	1	1134-2462-01	Låsbleck	Lock	
9	2	9988-3632-12	Skruv	Screw	
10	1	1134-2733-01	Värmskydd (5-01 F12)20	Heat Protection	
11	1	9997-0850-16	Skruv	Screw	
12	2	9942-0612-16	Skruv	Screw	
13	1	1134-3243-01	Ljuddämpare	Silencer	
14	1	9578-0011-00	Klämma F Ljuddämp D35 Rid	Clamp	
15	2	9799-0831-02	Mutter	Nut	
16	1	1134-2212-01	Oljeavtappningsrör Kpl.	Oil Drain Pipe	
17	1	9404-0020-00	O-Ring 11,3 X 2,4	O-ring	
18	1	1134-0995-01	Plugg	Plug	
19	1	1134-0997-01	Packning	Gasket	
20	1	1134-2033-01	1134-3593-01+1134-3736-01	Protection Strip	
21	1	1134-2168-01	Tanklock	Petrol Cap	
22	2	9578-0016-00	Slangklämma	Clamp	
23	1	1134-2034-01	Kantskyddslit	Protection Strip	
24	2	1134-2037-01	Fäste	Bracket	
25	4	9849-8009-16	Skruv	Screw	
26	1	1134-0269-00	Pedalgummi	Pedal Rubber	
27	1	1134-2170-02	Bromspedal (hö sida)	Brake pedal (R. H.)	
28	2	1134-9024-01	Lager (4 St)	Bearing	
30	1	1134-1975-09	Gasreglage	Throttle Cable	
31	1	9403-0035-10	Knopp	Knob	
32	2	9849-8013-16	Skruv	Screw	
33	3	9959-0820-16	Skruv	Screw	
34	1	1134-0245-00	Skruv	Screw	
36	1	1134-2151-01	Spärr	Stop	
37	1	1134-1184-02	Stag F Parkeringsbroms	Stay	
38	1	9646-0036-22	Nit Kn 5X12	Rivet	
39	1	9675-0008-02	Starlockbricka	Starlock	
40	1	1134-3573-02	Motorbromswire	Cable, Thread Engine Brake	
44	1	1134-1242-02	Fjäder	Spring	
45	1	1131-1506-00	Fjäder	Spring	
46	1	1134-2045-01	Bromsstopp	Brake Stop	
47	2	9942-0820-16	Skruv	Screw	
49	1	1134-2035-02	Bränsleslang	Petrol tube	
50	1	9500-9924-00	Insats För Ljuddämpare	Pipe-Silencer	
51	1	9578-0015-00	Ljuddämparklämma	Clamp	
52	2	9799-0831-02	Mutter	Nut	
53	1	1131-1497-01	Fjäder	Brake Spring	
39	1	9675-0008-02	Starlockbricka	Starlock	
53	1	1131-1497-01	Fjäder	Brake Spring	




STIGA
161D
SPARE PARTS


Utgåva Issue 32 - 2014		Engine - Brake System		Engine - Brake System	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
45	1	1131-1506-00	Fjäder	Spring	
34	1	1134-0245-00	Skruv	Screw	
26	1	1134-0269-00	Pedalgummi	Pedal Rubber	
7	2	1134-0345-01	Distans	Spacer	
5	1	1134-0433-00	Packning	Gasket	
18	1	1134-0995-01	Plugg	Plug	
19	1	1134-0997-01	Packning	Gasket	
37	1	1134-1184-02	Stag F Parkeringsbroms	Stay	
44	1	1134-1242-02	Fjäder	Spring	
7	2	1134-1565-01	Distans	Spacer	
30	1	1134-1975-09	Gasreglage	Throttle Cable	
40	1	1134-2030-10	Motorbromswire	Cable, Thread Engine Brake	
20	1	1134-2033-01	1134-3593-01+1134-3736-01	Protection Strip	
23	1	1134-2034-01	Kantskyddslit	Protection Strip	
49	1	1134-2035-02	Bränsleslang	Petrol tube	
24	2	1134-2037-01	Fäste	Bracket	
36	1	1134-2151-02	Spärr	Stop	
21	1	1134-2168-01	Tanklock	Petrol Cap	
16	1	1134-2212-01	Oljeavtappningsrör Kpl.	Oil Drain Pipe	
8	1	1134-2462-01	Låsbleck	Lock	
6	1	1134-2718-01	Avgasrör	Exhaust pipe	
10	1	1134-2733-01	Värmskydd (5-01 F12)20	Heat Protection	
13	1	1134-3244-01	Ljuddämpare	Silencer	
27	1	1134-3450-01	Bromspedal (vå sida)	Brake pedal (L. H.)	
28	2	1134-9024-01	Lager (4 St)	Bearing	
31	1	9403-0035-10	Knopp	Knob	
17	1	9404-0020-00	O-Ring 11,3 X 2,4	O-ring	
50	1	9500-9924-00	Insats För Ljuddämpare	Pipe-Silencer	
14	1	9578-0011-00	Klämma F Ljuddämp D35 Rid	Clamp	
51	1	9578-0015-00	Ljuddämparklämma	Clamp	
22	2	9578-0016-00	Slangklämma	Clamp	
3	1	9600-0250-00	Kil	Key	
38	1	9646-0036-22	Nit Kn 5X12	Rivet	
4	6	9739-0831-22	Mutter	Nut	
52	1	9799-0831-02	Mutter	Nut	
15	2	9799-0831-02	Mutter	Nut	
25	4	9849-8009-16	Skruv	Screw	
32	2	9849-8013-16	Skruv	Screw	
12	2	9942-0612-16	Skruv	Screw	
33	3	9959-0820-16	Skruv	Screw	
9	2	9988-3651-12	Skruv	Screw	
1	3	9997-0835-12	Skruv	Screw	
11	1	9997-0835-12	Skruv	Screw	
1	2	9997-0835-12	Skruv	Screw	
2	1	9997-0865-12	Skruv	Screw	




Utgåva Issue 32 - 2014		Power Take-Off		Power Take-Off	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	3	9739-0831-22	Mutter	Nut	
2	1	1134-0143-00	Bricka	Washer	
3	1	1134-2453-01	Låshake	Locking Pawl	
4	1	9695-0002-00	Bricka	Washer	
5	1	1131-1497-01	Fjäder	Brake Spring	
6	1	9646-0036-22	Nit Kn 5X12	Rivet	
7	1	9675-0008-02	Starlockbricka	Starlock	
8	1	1134-0027-01	Reglagespak	Control Lever	
9	1	1134-3573-01	Wire (Kraft)	Cable	
10	1	1134-1972-01	Urkopplingsspak	Disengaging Lever	
11	2	9699-0025-02	Bricka	Washer	
12	1	1134-0583-00	Knopp	Knob	
15	1	1134-0022-00	Reglagestång	Control Rod	
16	2	9672-0004-02			
17	1	1134-0153-00	T-Handtag	Handle Gear Shifter	
19	1	9847-8016-16	Skruv	Screw	
23	1	4231-0013-00	Fjäder	Spring	
25	1	1134-1565-01	Distans	Spacer	
26	1	1134-1242-02	Fjäder	Spring	
27	1	1134-2018-01	Spännarm Kpl 5-01 24	Tensioning Arm	
28	1	9997-1030-16	Skruv	Screw	
29	1	1134-0054-01	Distans	Spacer	
30	1	1134-9027-01	Spännrulle (Svart)	Tension Roller (Black)	
31	1	9799-1031-02	Mutter	Nut	
32	1	1134-2020-01	Motorremskiva	Engine Pulley	
33	1	9959-0820-16	Skruv	Screw	
34	1	9997-0850-16	Skruv	Screw	
35	1	9699-0056-02	Bricka	Washer	
36	2	1134-0052-00	Distans	Spacer	
37	1	1134-1769-02	Remskiva	Belt Pulley	
38	2	9651-0040-04	Spårring Sgh 40	Circlip	
40	1	1134-0051-09	Distans	Spacer	
41	2	9549-0019-00	Kullager	Ball Bearing	
42	1	1134-0057-00	Centrumaxel	Centre Shaft	
43	1	9699-0109-02	Bricka	Washer	
44	1	1134-0222-00	Bricka	Washer	
45	1	9959-1025-16	Skruv	Screw	
46	1	1134-1730-01	Spännhjulsarm	Tensioning Wheel Arm	
47	2	1134-1888-01	Distans	Spacer	
48	1	1134-1770-01	Spännhjul Kpl	Tension Roller	
49	1	9549-0019-00	Kullager	Ball Bearing	
50	1	9651-0040-04	Spårring Sgh 40	Circlip	
52	1	1134-1893-01	Fjäder	Spring	
53	2	9699-0062-02	Bricka	Washer	
54	1	9997-0865-12	Skruv	Screw	
55	1	1134-1322-01	Fjäder	Tensioning Wheel Spring	
56	1	9987-5332-16	Skruv	Screw	
57	1	1134-9012-01	Kilrem	V-Belt	
58	1	1134-9011-01	Kilrem	V-Belt	




Utgåva Issue 32 - 2014		Power Take-Off		Power Take-Off	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
60	1	1134-3654-01	Fingerskydd 5-01 24	Guard	
61	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
62	2	9959-0612-16	Skruv	Screw	
16	2	9672-0004-02			
7	1	9675-0008-02	Starlockbricka	Starlock	
5	1	1131-1497-01	Fjäder	Brake Spring	
15	1	1134-0022-00	Reglagestång	Control Rod	
8	1	1134-0027-01	Reglagespak	Control Lever	
40	1	1134-0051-09	Distans	Spacer	
36	2	1134-0052-00	Distans	Spacer	
29	1	1134-0054-01	Distans	Spacer	
42	1	1134-0057-00	Centrumaxel	Centre Shaft	
2	1	1134-0143-00	Bricka	Washer	
17	1	1134-0153-00	T-Handtag	Handle Gear Shifter	
44	1	1134-0222-00	Bricka	Washer	
12	1	1134-0583-00	Knopp	Knob	
26	1	1134-1242-02	Fjäder	Spring	
55	1	1134-1322-01	Fjäder	Tensioning Wheel Spring	
25	1	1134-1565-01	Distans	Spacer	
46	1	1134-1730-01	Spännhjularm	Tensioning Wheel Arm	
37	1	1134-1769-02	Remskiva	Belt Pulley	
48	1	1134-1770-01	Spännhjul Kpl	Tension Roller	
47	2	1134-1888-01	Distans	Spacer	
52	1	1134-1893-01	Fjäder	Spring	
10	1	1134-1972-01	Urkopplingsspak	Disengaging Lever	
27	1	1134-2018-01	Spännarm Kpl 5-01 24	Tensioning Arm	
32	1	1134-2020-01	Motorremskiva	Engine Pulley	
3	1	1134-2453-01	Låshake	Locking Pawl	
9	1	1134-3573-01	Wire (Kraft)	Cable	
60	1	1134-3654-01	Fingerskydd 5-01 24	Guard	Tyskland (DE)
58	1	1134-9011-01	Kilrem	V-Belt	
57	1	1134-9012-01	Kilrem	V-Belt	
30	1	1134-9027-01	Spännrulle (Svart)	Tension Roller (Black)	
23	1	4231-0013-00	Fjäder	Spring	
41	2	9549-0019-00	Kullager	Ball Bearing	
49	1	9549-0019-00	Kullager	Ball Bearing	
6	1	9646-0036-22	Nit Kn 5X12	Rivet	
38	2	9651-0040-04	Spårring Sgh 40	Circlip	
50	1	9651-0040-04	Spårring Sgh 40	Circlip	
4	1	9695-0002-00	Bricka	Washer	
11	2	9699-0025-02	Bricka	Washer	
35	1	9699-0056-02	Bricka	Washer	
53	2	9699-0062-02	Bricka	Washer	
43	1	9699-0109-02	Bricka	Washer	
61	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	Tyskland (DE)
1	3	9739-0831-22	Mutter	Nut	
31	1	9799-1031-02	Mutter	Nut	
19	1	9847-8016-16	Skruv	Screw	
62	2	9959-0612-16	Skruv	Screw	Tyskland (DE)



Utgåva Issue 32 - 2014		Power Take-Off			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
33	1	9959-0820-16	Skruv	Screw	
45	1	9959-1025-16	Skruv	Screw	
56	1	9987-5332-16	Skruv	Screw	
34	1	9997-0850-16	Skruv	Screw	
54	1	9997-0865-12	Skruv	Screw	
28	1	9997-1030-16	Skruv	Screw	




Utgåva Issue 32 - 2014		Electrical System		Electrical System	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-1466-01	Strålkastare Kpl	Headlamp Assy.	
2	1	9400-0075-00	Glödlampa 12336H3 12	Glow Lamp	
3	2	9847-7922-16	Skruv	Screw	
4	2	9849-8013-16	Skruv	Screw	
5	2	9699-0099-02	Bricka	Washer	
6	1	1134-3082-01	Elkabel	Cable	
7	1	9400-0063-00	Brytare	Switch	
8	1	1134-1814-01	Tändningslås Kpl Service	Starter Switch Assy.	
9	1	1134-2848-01	Tändningsnyckel	Ignition Key	
11	1	9400-0167-00	Brytare	Switch	
12	2	9400-0171-00	Fl.Stift 3868 F/45Msbk	Cable Connection	
13	1	1134-2916-01	Kabel	Wire	
14	1	9942-0612-16	Skruv	Screw	
15	3	9579-0003-00	Bunband Kablage Buntband	Cable Cable harness Cable Holder	
16	1	1134-2040-01	Kabelhärva	Cable Harness	
17	1	1134-2782-01	Låsbleck	Clamp	
18	1	9997-0520-16	Skruv	Screw	
19	1	1134-2084-02	Kabel	Cable	
20	1	1134-2962-01	Solenoid Kpl Service	Solenoid	
21	4	9849-8009-16	Skruv	Screw	
22	1	9400-0103-00	Säkringshållare	Fuse Box	
23	2	9400-0102-00	Säkring 8A	Fuse 8A	
24	1	1134-1199-01	Kabel	Cable	
25	1	1134-2042-01	Batterikabel (-)	Battery Cable (-)	
26	1	1134-0234-01	Batterikabel (+)	Battery Cable (+)	
27	1	9400-0086-00	Batteri	Battery	
28	1	1134-2333-01	Batteriunderlägg	Battery Pad	
29	1	9400-0064-02	Batterihållare	Battery Holder	
30	1	9400-0165-00	Kabelgenomföring O 26	Cable Protector	
31	1	9400-0170-00	Flatst.Hylsa A2507 Flh-1	Cable Connection	
33	1	9739-0531-22	Mutter	Nut	
35	1	1134-2310-01	Batteriskydd	Guard Cap (+)	
39	2	1134-3300-01	Batterisyra	Battery Acid	
26	1	1134-0234-01	Batterikabel (+)	Battery Cable (+)	
24	1	1134-1199-01	Kabel	Cable	
1	1	1134-1466-01	Strålkastare Kpl	Headlamp Assy.	
8	1	1134-1814-01	Tändningslås Kpl Service	Starter Switch Assy.	
16	1	1134-2040-01	Kabelhärva	Cable Harness	
25	1	1134-2042-01	Batterikabel (-)	Battery Cable (-)	
19	1	1134-2084-02	Kabel	Cable	
35	1	1134-2310-01	Batteriskydd	Guard Cap (+)	
28	1	1134-2333-01	Batteriunderlägg	Battery Pad	
17	1	1134-2782-01	Låsbleck	Clamp	
9	1	1134-2848-01	Tändningsnyckel	Ignition Key	
13	1	1134-2916-01	Kabel	Wire	
20	1	1134-2962-01	Solenoid Kpl Service	Solenoid	
6	1	1134-3082-01	Elkabel	Cable	
39	2	1134-3300-01	Batterisyra	Battery Acid	




Utgåva Issue 32 - 2014		Electrical System		Electrical System	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
7	1	9400-0063-00	Brytare	Switch	
29	1	9400-0064-02	Batterihållare	Battery Holder	
2	1	9400-0075-00	Glödlampa 12336H3 12	Glow Lamp	
27	1	9400-0086-00	Batteri	Battery	
23	2	9400-0102-00	Säkring 8A	Fuse 8A	
22	1	9400-0103-00	Säkringshållare	Fuse Box	
30	1	9400-0165-00	Kabelgenomföring O 26	Cable Protector	
11	1	9400-0167-00	Brytare	Switch	
31	1	9400-0170-00	Flatst.Hylsa A2507 Flh-1	Cable Connection	
12	2	9400-0171-00	Fl.Stift 3868 F/45Msbk	Cable Connection	
15	3	9579-0003-00	Bunband Kablage Buntband	Cable Cable harness Cable Holder	
5	2	9699-0099-02	Bricka	Washer	
33	1	9739-0531-22	Mutter	Nut	
3	2	9847-7922-16	Skruv	Screw	
21	4	9849-8009-16	Skruv	Screw	
4	2	9849-8013-16	Skruv	Screw	
14	1	9942-0612-16	Skruv	Screw	
18	1	9997-0520-16	Skruv	Screw	

Utgåva Issue 32 - 2014		Transmission		Transmission	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
24	1	9652-0010-04	Segersäkringsåkring Sga10	Circlip	
51	1	9675-0012-02	Starlock	Locking washer	
11	1	1134-0054-01	Distans	Spacer	
35	1	1134-0266-00	Fästbygel	Attaching Clamp	
113	1	1134-0267-00	Underläggsbleck	Clamp Plate	
16	1	1134-0645-00	Fjäder	Spring	
62	1	1134-1565-01	Distans	Spacer	
15	1	1134-2015-03	Spännarm	Tension Arm	
39	2	1134-2471-01	Kil	Key	
71	2	1134-2653-01	röduceringsnippel	Nipple	
5	2	1134-2700-01	Fäste	Bracket	
8	1	1134-2703-01	Arm Kpl.	Arm	
74	1	1134-2707-01	Arm Kpl.	Arm	
59	1	1134-2708-01	Stay	Stay	
102	1	1134-2713-01	Arm Kpl.	Arm	
66	1	1134-2714-01	Bricka	Washer	
90	1	1134-2717-01	Motorremskiva	Engine Pulley	
45	1	1134-2721-01	Reglagestång	Control rod	
101	1	1134-2724-01	Pivotplatta Kpl. 24	Pivoting Plate	
26	1	1134-2726-01	Fäste	Bracket	
112	1	1134-2727-01	Fäste	Bracket	
73	1	1134-2729-01	Arm Kpl.	Arm	
111	1	1134-2734-01	Stag Kpl	Rod	
63	1	1134-2737-01	Remskiva	Belt Pulley	
2	1	1134-2739-01	Pedal	Pedal	
56	3	1134-2758-01	Distans	Spacer	
84	1	1134-2765-02	Oljetank	Oil Tank	
12	1	1134-2766-01	Fartreglagewire	Speed Control Wire	
95	1	1134-2767-01	Mutter	Nut	
94	1	1134-2774-01	Brytare	Switch	
64	1	1134-2776-01	Kil	Key	
85	1	1134-2777-02	Tanklock	Filler Cap	
86	1	1134-2778-01	Fästband5-01	Band	
109	1	1134-2779-01	Slang	Tube	
4	2	1134-2780-01	Lager	Bearing	
70	1	1134-2783-01	Nipple	Nipple	
46	1	1134-2786-01	Knopp	Knob	
47	1	1134-2789-01	Fäste	Bracket	
48	1	1134-2790-01	Kabelgenomföring	Cable Protection	
33	1	1134-2800-01	Transaxel	Transaxle	
53	1	1134-2801-02	Hydrostat	Hydrostatic Transmission	
21	1	1134-2840-01	Bricka	Washer	
114	1	1134-2843-01	Fjäder	Spring	
93	1	1134-2916-01	Kabel	Wire	
40	2	1134-3175-01	Fälg-bak	Rim-rear	
65	1	1134-3552-01	Fläkt	Fan	
13	1	1134-9013-01	Kilrem	V-Belt	
10	1	1134-9027-01	Spännrulle (Svart)	Tension Roller (Black)	
99	1	4231-0013-00	Fjäder	Spring	




Utgåva Issue 32 - 2014		Transmission		Transmission	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
34	2	9545-0103-00	Däck	Tyre	
34A	2	9545-0116-00	Däck	Tyre	Frankrike (F)
34A	1	9545-0203-00	Innerslang	Inner Tube	
36	2	9545-0500-00	Ventil	Valve Assy.	
22	2	9548-0015-00	Oljebrons12X18X12-24X3	Flanged Bearing	
30	1	9549-0004-00	Kullager	Ball Bearing	
52	4	9570-0001-00	Vinkellänk As8 Din 71802M5	Elbow Link	
72	2	9578-0016-01	Clamp	Clamp	
89	2	9579-0003-00	Bunband Kablage Buntband	Cable Cable harness Cable Holder	
14	2	9595-0235-00	Spännstift	Pin	
57	4	9699-0028-02	Bricka	Washer	
29	4	9699-0029-02	Bricka	Washer	
23	1	9699-0037-02	Bricka	Washer	
79	3	9699-0090-02	Bricka	Washer	
108	10	9739-0531-22	Mutter	Nut	
88	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
7	7	9739-0831-22	Mutter	Nut	
42	2	9743-3621-32	Mutter	Nut	
83	6	9747-0831-02	Mutter Låsmutter	Nut	
9	1	9799-1031-02	Mutter	Nut	
31	1	9799-1031-02	Mutter	Nut	
110	2	9942-0612-16	Skruv	Screw	
38	2	9942-0816-16	Skruv	Screw	
67	5	9959-0612-16	Skruv	Screw	
50	1	9959-0816-16	Skruv	Screw	
6	6	9959-0820-16	Skruv	Screw	
80	1	9959-0830-16	Skruv	Screw	
28	1	9959-1030-16	Skruv	Screw	
19	1	9987-5332-16	Skruv	Screw	
41	2	9988-3645-16	Skruv	Screw	
37	2	9997-0520-16	Skruv	Screw	
87	2	9997-0612-16	Skruv	Screw	
55	2	9997-0812-02	Skruv	Screw	
103	1	9997-0835-12	Skruv	Screw	
105	1	9997-0835-12	Skruv	Screw	
20	1	9997-0840-16	Skruv	Screw	
54	2	9997-0840-16	Skruv	Screw	
32	1	9997-0865-12	Skruv	Screw	
104	4	9997-0870-16	Skruv	Screw	
17	1	9997-1030-16	Skruv	Screw	


Utgåva Issue 32 - 2014		Steering			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-1967-01	Ratt	Steering Wheel	
3	1	9699-0103-02	Bricka	Washer	
3	1	9699-0114-02	Bricka	Washer	
4	1	9595-0262-00	Spännstift	Locating Pin	
8	1	1134-1307-01	Rattstång	Steering Rod	
9	2	1134-1901-01	Lager	Bearing	
10	2	9942-0612-16	Skruv	Screw	
11	1	1134-1305-03	Rattrör Nedre	Steering Column,Lower	
12	1	9595-0262-00	Spännstift	Locating Pin	
13	1	1134-1933-01	Linhjul	Steering Pulley	
14	5	1134-0041-01	Bussning	Bushing	
15	5	1134-9025-01	Linhjul	Steering Pulley	
16	5	1134-3022-01	Fäste	Bracket	
17	2	1134-1934-02	Distans	Spacer	
20	1	9997-1080-12	Skruv	Screw	
22	5	9739-1031-22	Mutter	Nut	
23	1	1134-9022-01	Styrwire	Steering Cable	
24	1	9959-0816-16	Skruv	Screw	
27	1	1134-1310-01	Fjäder	Spring	
28	1	9699-0090-02	Bricka	Washer	
29	1	9747-0831-02	Mutter Låsmutter	Nut	
30	1	1134-1934-01	Distans	Spacer	
31	1	9699-0030-02	Bricka	Washer	
32	1	9898-1060-12	Skruv	Screw	
33	1	9898-1035-16	Skruv	Screw	
34	2	9997-1050-16	Skruv	Screw	
14	5	1134-0041-01	Bussning	Bushing	
11	1	1134-1305-03	Rattrör Nedre	Steering Column,Lower	
8	1	1134-1307-01	Rattstång	Steering Rod	
27	1	1134-1310-01	Fjäder	Spring	
9	2	1134-1901-01	Lager	Bearing	
13	1	1134-1933-01	Linhjul	Steering Pulley	
30	1	1134-1934-01	Distans	Spacer	
17	2	1134-1934-02	Distans	Spacer	
1	1	1134-1967-01	Ratt	Steering Wheel	
16	5	1134-3022-01	Fäste	Bracket	
23	1	1134-9022-01	Styrwire	Steering Cable	
15	5	1134-9025-01	Linhjul	Steering Pulley	
4	1	9595-0262-00	Spännstift	Locating Pin	
12	1	9595-0262-00	Spännstift	Locating Pin	
31	1	9699-0030-02	Bricka	Washer	
28	1	9699-0090-02	Bricka	Washer	
3	1	9699-0103-02	Bricka	Washer	0.5 mm
3	1	9699-0114-02	Bricka	Washer	1.0 mm
22	5	9739-1031-22	Mutter	Nut	
29	1	9747-0831-02	Mutter Låsmutter	Nut	
33	1	9898-1035-16	Skruv	Screw	
32	1	9898-1060-12	Skruv	Screw	
10	2	9942-0612-16	Skruv	Screw	



Utgåva Issue 32 - 2014		Steering			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
24	1	9959-0816-16	Skruv	Screw	
34	2	9997-1050-16	Skruv	Screw	
20	1	9997-1080-12	Skruv	Screw	



Utgåva Issue 32 - 2014		Seat			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-2541-01	Sits Suburban Sa 10314	Seat	
2	2	1134-2961-01	Sitsadapter 5-01 24	Seat Adapter	
3	2	9898-0820-16	Skruv	Screw	
4	4	9863-3613-16	Skruv	Screw	
5	4	9675-0017-02	Låsbricka	Starlock	
6	1	1134-3618-01	Sitsfäste Kpl. 5-01 14	Seat Attachment-R.H.	
10	1	1134-3618-02	Sitsfäste Kpl. 5-01 14	Seat Attachment-L.H.	
11	2	9699-0062-02	Bricka	Washer	
12	2	1134-1711-01	Knopp	Knob	
13	1	1134-1652-01	Fjäder	Spring	
14	1	1134-0050-00	Sitsstång	Seat Rod	
18	2	1134-1650-01	Parallellstag5-01 F24	Tie Bar	
20	1	1134-0493-00	Mutter	Nut	
21	1	1134-0015-00	Sitsfjäder	Seat spring	
28	1	1134-2846-01	Rör	Tube	
30	1	1134-1883-01	Axel	Axle	
31	1	1134-0022-00	Reglagestång	Control Rod	
32	2	9672-0004-02			
36	1	1134-2163-01	Spännstång Kpl.	Rod	
37	1	1134-2166-01	Distans	Spacer	
40	1	1134-1801-01	Sits	Adjustable seat park	
41	4	9795-3631-02	Mutter	Nut	
42	4	9699-0028-02	Bricka	Washer	
44	2	9675-0017-02	Låsbricka	Starlock	
45	1	1134-1687-03	Sitsfäste Hö	Seat Attachment Right	
46	1	1134-1687-04	Sitsfäste-vä	Seat attachment-L.H.	
48	1	1134-2454-01	Axel	Shaft	
49	2	9672-0006-02	Starlock	Lock washer	
50	1	1134-2847-01	Mellanstag	Shaft	
32	2	9672-0004-02			
49	2	9672-0006-02	Starlock	Lock washer	
21	1	1134-0015-00	Sitsfjäder	Seat spring	
31	1	1134-0022-00	Reglagestång	Control Rod	
14	1	1134-0050-00	Sitsstång	Seat Rod	
20	1	1134-0493-00	Mutter	Nut	
18	2	1134-1650-01	Parallellstag5-01 F24	Tie Bar	
13	1	1134-1652-01	Fjäder	Spring	
45	1	1134-1687-03	Sitsfäste Hö	Seat Attachment Right	
46	1	1134-1687-04	Sitsfäste-vä	Seat attachment-L.H.	
12	2	1134-1711-01	Knopp	Knob	
40	1	1134-1801-01	Sits	Adjustable seat park	Tillbehör/Accessory
30	1	1134-1883-01	Axel	Axle	
36	1	1134-2163-01	Spännstång Kpl.	Rod	
37	1	1134-2166-01	Distans	Spacer	
48	1	1134-2454-01	Axel	Shaft	
1	1	1134-2541-01	Sits Suburban Sa 10314	Seat	
28	1	1134-2846-01	Rör	Tube	
50	1	1134-2847-01	Mellanstag	Shaft	
2	2	1134-2961-01	Sitsadapter 5-01 24	Seat Adapter	




Utgåva Issue 32 - 2014		Seat			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
6	1	1134-3618-01	Sitsfäste Kpl. 5-01 14	Seat Attachment-R.H.	
10	1	1134-3618-02	Sitsfäste Kpl. 5-01 14	Seat Attachment-L.H.	
5	4	9675-0017-02	Låsbricka	Starlock	
44	2	9675-0017-02	Låsbricka	Starlock	
42	4	9699-0028-02	Bricka	Washer	
11	2	9699-0062-02	Bricka	Washer	
41	4	9795-3631-02	Mutter	Nut	
4	4	9863-3613-16	Skruv	Screw	
3	2	9898-0820-16	Skruv	Screw	
4	4	9988-3616-16	Skruv	Screw	
4	4	9988-3616-16	Skruv	Screw	

1139-0213-01 1— 1
 1139-0213-01 A1— 1
 1139-0214-01 4— 1
 1139-0214-01 A4— 1
 1139-0215-




1139-0215-01
 A2—
 1
 1139-0215-01
 B2—
 1
 1139-0216-01
 A3—
 1
 1139-0216-01
 A3—
 1
 1139-0216-01
 B3—
 1
 1139-0217-01
 A4—
 2
 1139-0217-01
 A4—
 2
 1139-0217-01
 B4—
 2
 1139-0218-01
 B3—
 2
 1139-0218-01
 B3—
 2
 1139-0218-01
 C3—
 2
 1139-0219-01
 B4—
 1
 1139-0219-01
 B4—
 1
 1139-0219-01
 C4—
 1
 1139-0220-01
 B1—
 1
 1139-0220-01
 B1—
 1
 1139-0220-01
 C1—
 1
 1139-0221-01
 B2—
 1
 1139-0221-01
 B2—
 1
 1139-0221-01
 B2—
 1
 1139-0221-01
 C2—
 1
 1139-0222-01
 B5—
 1
 1139-0222-01
 B5—
 1
 1139-0222-01
 C5—
 1
 1139-0225-01
 A1—
 2
 1139-0225-01
 A1—
 2
 1139-0225-01
 B1—
 1
 1139-0228-01


TRANSMISSIONSHUS KPL/TRANSAXLE CASE ASSY



HUVUDAXEL KPL/MAIN SHAFT ASSY




DIFFERENTIALDREV KPL/DIFFERENTIAL GEAR ASSY




Utgåva		Kanzaki Transaxel K110			Kanzaki Transaxle K110	
32 - 2014						
Pos. Fig.	Antal Q.ty	Anmärkning Notes	Benämning Part No	Description	Anmärkning Notes	
2	1		1139-0200-01	Transmission case	Transmission case	
A2	1		1139-0200-01	Transmission case	Transmission case	
A1	1		1139-0201-01	Bricka	Washer	
A1	1		1139-0201-01	Bricka	Washer	
A1	1		1139-0201-01	Bricka	Washer	
B1	1		1139-0201-01	Bricka	Washer	
3	1		1139-0202-01	Upper case	Upper case	
A3	1		1139-0202-01	Upper case	Upper case	
7	1		1139-0203-01	Hus-nedre	Lower Case	
A7	1		1139-0203-01	Hus-nedre	Lower Case	
A2	1		1139-0204-01	Motordrev Kpl	Motor Gear Assy	
A2	1		1139-0204-01	Motordrev Kpl	Motor Gear Assy	
A2	1		1139-0204-01	Motordrev Kpl	Motor Gear Assy	
B2	1		1139-0204-01	Motordrev Kpl	Motor Gear Assy	
A05	1		1139-0205-01	Huvudaxel	Main Shaft	
A5	1		1139-0205-01	Huvudaxel	Main Shaft	
B5	1		1139-0205-01	Huvudaxel	Main Shaft	
A06	1		1139-0206-01	Shims (Sats)	Shim Assy	
A6	1		1139-0206-01	Shims (Sats)	Shim Assy	
B6	1		1139-0206-01	Shims (Sats)	Shim Assy	
A10	1		1139-0207-01	Mellanaxel	Idle Shaft	
B10	1		1139-0207-01	Mellanaxel	Idle Shaft	
A11	1		1139-0208-01	Drev (24)	Gear (24)	
A11	1		1139-0208-01	Drev (24)	Gear (24)	
B11	1		1139-0208-01	Drev (24)	Gear (24)	
A12	2		1139-0209-01	Bricka	Thrust	
B12	2		1139-0209-01	Bricka	Thrust	
A13	1		1139-0210-01	Nållager	Needle Bearing	
B13	1		1139-0210-01	Nållager	Needle Bearing	
B2	1		1139-0211-01	Axel	Pinion shaft	
B2	1		1139-0211-01	Axel	Pinion shaft	
B2	1		1139-0211-01	Axel	Pinion shaft	
C2	1		1139-0211-01	Axel	Pinion shaft	
B4	2		1139-0212-01	Case	Case	
B4	2		1139-0212-01	Case	Case	
C4	2		1139-0212-01	Case	Case	
1	1		1139-0223-01	Sealant	Sealant	
A1	1		1139-0223-01	Sealant	Sealant	
4	1		1139-0224-01	Vent valve assy	Vent valve assy	
A4	1		1139-0224-01	Vent valve assy	Vent valve assy	
B1	2		1139-0226-01	Drev	Differential Gear	
B1	2		1139-0226-01	Drev	Differential Gear	
C1	2		1139-0226-01	Drev	Differential Gear	
B3	2		1139-0227-01	Drev	Differential pinion	
B3	2		1139-0227-01	Drev	Differential pinion	
C3	2		1139-0227-01	Drev	Differential pinion	
B5	6		1139-0230-01	Bricka	Washer	
B5	6		1139-0230-01	Bricka	Washer	
C5	6		1139-0230-01	Bricka	Washer	


TRANSMISSIONSHUS KPL/TRANSAXLE CASE ASSY




HUVUDAXEL KPL/MAIN SHAFT ASSY









DIFFERENTIALDREV KPL/DIFFERENTIAL GEAR ASSY





Utgåva Issue 32 - 2014		Kanzaki Transaxel K110		Kanzaki Transaxle K110	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
8	2	1139-0231-01	Plugg	Plug	
A8	2	1139-0231-01	Plugg	Plug	
9	1	1139-0232-01	Plugg	Plug	
A9	1	1139-0232-01	Plugg	Plug	
A14	1	1139-0233-01	Kullager	Ball Bearing	
B14	1	1139-0233-01	Kullager	Ball Bearing	
B6	2	1139-0234-01	Kullager	Ball Bearing	
B6	2	1139-0234-01	Kullager	Ball Bearing	
C6	2	1139-0234-01	Kullager	Ball Bearing	
A15	2	1139-0235-01	Kullager	Ball Bearing	
B15	2	1139-0235-01	Kullager	Ball Bearing	
10	2	1139-0238-01	Packning	Packing	
A10	2	1139-0238-01	Packning	Packing	
11	1	1139-0239-01	Packning	Packing	
A11	1	1139-0239-01	Packning	Packing	
12	1	1139-0240-01	Packning	Packing	
A12	1	1139-0240-01	Packning	Packing	
B7	6	1139-0243-01	Bult	Bolt	
B7	6	1139-0243-01	Bult	Bolt	
C7	6	1139-0243-01	Bult	Bolt	
13	14	1139-0244-01	Skruv	Screw	
A13	14	1139-0244-01	Skruv	Screw	
14	6	1139-0245-01	Skruv	Screw	
A14	6	1139-0245-01	Skruv	Screw	
15	4	1139-0246-01	Skruv	Screw	
A15	4	1139-0246-01	Skruv	Screw	
B8	6	1139-0247-01	Mutter	Nut	
B8	6	1139-0247-01	Mutter	Nut	
C8	6	1139-0247-01	Mutter	Nut	




121 CARBURETOR OVERHAUL KIT









861 PUMP REPAIR KIT





Utgåva Issue 32 - 2014		Carburettor			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
52	1	270872	Packning	Gasket	
94	1	292681	Ventil	Valve	
95	2	93499	Skruv	Screw	
98	1	91920	Skruv	Screw	
99	1	26157	Fjäder	Spring	
101	1	93043	LåsSprint	Pin	
104	1	230896	Axel	Shaft	
108	1	222010	Chokespjäll	Choke valve	
118	1	396568	Nålventil	Needle valve	
121	1	394698	Rep.sats	Overhaul kit	
123	2	93357	Skruv	Screw	
125	1	490518	Förgasare kpl	Carburettor Assy	
126	1	490515	Förgasare	Carburetor	
127	1	221997	Täckbricka	Welch plug	
128	1	211960	Venturirör	Venturi	
130	1	222433	Gasspjäll	Throttle Valve	
131	1	491006	Spjällaxel	Shaft	
132	1	211712	Axelstopp	Stop	
133	1	299707	Flottör	Float	
134	1	394683	Bränslenål	Inlet valve	
136	1	221995	Flottörhus	Bowl	
137	1	270511	Packning	Gasket	
138	1	222014	Bricka	Washer	
141	1	299647	Chokeaxel	Choke shaft	
142	1	299740	Munstycke	Nozzle	
147	1	231323	Munstycke	Nozzle	
171	1	231532	Mutter	Nut	
186	1	67218	Nippel	Connector	
187	1	393815	Bränsleledning	Fuel line	
224	1	94018	Skruv	Screw	
240	1	394358	Bränslefilter	Fuelfilter	
257	1	93543	Skruv	Screw	
309	1	490420	Startmotor	Starting motor	
310	2	94004	Bult	Bolt	
311	4	395538	Släpkol	Brush	
333	1	398811	Tändsystem kpl	Armature group	
334	2	93381	Skruv	Screw	
367	1	93380	Skruv	Screw	
387	1	390818	Bränslepump	Impulse pump	
423	2	93984	Skruv	Screw	
445	1	399806	Pappersfilter	Cartridge	
467	1	212706	Lås ratt	Knob	
474	1	392595	Stator	Alternator stator	
482	4	93621	Skruv	Screw	
510	1	490421	Drev kpl	Drive assy	
513	1	398003	Koppling kpl	Clutch Ass.Y	
528	1	393815	Bränsleledning	Fuel line	
534	1	94248	Skruv	Screw	
534A	1	94246	Skruv	Screw	




121 CARBURETOR OVERHAUL KIT









861 PUMP REPAIR KIT





Utgåva Issue 32 - 2014		Carburettor			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
535	1	271962	Filterelement	Element	
537	1	270853	Packning	Gasket	
544	1	391160	Startarmatur	Armature	
549	1	94249	Bricka	Washer	
601	2	93053	Slangklämma	Hose clamp	
662	1	222311	Fäste	Bracket	
663	2	93572	Skruv	Screw	
726	1	392134	Kuggkrans	Gear ring	
727	1	490324	Skyddskåpa	Cover	
728	2	93535	Skruv	Screw	
783	1	280104	Drev	Gear	
801	1	394857	Lock	End cap	
802	1	395537	Botten	End cap	
803	1	394544	Hus	Housing	
851	1	221798	Anslutning	Terminal	
861	1	394462	Rep.sats bränslepump	Repair Kit	
872	1	223700	Lock	Cover	
875	1	490332	Filterhus	Body	
876	1	490467	Startdrev	Retainer kit	
877	1	393537	Anslutning	Connector	
896	1	94288	Stift	Roll pin	
987	1	398970	Tätning	Seal	
99	1	26157	Fjäder	Spring	
186	1	67218	Nippel	Connector	281707-0127
98	1	91920	Skruv	Screw	
101	1	93043	LåsSprint	Pin	
601	2	93053	Slangklämma	Hose clamp	
123	2	93357	Skruv	Screw	
367	1	93380	Skruv	Screw	281707-0127
334	2	93381	Skruv	Screw	
95	2	93499	Skruv	Screw	
728	2	93535	Skruv	Screw	
257	1	93543	Skruv	Screw	281707-0127
663	2	93572	Skruv	Screw	
482	4	93621	Skruv	Screw	
423	2	93984	Skruv	Screw	
310	2	94004	Bult	Bolt	
224	1	94018	Skruv	Screw	
534A	1	94246	Skruv	Screw	
534	1	94248	Skruv	Screw	
549	1	94249	Bricka	Washer	
896	1	94288	Stift	Roll pin	
132	1	211712	Axelstopp	Stop	
128	1	211960	Venturirör	Venturi	
467	1	212706	Lås ratt	Knob	
851	1	221798	Anslutning	Terminal	
136	1	221995	Flottörhus	Bowl	
127	1	221997	Täckbricka	Welch plug	
108	1	222010	Chokespjäll	Choke valve	




121 CARBURETOR OVERHAUL KIT









861 PUMP REPAIR KIT





Utgåva Issue 32 - 2014		Carburettor		Carburettor	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
138	1	222014	Bricka	Washer	
662	1	222311	Fäste	Bracket	
130	1	222433	Gasspjäll	Throttle Valve	
917	1	223271	Handtag	Handle	281707-0142
872	1	223700	Lock	Cover	
104	1	230896	Axel	Shaft	
147	1	231323	Munstycke	Nozzle	
171	1	231532	Mutter	Nut	
618	1	261116	Fjäder	Spring	281707-0142
216	1	261610	Choke link	Choke link	281707-0142
634	1	270382	Bricka	Foam washer	281707-0142
137	1	270511	Packning	Gasket	
537	1	270853	Packning	Gasket	
52	1	270872	Packning	Gasket	
535	1	271962	Filterelement	Element	
783	1	280104	Drev	Gear	
94	1	292681	Ventil	Valve	
198	1	293934	Shut-off valve	Shut-off valve	281707-0142
240	1	298090	Bränslefilter	Fuel Filter	281707-0142
141	1	299647	Chokeaxel	Choke shaft	281707-0127
133	1	299707	Flottör	Float	
142	1	299740	Munstycke	Nozzle	
141	1	390684	Axel	Shaft	281707-0142
387	1	390818	Bränslepump	Impulse pump	281707-0127
544	1	391160	Startarmatur	Armature	
726	1	392134	Kuggkrans	Gear ring	
474	1	392595	Stator	Alternator stator	281707-0127
878	1	393362	Kabelhärva	Harness	281707-0142
877	1	393456	Connector	Connector	281707-0142
474	1	393474	Generator	Alternator	281707-0142
877	1	393537	Anslutning	Connector	281707-0127
528	1	393815	Bränsleledning	Fuel line	281707-0127
187	1	393815	Bränsleledning	Fuel line	
240	1	394358	Bränslefilter	Fuel filter	281707-0127
861	1	394462	Rep.sats bränslepump	Repair Kit	281707-0127
803	1	394544	Hus	Housing	
134	1	394681	Bränslenål	Inlet valve	281707-0142 _/ Kit: F
134	1	394683	Bränslenål	Inlet valve	281707-0127 _/ Kit: F
121	1	394698	Rep.sats	Overhaul kit	Delarna märkta F
801	1	394857	Lock	End cap	
802	1	395537	Botten	End cap	
311	4	395538	Släpkol	Brush	
118	1	396568	Nålventil	Needle valve	
513	1	398003	Koppling kpl	Clutch Ass.Y	
333	1	398811	Tändsystem kpl	Armature group	
987	1	398970	Tätning	Seal	
445	1	399806	Pappersfilter	Cartridge	
199	1	399949	Connector	Connector	281707-0142
727	1	490324	Skyddskåpa	Cover	



121 CARBURETOR OVERHAUL KIT




861 PUMP REPAIR KIT



Utgåva Issue 32 - 2014		Carburettor			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
875	1	490332	Filterhus	Body	
309	1	490420	Startmotor	Starting motor	
510	1	490421	Drev kpl	Drive assy	
876	1	490467	Startdrev	Retainer kit	
126	1	490473	Carurettor body	Carurettor body	281707-0142
126	1	490515	Förgasare	Carburetor	281707-0127
125	1	490518	Förgasare kpl	Carburettor Assy	281707-0127
131	1	491006	Spjällaxel	Shaft	
125	1	491031	Förgasare kpl	Carburettor Assy	281707-0142


Utgåva Issue 32 - 2014		Cylinder			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	490450	Cylinder kpl	Cylinder Assy	
2	1	261623	Lager	Bearing	
3	1	391086	Tätningring	Seal	
5	1	491491	Topplöck	Cylinder Head	
7	1	271866	Packning	Gasket	
8	1	394217	Vevhusventilation	Breather	
9	1	27803	Packning	Gasket	
10	2	93394	Skruv	Screw	
11	1	280100	Rör	Tube	
12	1	271916	Packning	Gasket	
13	9	93723	Skruv	Screw	
15	1	91084	OljePlugg	Oil plug	
16	1	490466	Vevaxel	Crankshaft	
18	1	490452	Vevhus	Oil sump	
20	1	291675	Tätningring	Oil Seal Oil seal	
22	8	94305	Skruv	Screw	
23	1	399917	Svånghjul	Flywheel	
24	1	222698	Kil	Key	
25	1	394661	Kolv kpl	Piston Assy	
26	1	394665	Kolvringssats	Ring set	
27	2	260924	Låsring	Lock	
28	1	299691	Kolvspind	Piston Pin	
29	1	490348	Vevstake kpl	Connecting rod assy	
31	1	222299	Låsbleck	Lock	
32	2	92909	Skruv	Screw	
33	1	262246	Utblåsningsventil	Exhaust valve	
34	1	262247	Insugningsventil	Intake valve	
35	1	65906	Ventilfjäder-insug	Valve spring-intake	
36	1	26828	Ventilfjäder-utblås	Valve spring-exhaust	
37	1	223752	Skydd	Cover	
40	1	221596	Hållare	Retainer	
41	1	292260	Rotator	Rotocoil	
42	2	93630	Hållare	Retainer	
635	1	66538	Tändstiftsskydd	Spark plug elbow	
657	1	93496	Skruv	Screw	
663	2	93572	Skruv	Screw	
741	1	262135	Drev	Gear	
757	1	212359	Länk	Link	
758	1	399891	Balanseringsvikt	Counterweight	
759	1	298909	Kolvspind	Piston Pin	
761	2	93875	Skruv	Screw	
842	1	270920	Tätning	Seal	
847	1	490474	Oljesticka kpl	Oil filler group	
869	1	261463	Ventilsäte	Valve seat	
870	1	210940	Ventilsäte	Valve seat	
871	1	261961	Ventilstyrning-utblås	Valve guide-exhaust	
871	1	231218	Ventilstyrning-insug	Valve guide-intake	
883	1	270917	Packning	Gasket	
985	1	398525	Isolator	Insulator	

Utgåva Issue 32 - 2014		Cylinder			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1005	1	280687	Fläkt	Fan	
1006	1	223726	Fläkthållare	Fan retainer	
1007	1	231531	Distans	Spacer	
1020	1	262243	Excenter	Eccentric	
1021	1	94160	Stift	Pin	
45	2	262248	Ventillyftare	Valve tappet	
46	1	212897	Kamaxel	Camshaft	
75	1	220865	Bricka	Washer	
78	3	93805	Skruv	Screw	
188	2	93535	Skruv	Screw	
201	1	262348	Regulatorlänk	Governor link	
209	1	260871	Fjäder	Spring	
219	1	490815	Oljekastardrev	Oil slinger gear	
222	1	390746	Regulatorplatta	Governor plate	
225	1	231058	Regulatoraxel	Governor crank	
227	1	490927	Arm	Lever	
230	1	222450	Bricka	Washer	
232	1	260584	Fjäder	Spring	
265	1	221535	Klämma	Clamp	
284	1	93804	Skruv	Screw	
304	1	490733	Fläkthus	Blower housing	
305	4	93158	Skruv	Screw	
306	1	223715	Skyddsplåt	Shield	
307	1	93163	Skruv	Screw	
308	1	491490	Skydd	Cover	
332	1	92284	Mutter	Nut	
337	1	1111-9028-02	Tändstift (J19Lm)	Spark Plug (J19Lm)	
346	2	93705	Skruv	Screw	
353	2	92791	Bricka	Washer	
354	2	90576	Mutter	Nut	
356	1	398808	Kortslutningskabel	Ground wire	
358	1	490525	Packning Packningssats	Gasket Gasket set	
363	1	19203	Avdragare	Puller	
383	1	1111-9029-01	Tändstiftsnyckel (19 Mm-21 Mm)	Spark Plug Wrench (19 Mm-21 Mm)	
422	1	223721	Bygel	Clamp	
455	1	222561	Kopp	Cup	
468	1	223713	Skyddsnät	Screen	
520	1	93722	Anslutningsbleck	Terminal	
523	1	490327	Oljesticka	Oil dipstick	
524	1	68838	Tätning	Seal	
525	1	280741	Rör	Tube	
552	1	231055	Bussning	Bushing	
562	1	92613	Skruv	Screw	
592	1	231082	Mutter	Nut	
614	1	93306	Låsnål	Cotter pin Cotter Pin	
615	1	93307	Låsring	Retainer	
363	1	19203	Avdragare	Puller	Tillbehör/Accessory
36	1	26828	Ventilfjäder-utblås	Valve spring-exhaust	



Utgåva Issue 32 - 2014		Cylinder			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
9	1	27803	Packning	Gasket	
35	1	65906	Ventilfjäder-insug	Valve spring-intake	
635	1	66538	Tändstiftsskydd	Spark plug elbow	
524	1	68838	Tätning	Seal	
354	2	90576	Mutter	Nut	
15	1	91084	OljePlugg	Oil plug	
332	1	92284	Mutter	Nut	
562	1	92613	Skruv	Screw	
353	2	92791	Bricka	Washer	
32	2	92909	Skruv	Screw	
305	4	93158	Skruv	Screw	
307	1	93163	Skruv	Screw	
614	1	93306	Låsnål	Cotter pin Cotter Pin	
615	1	93307	Låsring	Retainer	
10	2	93394	Skruv	Screw	
657	1	93496	Skruv	Screw	
188	2	93535	Skruv	Screw	
663	2	93572	Skruv	Screw	
42	2	93630	Hållare	Retainer	
346	2	93705	Skruv	Screw	
520	1	93722	Anslutningsbleck	Terminal	281707-0127
13	9	93723	Skruv	Screw	
284	1	93804	Skruv	Screw	
78	3	93805	Skruv	Screw	
761	2	93875	Skruv	Screw	
1021	1	94160	Stift	Pin	
22	8	94305	Skruv	Screw	
870	1	210940	Ventilsäte	Valve seat	
757	1	212359	Länk	Link	
46	1	212897	Kamaxel	Camshaft	
75	1	220865	Bricka	Washer	
265	1	221535	Klämma	Clamp	
40	1	221596	Hållare	Retainer	
31	1	222299	Låsbleck	Lock	
230	1	222450	Bricka	Washer	
455	1	222561	Kopp	Cup	
24	1	222698	Kil	Key	
468	1	223713	Skyddsnät	Screen	
306	1	223715	Skyddsplåt	Shield	
422	1	223721	Bygel	Clamp	
1006	1	223726	Fläkthållare	Fan retainer	
37	1	223752	Skydd	Cover	
552	1	231055	Bussning	Bushing	
225	1	231058	Regulatoraxel	Governor crank	
592	1	231082	Mutter	Nut	
871	1	231218	Ventilstyrning-insug	Valve guide-intake	
871	1	231218	Ventilstyrning-insug	Valve guide-intake	
871	1	231218	Ventilstyrning-insug	Valve guide-intake	
1007	1	231531	Distans	Spacer	

Utgåva Issue 32 - 2014		Cylinder			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
232	1	260584	Fjäder	Spring	
209	1	260871	Fjäder	Spring	
27	2	260924	Låsring	Lock	
869	1	261463	Ventilsäte	Valve seat	
2	1	261623	Lager	Bearing	
871	1	261961	Ventilstyrning-utblås	Valve guide-exhaust	
871	1	261961	Ventilstyrning-utblås	Valve guide-exhaust	
871	1	261961	Ventilstyrning-utblås	Valve guide-exhaust	
741	1	262135	Drev	Gear	
1020	1	262243	Excenter	Eccentric	
33	1	262246	Utblåsningsventil	Exhaust valve	
34	1	262247	Insugningsventil	Intake valve	
45	2	262248	Ventillyftare	Valve tappet	
201	1	262348	Regulatorlänk	Governor link	
883	1	270917	Packning	Gasket	281707-0127
842	1	270920	Tätning	Seal	
7	1	271866	Packning	Gasket	
12	1	271916	Packning	Gasket	
11	1	280100	Rör	Tube	
1005	1	280687	Fläkt	Fan	
525	1	280741	Rör	Tube	
20	1	291675	Tätning	Oil Seal Oil seal	
41	1	292260	Rotator	Rotocoil	
759	1	298909	Kolvspind	Piston Pin	
28	1	299691	Kolvspind	Piston Pin	
222	1	390746	Regulatorplatta	Governor plate	281707-0127
3	1	391086	Tätning	Seal	
8	1	391406	Vevhusventilation	Breather	281707-0142
8	1	394217	Vevhusventilation	Breather	281707-0127
25	1	394661	Kolv kpl	Piston Assy	
26	1	394665	Kolvringssats	Ring set	
621	1	396847	Stop switch	Stop switch	281707-0142
985	1	398525	Isolator	Insulator	
356	1	398808	Kortslutningskabel	Ground wire	
758	1	399891	Balanseringsvikt	Counterweight	
23	1	399917	Svånghjul	Flywheel	
523	1	490327	Oljesticka	Oil dipstick	
29	1	490348	Vevstake kpl	Connecting rod assy	
1	1	490450	Cylinder kpl	Cylinder Assy	
18	1	490452	Vevhus	Oil sump	
16	1	490466	Vevaxel	Crankshaft	
847	1	490474	Oljesticka kpl	Oil filler group	
358	1	490525	Packning Packningssats	Gasket Gasket set	Delarna märkta S
304	1	490689	Blower housing	Blower housing	281707-0142
304	1	490733	Fläkthus	Blower housing	281707-0127
219	1	490815	Oljekastardrev	Oil slinger gear	
227	1	490927	Arm	Lever	
308	1	491490	Skydd	Cover	
5	1	491491	Topplöck	Cylinder Head	



Utgåva Issue 32 - 2014		Cylinder			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
222	1	491594	Governor plate	Governor plate	281707-0142
337	1	1111-9028-02	Tändstift (J19Lm)	Spark Plug (J19Lm)	
383	1	1111-9029-01	Tändstiftsnyckel (19 Mm-21 Mm)	Spark Plug Wrench (19 Mm-21 Mm)	Tillbehör/Accessory

code	pos.	q.ty	page									
9863-3613-16	4	4	p. 33	9997-0850-16	11	1	p. 9	93496	657	1	p. 51	
9898-0820-16	3	2	p. 31	9997-0850-16	34	1	p. 13	93499	95	2	p. 39	
9898-0820-16	3	2	p. 33	9997-0850-16	34	1	p. 17	93499	95	2	p. 41	
9898-1035-16	33	1	p. 27	9997-0865-12	2	1	p. 9	93535	188	2	p. 49	
9898-1035-16	33	1	p. 27	9997-0865-12	2	1	p. 11	93535	188	2	p. 51	
9898-1060-12	32	1	p. 27	9997-0865-12	32	1	p. 25	93535	728	2	p. 41	
9898-1060-12	32	1	p. 27	9997-0865-12	54	1	p. 13	93535	728	2	p. 41	
9942-0612-16	10	2	p. 27	9997-0865-12	54	1	p. 17	93543	257	1	p. 39	
9942-0612-16	10	2	p. 27	9997-0870-16	104	4	p. 25	93543	257	1	p. 41	
9942-0612-16	12	2	p. 9	9997-1030-16	17	1	p. 25	93572	663	2	p. 41	
9942-0612-16	12	2	p. 11	9997-1030-16	28	1	p. 13	93572	663	2	p. 41	
9942-0612-16	14	1	p. 19	9997-1030-16	28	1	p. 17	93572	663	2	p. 47	
9942-0612-16	14	1	p. 21	9997-1050-16	34	2	p. 27	93572	663	2	p. 51	
9942-0612-16	14	1	p. 25	9997-1050-16	34	2	p. 29	93621	482	4	p. 39	
9942-0620-16	15	2	p. 3	9997-1080-12	20	1	p. 27	93621	482	4	p. 41	
9942-0620-16	15	2	p. 5	9997-1080-12	20	1	p. 29	93630	42	2	p. 47	
9942-0816-16	20	16	p. 3	19203	363	1	p. 49	93630	42	2	p. 51	
9942-0816-16	20	16	p. 5	19203	363	1	p. 49	93705	346	2	p. 49	
9942-0816-16	38	2	p. 25	26157	99	1	p. 39	93705	346	2	p. 51	
9942-0820-16	47	2	p. 9	26157	99	1	p. 41	93722	520	1	p. 49	
9959-0612-16	62	2	p. 15	26828	36	1	p. 47	93722	520	1	p. 51	
9959-0612-16	62	2	p. 15	26828	36	1	p. 49	93723	13	9	p. 47	
9959-0612-16	67	5	p. 25	27803	9	1	p. 47	93723	13	9	p. 51	
9959-0816-16	21	2	p. 3	27803	9	1	p. 51	93804	284	1	p. 49	
9959-0816-16	21	2	p. 5	65906	35	1	p. 47	93804	284	1	p. 51	
9959-0816-16	24	1	p. 27	65906	35	1	p. 51	93805	78	3	p. 49	
9959-0816-16	24	1	p. 29	66538	635	1	p. 47	93805	78	3	p. 51	
9959-0816-16	24	1	p. 25	66538	635	1	p. 51	93875	761	2	p. 47	
9959-0820-16	6	6	p. 25	67218	186	1	p. 39	93875	761	2	p. 51	
9959-0820-16	23	5	p. 3	67218	186	1	p. 41	93984	423	2	p. 39	
9959-0820-16	23	5	p. 7	68838	524	1	p. 49	93984	423	2	p. 41	
9959-0820-16	33	1	p. 13	68838	524	1	p. 51	94004	310	2	p. 39	
9959-0820-16	33	1	p. 17	90576	354	2	p. 49	94004	310	2	p. 41	
9959-0820-16	33	3	p. 9	90576	354	2	p. 51	94018	224	1	p. 39	
9959-0820-16	33	3	p. 11	91084	15	1	p. 47	94018	224	1	p. 41	
9959-0830-16	80	1	p. 25	91084	15	1	p. 51	94160	1021	1	p. 49	
9959-1020-16	33	1	p. 3	91920	98	1	p. 39	94160	1021	1	p. 51	
9959-1020-16	33	1	p. 7	91920	98	1	p. 41	94246	534A	1	p. 39	
9959-1025-16	31	1	p. 3	92284	332	1	p. 49	94246	534A	1	p. 41	
9959-1025-16	31	1	p. 7	92284	332	1	p. 51	94248	534	1	p. 39	
9959-1025-16	45	1	p. 13	92613	562	1	p. 49	94248	534	1	p. 41	
9959-1025-16	45	1	p. 17	92613	562	1	p. 51	94249	549	1	p. 41	
9959-1030-16	28	1	p. 25	92791	353	2	p. 49	94249	549	1	p. 41	
9987-5332-16	19	1	p. 25	92791	353	2	p. 51	94288	896	1	p. 41	
9987-5332-16	56	1	p. 13	92909	32	2	p. 47	94288	896	1	p. 41	
9987-5332-16	56	1	p. 17	92909	32	2	p. 51	94305	22	8	p. 47	
9988-3616-16	4	4	p. 33	93043	101	1	p. 39	94305	22	8	p. 51	
9988-3616-16	4	4	p. 33	93043	101	1	p. 41	210940	870	1	p. 47	
9988-3632-12	9	2	p. 9	93053	601	2	p. 41	210940	870	1	p. 51	
9988-3645-16	41	2	p. 25	93053	601	2	p. 41	211712	132	1	p. 39	
9988-3651-12	9	2	p. 11	93158	305	4	p. 49	211712	132	1	p. 41	
9997-0520-16	18	1	p. 19	93158	305	4	p. 51	211960	128	1	p. 39	
9997-0520-16	18	1	p. 21	93163	307	1	p. 49	211960	128	1	p. 41	
9997-0520-16	37	2	p. 25	93163	307	1	p. 51	212359	757	1	p. 47	
9997-0612-16	87	2	p. 25	93306	614	1	p. 49	212359	757	1	p. 51	
9997-0670-12	66	1	p. 3	93306	614	1	p. 51	212706	467	1	p. 39	
9997-0670-12	66	1	p. 7	93307	615	1	p. 49	212706	467	1	p. 41	
9997-0812-02	55	2	p. 25	93307	615	1	p. 51	212897	46	1	p. 49	
9997-0835-12	1	2	p. 9	93307	615	1	p. 51	212897	46	1	p. 51	
9997-0835-12	1	2	p. 11	93357	123	2	p. 39	212897	46	1	p. 51	
9997-0835-12	1	3	p. 11	93357	123	2	p. 41	220865	75	1	p. 49	
9997-0835-12	11	1	p. 11	93380	367	1	p. 39	220865	75	1	p. 51	
9997-0835-12	103	1	p. 25	93380	367	1	p. 41	221535	265	1	p. 49	
9997-0835-12	105	1	p. 25	93381	334	2	p. 39	221535	265	1	p. 51	
9997-0840-16	20	1	p. 25	93381	334	2	p. 41	221596	40	1	p. 47	
9997-0840-16	54	2	p. 25	93394	10	2	p. 47	221596	40	1	p. 51	
				93394	10	2	p. 51	221798	851	1	p. 41	
				93496	657	1	p. 47	221798	851	1	p. 41	

code	pos.	q.ty	page										
221995	136	1	p. 39	261961	871	1	p. 53	392134	726	1	p. 43		
221995	136	1	p. 41	262135	741	1	p. 47	392595	474	1	p. 39		
221997	127	1	p. 39	262135	741	1	p. 53	392595	474	1	p. 43		
221997	127	1	p. 41	262243	1020	1	p. 49	393362	878	1	p. 43		
222010	108	1	p. 39	262243	1020	1	p. 53	393456	877	1	p. 43		
222010	108	1	p. 41	262246	33	1	p. 47	393474	474	1	p. 43		
222014	138	1	p. 39	262246	33	1	p. 53	393537	877	1	p. 41		
222014	138	1	p. 43	262247	34	1	p. 47	393537	877	1	p. 43		
222299	31	1	p. 47	262247	34	1	p. 53	393815	187	1	p. 39		
222299	31	1	p. 51	262248	45	2	p. 49	393815	187	1	p. 43		
222311	662	1	p. 41	262248	45	2	p. 53	393815	528	1	p. 39		
222311	662	1	p. 43	262348	201	1	p. 49	393815	528	1	p. 43		
222433	130	1	p. 39	262348	201	1	p. 53	394217	8	1	p. 47		
222433	130	1	p. 43	270382	634	1	p. 43	394217	8	1	p. 53		
222450	230	1	p. 49	270511	137	1	p. 39	394358	240	1	p. 39		
222450	230	1	p. 51	270511	137	1	p. 43	394358	240	1	p. 43		
222561	455	1	p. 49	270853	537	1	p. 41	394462	861	1	p. 41		
222561	455	1	p. 51	270853	537	1	p. 43	394462	861	1	p. 43		
222698	24	1	p. 47	270872	52	1	p. 39	394544	803	1	p. 41		
222698	24	1	p. 51	270872	52	1	p. 43	394544	803	1	p. 43		
223271	917	1	p. 43	270917	883	1	p. 47	394661	25	1	p. 47		
223700	872	1	p. 41	270917	883	1	p. 53	394661	25	1	p. 53		
223700	872	1	p. 43	270920	842	1	p. 47	394665	26	1	p. 47		
223713	468	1	p. 49	270920	842	1	p. 53	394665	26	1	p. 53		
223713	468	1	p. 51	271866	7	1	p. 47	394681	134	1	p. 43		
223715	306	1	p. 49	271866	7	1	p. 53	394683	134	1	p. 39		
223715	306	1	p. 51	271916	12	1	p. 47	394683	134	1	p. 43		
223721	422	1	p. 49	271916	12	1	p. 53	394698	121	1	p. 39		
223721	422	1	p. 51	271962	535	1	p. 41	394698	121	1	p. 43		
223726	1006	1	p. 49	271962	535	1	p. 43	394857	801	1	p. 41		
223726	1006	1	p. 51	280100	11	1	p. 47	394857	801	1	p. 43		
223752	37	1	p. 47	280100	11	1	p. 53	395537	802	1	p. 41		
223752	37	1	p. 51	280104	783	1	p. 41	395537	802	1	p. 43		
230896	104	1	p. 39	280104	783	1	p. 43	395538	311	4	p. 39		
230896	104	1	p. 43	280687	1005	1	p. 49	395538	311	4	p. 43		
231055	552	1	p. 49	280687	1005	1	p. 53	396568	118	1	p. 39		
231055	552	1	p. 51	280741	525	1	p. 49	396568	118	1	p. 43		
231058	225	1	p. 49	280741	525	1	p. 53	396847	621	1	p. 53		
231058	225	1	p. 51	291675	20	1	p. 47	398003	513	1	p. 39		
231082	592	1	p. 49	291675	20	1	p. 53	398003	513	1	p. 43		
231082	592	1	p. 51	292260	41	1	p. 47	398525	985	1	p. 47		
231218	871	1	p. 47	292260	41	1	p. 53	398525	985	1	p. 53		
231218	871	1	p. 51	292681	94	1	p. 39	398808	356	1	p. 49		
231218	871	1	p. 51	292681	94	1	p. 43	398808	356	1	p. 53		
231323	147	1	p. 39	293934	198	1	p. 43	398811	333	1	p. 39		
231323	147	1	p. 43	298090	240	1	p. 43	398811	333	1	p. 43		
231531	1007	1	p. 49	298909	759	1	p. 47	398970	987	1	p. 41		
231531	1007	1	p. 51	298909	759	1	p. 53	398970	987	1	p. 43		
231532	171	1	p. 39	299647	141	1	p. 39	399806	445	1	p. 39		
231532	171	1	p. 43	299647	141	1	p. 43	399806	445	1	p. 43		
260584	232	1	p. 49	299691	28	1	p. 47	399891	758	1	p. 47		
260584	232	1	p. 53	299691	28	1	p. 53	399891	758	1	p. 53		
260871	209	1	p. 49	299707	133	1	p. 39	399917	23	1	p. 47		
260871	209	1	p. 53	299707	133	1	p. 43	399917	23	1	p. 53		
260924	27	2	p. 47	299740	142	1	p. 39	399949	199	1	p. 43		
260924	27	2	p. 53	299740	142	1	p. 43	490324	727	1	p. 41		
261116	618	1	p. 43	390684	141	1	p. 43	490324	727	1	p. 43		
261463	869	1	p. 47	390746	222	1	p. 49	490327	523	1	p. 49		
261463	869	1	p. 53	390746	222	1	p. 53	490327	523	1	p. 53		
261610	216	1	p. 43	390818	387	1	p. 39	490332	875	1	p. 41		
261623	2	1	p. 47	390818	387	1	p. 43	490332	875	1	p. 45		
261623	2	1	p. 53	391086	3	1	p. 47	490348	29	1	p. 47		
261961	871	1	p. 47	391086	3	1	p. 53	490348	29	1	p. 53		
261961	871	1	p. 53	391160	544	1	p. 41	490420	309	1	p. 39		
261961	871	1	p. 53	391160	544	1	p. 43	490420	309	1	p. 45		
261961	871	1	p. 53	391406	8	1	p. 53	490421	510	1	p. 39		
261961	871	1	p. 53	392134	726	1	p. 41	490421	510	1	p. 45		

code	pos.	q.ty	page
490450	1	1	p. 47
490450	1	1	p. 53
490452	18	1	p. 47
490452	18	1	p. 53
490466	16	1	p. 47
490466	16	1	p. 53
490467	876	1	p. 41
490467	876	1	p. 45
490473	126	1	p. 45
490474	847	1	p. 47
490474	847	1	p. 53
490515	126	1	p. 39
490515	126	1	p. 45
490518	125	1	p. 39
490518	125	1	p. 45
490525	358	1	p. 49
490525	358	1	p. 53
490689	304	1	p. 53
490733	304	1	p. 49
490733	304	1	p. 53
490815	219	1	p. 49
490815	219	1	p. 53
490927	227	1	p. 49
490927	227	1	p. 53
491006	131	1	p. 39
491006	131	1	p. 45
491031	125	1	p. 45
491490	308	1	p. 49
491490	308	1	p. 53
491491	5	1	p. 47
491491	5	1	p. 53
491594	222	1	p. 55