



Reservdelskatalog Parts Catalogue

Park 120


2F5820241/S16 - Season 2016

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
 - The contents described in the parts list may change due to improvement.
 - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
 - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


© Copyright 2016 Global Garden Products

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


www.stiga.com




Utgåva Issue 18 - 2016		Monteringsdetaljer Assembly parts			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	9595-0262-00	Spännstift	Locating Pin	
2	4	9959-0820-16	Skruv	Screw	
3	2	1134-4185-01	Ansatsbricka	Flange Washer	
4	4	112523060/0	Bricka	Washer	
5	2	1134-4734-01	Tändningsnyckel	Ignition Key	
6	1	1134-6113-01	Skruv	Screw	
11	1	137510307/0	Stift	Pin	
12	1	112642450/0	Stift	Pin	
13	1	1134-0072-02	Linhjul	Steering Pulley	
14	1	337774098/0	Fäste	Bracket	
15	1	112523060/0	Bricka	Washer	
16	1	322399804/1	Mutter	Nut	
17	1	112155000/0	Mutter	Nut	




Utgåva Issue 18 - 2016		Kaross Body works			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0854-01	Motorlucka Gul	Engine Hood Yellow	
2	2	1137-0861-01	Fjäder	Spring	
3	2	112728697/0	Skruv	Screw	
4	1	1137-0859-01	Lock	Cap	
5	1	337110314/0	Hougaiban	Rear Cover	
6	4	9893-0616-16	Skruv	Screw	
7	1	1137-1015-01	Packning	Gasket	
8	1	1137-1028-01	Packning	Gasket	
9	1	337110315/0	Motorlucka	Engine cover	
10	1	1137-0860-01	Stang	Rod	
11	1	337110316/0	Durk kpl - Gra	Footboard Cover Grey	
12	12	9893-0616-16	Skruv	Screw	
13	1	337110317/0	Kapa, gra	Grey Central Cover	
14	2	1134-4176-01	Clips	Clips	
15	1	337207101/0	Förvaringsfack	Tray	
16	1	337502506/0	Stötfångare	Bumper	
17	1	1137-0856-03	Luftledare	Air Guide	Park 120




Utgåva Issue 18 - 2016		Seat			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	125722477/0	Seat	Seat	
2	4	9945-0816-16	Skruv	Screw	
3	1	387785213/0	Sitsfäste	Seat Support	
4	1	1134-3134-01	Fjäder	Spring	
5	1	1134-3156-01	Brytare	Switch	
6	1	1134-3156-02	Brytare (gra)	Switch	
7	1	137430102/0	Fjäder	Spring	
9	1	112155000/0	Mutter	Nut	
10	2	1134-3144-01	Distans	Spacer	
11	2	9852-8013-16	Skruv	Screw	
12	1	1137-0862-01	Plåt	Plate	
13	1	9893-0616-16	Skruv	Screw	
14	1	1137-0872-01	Distans	Spacer	
15	1	9665-0002-00	Bricka	Washer	
16	1	112154510/0	Mutter	Nut	
17	1	1137-0867-01	Fäste	Bracket	
18	2	1134-0240-01	Ansattsskruv	Shoulder screw	
19	2	112155000/0	Mutter	Nut	
20	2	1137-0913-01	Knapp	Button	
21	2	112728697/0	Skruv	Screw	
22	1	1137-1033-01	Stang	Rod	
23	1	9675-0008-02	Starlockbricka	Starlock	
24	1	137510303/1	Stift	Pin	
25	1	127275000/0	Gummiplugg	Grommet	




Utgåva Issue 18 - 2016		Styrning Steering			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	1134-1901-01	Lager	Bearing	
2	1	1134-9025-01	Linhjul	Steering Pulley	
3	2	9653-0001-04	Sparryttare Rs	Lock Ring	
4	1	9945-0816-16	Skruv	Screw	
5	1	112523060/0	Bricka	Washer	
6	1	1137-0749-01	Fäste	Bracket	
7	1	9945-0816-16	Skruv	Screw	
8	1	1134-6378-02	Kedja	Chain	
9	4	112154220/0	Mutter	Nut	
10	1	1137-0905-01	Rattstang	Steering Column	
11	1	1134-2837-01	Distans	Spacer	
12	1	387962001/0	Ratt	Steering wheel	
13	1	1137-1000-01	Styrkonsolkapa, Svart	Steering Plate Cover	
14	1	1134-3751-01	Knopp	Knob	
15	1	1137-1005-01	Fäste	Support	
16	1	9699-0060-02	Bricka	Washer	
17	1	9997-0680-12	Skruv	Screw	
18	1	1134-1565-14	Distans	Spacer	
19	1	9403-0062-01	Lock	Cap	
20	1	9595-0210-00	Spiralspnst Prym N4X26	Locating Pin	
21	1	9699-0103-02	Bricka	Washer	




Utgåva Issue 18 - 2016		Reglage		Controls	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0992-01	Bromsvajer	Brake Cabel	
2	1	387500007/0	Bromspedal kpl	Pedal	
3	2	1134-6313-01	Lager	Bearing	
4	1	1137-0912-01	Distans	Spacer	
5	1	9997-0811-02	Skruv	Screw	
6	1	112154220/0	Mutter	Nut	
7	1	1137-0847-01	Fäste	Bracket	
8	2	9959-0620-16	Skruv	Screw	
9	2	9739-0631-22	Mutter	Nut	
10	1	1131-1507-00	Fjäder	Spring	
11	1	1137-0959-01	Bromspedal kpl	Pedal	
12	1	9930-0870-12	Skruv	Screw	
15	1	387318259/0	Fäste	Bracket	
16	2	1134-6313-01	Lager	Bearing	
17	1	1137-0802-01	Distans	Spacer	
18	1	112691800/0	Skruv	Screw	
19	1	112155000/0	Mutter	Nut	
20	1	337506741/0	Drivpedal	Drive Pedal	
21	2	9893-0616-16	Skruv	Screw	
22	1	1134-2766-10	Kablage	Cable	
23	2	9570-0001-00	Vinkellänk As8 Din 71802M5	Elbow Link	
24	2	9739-0531-22	Mutter	Nut	
25	2	112154330/0	Mutter	Nut	
26	1	337774041/0	Wirefäste	Wire Bracket	
27	2	9959-0620-16	Skruv	Screw	
28	2	9739-0631-22	Mutter	Nut	
29	1	1137-0928-01	Fäste	Bracket	
30	2	9959-0825-16	Skruv	Screw	
31	2	112154220/0	Mutter	Nut	
32	1	1134-0266-00	Fästbygel	Attaching Clamp	
33	1	1134-0267-00	Underläggsbleck	Clamp Plate	
34	1	112789008/0	Skruv	Screw	
35	1	9739-0531-22	Mutter	Nut	
36	1	1137-0784-01	Pedal	Pedal	
37	2	1134-0068-00	Lager (D20,4)	Bearing (D=20,4)	
38	1	1137-0795-01	Distans	Spacer	
39	1	9997-0814-02	Skruv	Screw	
40	1	9747-0831-02	Mutter Loc-King	Lock Nut	
41	1	1134-5824-01	Fjäder	Spring	
42	1	1137-0877-01	Pedal	Pedal	
43	1	9930-0820-16	Skruv	Screw	
44	1	1137-0958-01	Pedal	Pedal	
45	1	9595-0230-00	Stift	Pin	
46	1	1137-0792-01	Bromsstang	Brake Rod	
47	4	112604899/0	Starlock P6704 8 Fz	Crown Fastener	
48	1	1137-1092-01	Fjäder	Spring	
49	1	187000206/0	Kabel	Wire	
50	1	1134-0072-02	Linhjul	Steering Pulley	
51	1	1134-0041-01	Bussning	Bushing	




Utgåva Issue 18 - 2016		Reglage Controls			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
52	1	1137-0713-02	Fäste	Bracket	
53	1	112794300/0	Skruv	Screw	
54	1	9739-1031-22	Mutter	Nut	
56	2	1137-0952-01	Knopp	Knob	
57	1	1137-0837-01	Spak	Lever	P-broms/Parking brake
58	1	1137-0894-01	Gasreglage	Throttle Lever	
59	1	1137-0952-01	Knopp	Knob	
60	1	1137-0873-01	Plat	Plate	
61	2	112728697/0	Skruv	Screw	
62	1	1134-0240-00	Skruv	Screw	
63	1	1134-4242-01	Distansbricka	Washer	
64	1	9665-0002-00	Bricka	Washer	
65	1	9747-0831-02	Mutter Loc-King	Lock Nut	
66	1	1134-4197-01	Gasreglage	Throttle Cable	
67	1	9500-9991-00	Kabelklämma	Wire Clamp	
68	1	9943-0516-16	Skruv	Screw	
69	1	112604899/0	Starlock P6704 8 Fz	Crown Fastener	
70	1	9930-0820-16	Skruv	Screw	
71	1	9893-0616-16	Skruv	Screw	
72	1	1137-0825-01	Spak	Lever	
73	1	1137-0872-01	Distans	Spacer	
74	1	112789008/0	Skruv	Screw	
75	1	9739-0531-22	Mutter	Nut	
76	1	112800815/0	Skruv	Screw	
77	1	1134-4013-01	Distans	Spacer	
78	1	112604899/0	Starlock P6704 8 Fz	Crown Fastener	
79	1	1134-6368-01	Kedja	Chain	
80	1	137510315/0	Stift	Pin	
81	1	1134-2629-01	Schackel	Lift Link	




Utgåva Issue 18 - 2016		Motor	Engine		
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
2	1	1134-5825-01	Nippel	Nipple	
3	1	1137-1018-01	Oljeavtappningsrör	Oil Discharge Extension	
5	1	1137-0819-01	Ljuddämpare	Muffler	Park 120
6	1	1134-0433-00	Packning	Gasket	
7	2	1134-4930-01	Skruv	Screw	
10	1	1137-0815-01	Bränsletank	Tank	
11	1	1134-3224-01	Bensinkran	Fuel Shut-Off Valve	
12	1	1134-3225-01	Gummibussning	Grommet	
13	1	1134-2975-08	Bensinslang	Fuel Tube	Cutting length 0,6 mt - for engine WM 12 - WBE0702
14	1	9578-0023-02	Slangklämma D12*8 (Svart)	Hose Clamp	
15	1	1137-0838-01			
16	1	1135-2528-01	Gummimanschett	Rubber Cuff	
17	1	1134-5532-01	Tanklock	Fuel Tank Cap	
20	1	1137-0914-01	Fäste	Bracket	
21	3	9893-0616-16	Skruv	Screw	
22	2	112728697/0	Skruv	Screw	
23	1	9959-0820-16	Skruv	Screw	
24	2	9739-0631-22	Mutter	Nut	
25	1	1137-0777-01	Platta	Plate	
26	1	1137-1026-01	BränsleTankskydd	Tank Protection	
27	2	9893-0616-16	Skruv	Screw	
28	4	112793301/0	Skruv	Screw	
29	4	112154220/0	Mutter	Nut	
30	4	9955-3725-16	Skruv	Screw	




Utgåva Issue 18 - 2016		Ram Frame			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	387800019/0	Ram-Fram	Frame-Front	
2	1	1137-0869-01	Ram	Frame	
3	1	1137-0870-01	Ram	Frame	
4	4	112390007/0	Nit	Rivet	
5	4	9959-0825-16	Skruv	Screw	
6	4	112154220/0	Mutter	Nut	
7	1	9547-0008-01	Ledlager	Bearing	
8	1	1137-0963-01	Fäste	Support	
9	2	9699-0109-02	Bricka	Washer	
10	2	9997-1040-16	Skruv	Screw	
11	2	9739-1031-22	Mutter	Nut	
12	1	1137-0906-01	Remstyrning	Belt Guide	
13	2	9893-0616-16	Skruv	Screw	
14	1	1137-0893-01	Platta	Plate	
15	2	9959-0820-16	Skruv	Screw	
16	1	127275000/0	Gummiplugg	Grommet	
17	2	1137-0064-01	Dämpare	Rubber Cone	
18	2	112154220/0	Mutter	Nut	
22	1	1137-0923-01	Skydd	Protection	
23	2	112727801/0	Skruv	Screw	
24	2	9739-0631-22	Mutter	Nut	




Utgåva Issue 18 - 2016		Transmission			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-9168-01	Drivrem	Belt	
2	1	1131-1507-00	Fjäder	Spring	
3	1	1137-0890-01	Transaxel	Transmission Unit	
4	4	9960-0860-12	Skruv	Screw	
5	1	1137-0897-01	Plat	Plate	
6	2	112691400/0	Skruv	Screw	
7	2	112154220/0	Mutter	Nut	
10	1	1137-0714-01	Motorremskiva	Engine Pulley	
11	1	9600-0251-00	Kil	Key	
12	1	1134-5017-01	Bricka	Washer	
13	1	1137-0835-01	Distans	Spacer	
14	1	9987-5332-16	Skruv	Screw	
15	1	1137-0769-01	Spak	Lever	
16	1	112793905/0	Skruv	Screw	
17	1	112523060/0	Bricka	Washer	
18	1	1134-1565-08	Distans	Spacer	
19	1	112155000/0	Mutter	Nut	
20	1	1134-3459-01	Spännrulle	Tension Roller	
21	1	1134-5210-05	Distans	Spacer	
22	1	112692395/1	Skruv	Screw	
23	1	9739-1031-22	Mutter	Nut	
24	1	1137-0834-01	Stag	Rod	
25	1	112604896/0	Starlock P6493 6	Crown Fastener	
26	1	1137-0936-01	Fjäder	Spring	




Utgåva Issue 18 - 2016		Hjul Wheel			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	1134-4845-02	Navhylsa	Hub Sleeve	
2	2	1134-0341-01	Bricka	Washer	
3	2	187000451/1	Hjulnav	Wheel hub	
4	2	9545-0500-00	Ventil Kpl	Valve Assy.	
5	2	137950010/0	Däck	Tyre	
6	2	387680301/0	Hjul	Wheel	
7	2	1134-4981-01	Bricka	Washer	
8	2	9653-0001-04	Sparryttare Rs	Lock Ring	
9	2	1137-1006-01	Navkapsel	Hub Cap	
11	2	9595-0258-00	Spännstift	Locating Pin	
12	2	1134-0075-00	Framaxeltapp	Front Axle	
13	4	1134-0341-01	Bricka	Washer	
14	4	137038001/0	Bussning	Bush	
15	2	9545-0500-00	Ventil Kpl	Valve Assy.	
16	2	187000450/1	Hjulnav	Wheel hub	
17	2	137950010/0	Däck	Tyre	
18	2	387680303/0	Hjul	Wheel	
19	2	9699-0042-02	Bricka	Washer	
20	4	9599-0080-02	SaxSprint Sp 4*28	Cotter Pin	
45	1	13-0992-61	Rac Snabbfäste 2Wd Park	Rac Quick Connection 2Wd	
46	1	1134-7465-01	Sats-Fästen (Vä+Hö Inkl Skruv)	Attachment Kit	Inkl. pos 50-51
47	2	1137-0077-01	Lassprint	Locking Pin	
48	2	9548-0026-01	Glidlager 20E7X26-20	Bearing	
50	2	9898-1035-16	Skruv	Screw	
51	2	9739-1031-22	Mutter	Nut	



Utgåva Issue 18 - 2016		Kraftuttag PTO			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0791-01	Spak	Lever	
2	3	1134-2989-02	Spännrulle (Gra)	Tension Roller (Grey)	
3	2	9959-1025-16	Skruv	Screw	
4	3	1134-5548-01	Distans	Spacer	
5	1	1137-0918-01	Spak	Lever	
6	2	1134-5824-01	Fjäder	Spring	
7	1	1134-9167-01	Drivrem	Belt	
8	1	1137-0717-01	Remskiva	Belt Pulley	
10	1	1134-0051-08			
11	1	1134-9172-01	Drivrem	Belt	
12	1	1137-0863-01	Magnetkoppling	Magnet Clutch	
13	1	1137-0754-01	Magnetkoppling	Magnet Clutch	
14	1	9959-0820-16	Skruv	Screw	
15	1	112154220/0	Mutter	Nut	
16	1	1137-0741-01	Remskiva	Belt Pulley	
17	3	9945-0816-16	Skruv	Screw	
20	1	387773515/0	Fäste	Bracket	
21	1	9739-1031-22	Mutter	Nut	
22	1	112794400/0	Skruv	Screw	
23	1	387318257/0	Spak	Lever	
24	1	1134-6314-01	Spännarmsfäste	Tension Arm Attachment	
25	1	112689500/0	Skruv	Screw	
26	1	112154510/0	Mutter	Nut	
27	1	9930-1050-12	Skruv	Screw	
28	1	9699-0035-02	Bricka	Washer	
29	1	1134-4619-01	Distans	Spacer	
30	1	9739-1031-22	Mutter	Nut	
31	2	9959-0820-16	Skruv	Screw	
32	2	112154220/0	Mutter	Nut	
33	1	1137-1029-01	Fjäder	Spring	
34	1	1134-7829-01	Skruv	Screw	
35	1	1134-5127-01	Bricka	Washer	
36	1	1137-0800-01	Fäste	Bracket	
37	1	9959-0820-16	Skruv	Screw	Only Park 120
38	1	112154220/0	Mutter	Nut	Only Park 120
39	1	1137-1055-01	Värmskydd	Heat Guard	Only Park 120
40	1	112521350/0	Bricka	Washer	



Utgåva Issue 18 - 2016		Elsystem Electrical Parts			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	187040306/0	Kabelhärva	Harness	Incl. pos. 25
2	1	1134-3901-01	Solenoid	Solenoid	Incl. pos. 3
3	2	9743-5121-32	Mutter	Nut	
4	1	1134-4804-01	Batteri	Battery	
5	1	1137-1056-01	Fäste	Bracket	
6	2	1137-1057-01	Stang	Rod	
7	2	1134-4481-02	Vingmutter	Wing Nut	
8	2	112154510/0	Mutter	Nut	
9	1	1134-4093-01	Tändningslas	Ignition Switch	
10	1	1134-4749-01	Mutter	Nut	
11	2	112728697/0	Skruv	Screw	
12	1	9400-0282-01	Brytare (Med Diod)	Switch	
13	1	9400-0343-01	Vippa Pto (Röd)	Switch Cover-Pto	
14	1	1134-4129-01	Täckbricka	Cover	
15	1	1134-3399-01	Brytare	Switch	
16	4	9943-0516-16	Skruv	Screw	
17	1	1134-2167-03	Kabel (Minus)	Cable (-)	
18	1	1137-0664-01	Batterikabel (+)	Battery Cable (+)	
19	1	1134-0234-02	Batterikabel (+)	Battery Cable (+)	
20	1	112361005/0	Mutter	Nut	
21	1	118564864/1	Polskydd	Protection	
22	1	1134-2871-01	Relä	Relay	
23	1	1134-2871-03	Relä	Relay	
24	1	1134-3399-02	Brytare	Switch	
25	1	1134-3496-06	Säkring 20A Gul	Fuse (20A) Yellow	




STIGA — 1
Park 120 — 2



Utgåva Issue 18 - 2016		Dekaler Labels			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	3	114367494/2	Dekal STIGA logo	Label STIGA logo	
2	2	114369307/0	Dekal Park 120	Label Park 120	Park 120
3	1	9402-3650-02	Dekal "Bypass" Park (Svart Tryck)	Decal By-Pass Park	
4	1	114368429/0	Dekal	Label	

Utgåva Issue 18 - 2016		Transaxel		Transmission	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	118870120/0	Huvudhus	Main Housing	
10	1	1139-2022-01	Tätningssmassa	Sealant	
30	1	118870079/0	Tätningssring	Seal	
31	1	118870081/0	Lasring	Retaining ring	
32	1	1139-2203-01	Stag	Rod	
33	1	118870080/0	Lasring	Retaining ring	
34	1	118870091/0	Arm	Arm	
35	1	118870082/0	Lasring	Retaining ring	
40	1	118870090/0	Stänkplatta	Swashplate	
41	1	118870083/0	Skruv	Screw	
61	1	118870092/0	Drivaxel	Shaft	
62	1	1139-2001-01	Kullager	Ball Bearing	
63	1	1139-2003-01	Lasring	Wire Retaining Ring	
64	1	1139-2004-01	Distans	Spacer	
65	1	1139-2000-01	Tätning	Lip Seal	
66	1	1139-2002-01	Lasring	Retaining Ring	
70	1	118870125/0	Cylinderblock kpl	Pump Block Assy	
74	1	118870093/0	Lager	Bearing	
75	1	1139-2063-01	Cylinderblock	Cylinder Block	
79	1	1139-2021-01	Trycklager	Thrust Bearing	
100	1	118870072/0	Lasring	Retaining ring	
101	1	118870063/0	Drev	Gear	
104	1	118870115/0	Drivaxel	Shaft	
105	1	118870086/0	Bussning	Bushing	
106	1	118870085/0	Bussning	Bushing	
109	1	118870084/0	Lasring	Retaining ring	
110	2	1139-2204-01	Drivaxel	Shaft	
140	1	1139-2038-01	Nippel	Fitting	
141	1	118870102/0	Rör	Tube	
142	1	1139-2075-01	O-ring	O-Ring	
161	1	118870103/0	Arm	Arm	
162	1	1139-2026-01	Bult	Bolt	
163	1	1139-2011-01	Planbricka	Flat washer	
164	1	118870107/0	Arm kpl	Arm Assy	
165	1	118870108/0	Arm	Arm	
166	1	118870104/0	Bussning	Bushing	
167	1	118870089/0	Fjäder	Spring	
180	1	118870112/0	Platte	Plate	
200	1	118870123/0	Kit-Filter	Kit-Filter	
201	1	118870127/0	Kit-Centrumhus	Center Section Kit	
203	1	118870122/0	Kit-Expansionskärl	Kit-Expansion Tank	
204	1	118870061/0	Kit, Fläkt Remskiva	Kit, Fan Pulley	



Utgåva Issue 18 - 2016		Transaxel		Transmission	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
2	1	118870121/0	Sidohuset	Side Housing	
7	1	118870111/0	Tätningring	Seal	
8	14	1139-2042-01	Skruv	Screw	
13	1	1139-2010-01	Plugg	Plug	
80	1	118870070/0	Lasring	Retaining ring	
81	1	118870106/0	Drev	Gear	
82	1	118870095/0	Drivaxel	Shaft	
83	1	118870096/0	Bricka	Washer	
90	1	118870105/0	Drev	Gear	
91	1	118870098/0	Drev	Gear	
92	1	118870099/0	Stift	Pin	
93	3	1139-2016-01	Bricka	Washer	
100	1	118870072/0	Lasring	Retaining ring	
101	1	118870063/0	Drev	Gear	
103	1	118870116/0	Drivaxel	Shaft	
105	1	118870086/0	Bussning	Bushing	
106	1	118870085/0	Bussning	Bushing	
107	1	118870100/0	Drev	Gear	
109	1	118870084/0	Lasring	Retaining ring	
110	1	1139-2204-01	Drivaxel	Shaft	
120	2	118870066/0	Bromskloss	Brake Pad	
121	1	118870101/0	Broms	Brake	
122	1	118870067/0	Fäste, Bromskloss	Brake Pad Support	
124	1	118870119/0	Bromsok	Brake Caliper	
125	2	118870069/0	Stift	Pin	
126	1	118870062/0	Distans	Spacer	
127	1	118870077/0	Skruv	Screw	
128	1	118870071/0	Bult	Bolt	
129	1	118870076/0	Fjäder	Spring	
130	1	118870064/0	Bromsarm	Brake Lever	
131	1	1139-2011-01	Planbricka	Flat washer	
132	1	118870068/0	Mutter	Nut	
133	1	118870065/0	Stift	Pin	
134	1	118870075/0	Fjäder	Spring	
180	1	118870112/0	Plate	Plate	
195	1	118870126/0	Differentialdrev kpl	Kit-Gears and Pins	
205	1	118870124/0	Kit-Tätningring	Kit-Seal	

