



## **Reservdelskatalog Parts Catalogue**

# ***RAILS FOR Park Pro***


***13-3908-11 - Season 2015***

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
  - The contents described in the parts list may change due to improvement.
  - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
  - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

© Copyright 2015 Global Garden Products

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.

*[www.stiga.com](http://www.stiga.com)*



Utgåva Issue 17 - 2015		Fästen Rails			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
2	2	9897-0820-16	Skruv	Screw	
3	2	9747-0831-02	Mutter   Lasmutter	Nut	
4	1	9838-9530-12	Skruv	Screw	
10	1	1137-0138-01	rödska <span>­</span> sfäste	Tool Carrier	
11	2	1134-9028-01	Gummistropp (3 St)	Rubber Strap (3 Pcs)	Sats 3 st/kit of 3
12	8	9632-0516-00	Popnit Tap/D/Bs 416 Gf9.5	Pop Rivet	
13	4	9699-0120-02	Bricka	Washer	
14	4	9405-0029-00	Knopp	Knob	
15	4	9897-0640-12	Skruv	Screw	
16	4	9747-0631-02	Mutter   Lasmutter	Nut	

<b>code</b>	<b>pos.</b>	<b>q.ty</b>	<b>page</b>
1134-9028-01	11	2	p. 3
1137-0138-01	10	1	p. 3
9405-0029-00	14	4	p. 3
9632-0516-00	12	8	p. 3
9699-0120-02	13	4	p. 3
9747-0631-02	16	4	p. 3
9747-0831-02	3	2	p. 3
9838-9530-12	4	1	p. 3
9897-0640-12	15	4	p. 3
9897-0820-16	2	2	p. 3