



## **Reservdelskatalog Parts Catalogue**

# **READY**

**13-2715-14 - Season 2004**


- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
  - The contents described in the parts list may change due to improvement.
  - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
  - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

© Copyright 2004 Global Garden Products

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.





[www.stiga.com](http://www.stiga.com)

A









Utgåva Issue 20 - 2015		Topplöck (A)		Cylinder Head (A)	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	697396	Topplöck	Cylinder Head	21A907-0113
2	1	691843	Valve cap	Valve cap	21A907-0113
3	1	691279	Valve spring	Valve spring	21A907-0113
4	1	691279	Valve spring	Valve spring	21A907-0113
5	1	495856	Valve-exhaust	Valve-exhaust	21A907-0113
6	2	499586	Valve keeper	Valve keeper	21A907-0113
7	2	690964	Valve retainer	Valve retainer	21A907-0113
8	1	495857	Valve-intake	Valve-intake	21A907-0113
9	1	690968	Valve seal	Valve seal	21A907-0113
10	2	691986	Vipparmsjustering	Rocker arm adjuster	21A907-0113
11	2	691751	Vipparm	Rocker arm	21A907-0113
12	2	691095	Stud	Stud	21A907-0113
13	1	690822	Stötstangsstyrning	Push rod guide	21A907-0113
14	1	272475	Packning	Gasket	21A907-0113
15	1	273280	Topplöckspackning	Cylinder head gasket	21A907-0113
16	1	692138	O-ring	O-ring	21A907-0113
17	1	692492	Ventilkapa	Rocker cover	21A907-0113
18	4	691108	Skruv	Screw	21A907-0113
19	1	692137	Packning	Gasket	21A907-0113
20	1	697361	Insugningsrör	Intake Manifold	21A907-0113
21	2	691148	Skruv	Screw	21A907-0113
22	1	697394	Stötstang (insug)	Push rod (intake)	21A907-0146
22	1	697395	Stötstang (utblas)	Push rod (exhaust)	21A907-0113
23	2	690564	Valve tappet	Valve tappet	21A907-0113
24	8	690360	Skruv	Screw	21A907-0113

A







B









Utgåva Issue 20 - 2015		Cylinder (A) Vevaxel (B)		Cylinder (A) Crankshaft (B)	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	697377	Cylinder kpl	Cylinder Assy	21A907-0113
1	1	698375	Ring set	Ring set	Standard
1	1	698377	Ring set	Ring set	.020" oversize
1	1	698375	Ring set	Ring set	Standard _/ 21A907-0113
1	1	698377	Ring set	Ring set	.020" oversize _/ 21A907-0113
2	1	399265	Bussning	Bushing	21A907-0113
2	1	698371	Kolv kpl	Piston Assy	Standard
2	1	698373	Kolv kpl	Piston Assy	.020" oversize
2	1	698371	Kolv kpl	Piston Assy	Standard _/ 21A907-0113
2	1	698373	Kolv kpl	Piston Assy	.020" oversize _/ 21A907-0113
3	1	391086	Tätningring	Seal	21A907-0113
3	2	698469	Lasring	Lock	21A907-0113
4	2	690959	Tapp	Locating pin	21A907-0113
4	1	697390	Crankshaft	Crankshaft	21A907-0113
5	1	697144	Bussning	Bushing	21A907-0113
5	1	697128	Timing gear	Timing gear	21A907-0113
6	1	692407	Seal	Seal	21A907-0113
6	1	691639	Kil	Key	21A907-0113
7	2	697157	Skruv	Screw	21A907-0113
7	1	222698	Kil	Key	21A907-0113
8	1	697112	Cover	Cover	21A907-0113
8	1	697364	Connecting Rod	Connecting Rod	21A907-0113
9	1	697109	Packning	Gasket	21A907-0113
9	2	692852	Skruv	Screw	21A907-0113
10	1	697104	Skruv	Screw	21A907-0113
10	1	697099	Kolvsprint	Piston Pin	21A907-0113
11	1	697113	Breather Tube	Breather Tube	21A907-0113
11	1	697391	Motvikt	Counterweight	21A907-0113
12	1	697124	Breather reed	Breather reed	21A907-0113
12	1	697392	Stift	Pin	21A907-0113
13	1	692012	Governor crank	Governor crank	21A907-0113
13	1	697607	Länk	Link	21A907-0113
14	2	691691	Bricka	Washer	21A907-0113
14	2	697156	Plugg	Plug	21A907-0113
15	1	691620	Lasnal	Cotter pin	21A907-0113
15	1	697611	Oil dipstick assy	Oil dipstick assy	21A907-0113
16	1	697086	Oil dipstick	Oil dipstick	21A907-0113
17	1	691909	Spark plug boot	Spark plug boot	21A907-0113
17	1	691031	O-ring	O-ring	21A907-0113
18	1	9400-0244-00	Tändstift	Spark Plug	21A907-0113
18	1	697184	Oljerör	Dipstick tube	21A907-0113
19	1	89838	Hylsnyckel	Spark plug wrench	21A907-0113
19	1	691032	Tube seal	Tube seal	21A907-0113
20	1	697359	Cylinder shield	Cylinder shield	21A907-0113
21	1	691003	Skruv	Screw	21A907-0113
22	1	699016	Kamaxel	Camshaft	21A907-0113

A




B



Utgåva Issue 20 - 2015		Cylinder (A) Vevaxel (B) Cylinder (A) Crankshaft (B)			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
23	1	691968	Oil slinger	Oil slinger	21A907-0113
24	1	690946	Oil drain plug	Oil drain plug	21A907-0113
25	10	692125	Skruv	Screw	21A907-0113
26	1	690947	Oil seal	Oil seal	21A907-0113
27	1	697110	Packning	Gasket	21A907-0113
28	1	697106	Oljesump	Engine sump	21A907-0113


A







Utgåva Issue 20 - 2015		Regulator (A) Fläkthus (A)		Governor (A) Blower Housing (A)	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	691693	Skruv	Screw	
2	1	694042	Fäste	Control Bracket	
3	1	691024	Clamp	Clamp	
4	1	690804	Skruv	Screw	
5	1	690480	Regulatorfjäder	Governor Spring	
5	1	691795	Regulatorfjäder	Governor Spring	21A907-0113
6	1	691374	Governor lever	Governor lever	
7	1	691119	Bult	Bolt	
8	1	691251	Mutter	Nut	
9	1	696457	Generator	Alternator	
10	4	691183	Skruv	Screw	
11	1	393537	Anslutning	Connector	
12	1	698516	Bricka	Washer	
13	2	691061	Skruv	Screw	
14	1	492341	Armature magneto	Armature magneto	
15	1	493880	Terminal	Terminal	
16	1	694123	Wire clip	Wire clip	
17	1	697089	Stop wire	Stop wire	
18	1	697088	Skruv	Screw	
19	1	691188	Regulator	Regulator	
20	1	691841	Governor link	Governor link	
21	1	691842	Fjäder	Spring	
22	1	691840	Choke link	Choke link	
24	2	691003	Skruv	Screw	
25	1	697352	Guard	Guard	
26	1	698329	Kabelhärva	Wiring harness	
27	1	698139	Skruv	Screw	
28	4	697897	Skruv	Screw	
29	1	697133	Roterande skydd	Rotating screen	
30	2	697102	Skruv	Screw	
31	2	690372	Skruv	Screw	
32	1	699044	Fan	Fan	
33	1	698282	Flywheel	Flywheel	
34	1	19203	Avdragare	Puller	
35	1	697122	Insugningsrör	Intake elbow	
36	1	691917	O-ring	O-ring	
37	1	697123	O-ring	O-ring	
38	1	698368	Trim plate	Trim plate	
39	1	697870	Blower housing	Blower housing	
40	1	697420	Cover	Cover	
41	1	697419	Spärr	Latch	
42	1	698413	Lufffilter	Air Cleaner Filter	
43	1	697103	Skruv	Screw	
44	1	697292	Förfilter	Pre-cleaner filter	
45	1	697155	Retainer	Retainer	

A




17  
18



Utgåva Issue 20 - 2015		Startmotor (A) Packningssats (A)		Starter Motor (A) Gasket Set (A)	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	693551	Starter motor assy	Starter motor assy	
2	1	693699	Startdrev	Starter Drive	
3	1	691265	Retaining ring	Retaining ring	
4	1	693713	Drev	Pinion gear	
5	1	692024	Koppling	Drive clutch	
6	1	691283	Lock	Drive cap	
7	1	692034	Armature	Armature	
8	1	693757	Starter housing	Starter housing	
9	1	691029	Mutter	Nut	
10	1	691261	Bricka	Washer	
11	1	691293	Brush retainer	Brush retainer	
12	1	693167	Mutter	Nut	
13	1	497608	Brush set	Brush set	
14	2	690323	Bult	Bolt	
15	1	691286	Botten	End Cap	
16	1	691532	Strap	Strap	
17	1	691224	Wire clip	Wire clip	
18	1	690372	Skruv	Screw	
19	1	691581	Packningssats-motor	Gasket set-valve	
20	1	273280	Topplöckspackning	Cylinder head gasket	
21	1	692137	Packning	Gasket	
22	1	690968	Valve seal	Valve seal	
23	1	272475	Packning	Gasket	
24	1	697151	Packningssats-motor	Gasket set-engine	
25	1	391086	Tätningring	Seal	
26	1	697109	Packning	Gasket	
27	1	692407	Seal	Seal	
28	1	690947	Oil seal	Oil seal	
29	1	691917	O-ring	O-ring	
30	1	697123	O-ring	O-ring	
31	1	691032	Tube seal	Tube seal	
32	1	691031	O-ring	O-ring	
33	1	692138	O-ring	O-ring	
34	1	697110	Packning	Gasket	


A




31 CARBURETOR OVERHAUL KIT			
16	22	27	10
11	21	19	32
9	20	26	33
24			



Utgåva Issue 20 - 2015		Förgasare (A) Packningssats (A)		Carburettor (A) Gasket Set (A)	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	690958	Mutter	Nut	
2	2	690227	Stud	Stud	
3	1	699331	Fuel line	Fuel line	
4	2	95162	Slangklämma	Hose clamp	
5	1	394358	Bränslefilter	Fuel filter	
6	1	790019	Förgasare kpl	Carburettor Assy	
7	1	790175	Spjällsaxeln	Throttle Shaft	
8	1	790024	Gasspjäll	Throttle Valve	
9	1	691636	Skruv	Screw	
10	1	691326	Shaft seal	Shaft seal	
11	1	690602	Shaft bushing	Shaft bushing	
12	1	699027	Choke shaft	Choke shaft	
13	1	690802	Spring and seal	Spring and seal	
14	1	691227	Choke valve	Choke valve	
15	1	495800	Skruv	Screw	
16	1	692137	Packning	Gasket	
17	1	498030	Nalventil	Needle valve	
18	1	691333	Begränsningshuv	Limiter cap	
19	1	790025.	Nozzle	Nozzle	Standard
20	1	694524	Welch plug	Welch plug	
21	1	690577	Säte	Inlet seat	
22	1	231855	Nalventil	Inlet needle valve	
23	1	698174	Nippel	Hose connector	
24	1	690525	Flottörxel	Float hinge pin	
25	1	494381	Flottör	Float	
26	1	495933	Bowl	Bowl	
27	1	281165	Packning	Gasket	
28	1	692255	Bricka	Washer	
29	1	691657	Skruv	Screw	
30	1	790028	Nozzle	Nozzle	High altitude
31	1	790031.	Carb.overhaul kit	Carb.overhaul kit	
32	1	691917	O-ring	O-ring	
33	1	697123	O-ring	O-ring	




Utgåva Issue 20 - 2015		Transaxel		Transmission	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
0	1	1134-5281-01	Transaxel (Dana 4360-197)	Transaxle (Dana 4360-197)	/4360-197/
1	1	F000-7033-00	Hus-Övre	Housing-Upper	/4360-197/
2	16	F000-1919-00	Skruv	Screw	
3	2	F000-5947-00	Kula	Detent Ball	
4	2	F000-5948-00	Fjäder	Spring, Detent	
5	1	F084-0052-00	Skruv	Screw	/4360-197/
6	1	F000-6517-00	Växelförare	Assy, Kit, Shifter	/4360-197/
7	1	F000-7010-00	Hylsa	V-Ring	/4360-197/
8	3	F000-5510-00	Flänslager	Bearing, Flange	
9	1	F000-5508-00	Tätningring	Seal, Oil	/4360-197/
10	1	F000-1106-00	Lasring	Ring, Retaining	/4360-197/
11	4	F000-4689-00	Sats-Shims	Assy, Kit, Shim, .625 Shaft	
12	1	F000-5511-00	Flänslager	Bearing, Flange	/4360-197/
13	2	F000-3876-00	Bricka	Washer	
14	1	F000-1746-00	Woodruffkil	Woodruff Key	/4360-197/
15	1	F000-6205-00	Ingaende Axel Kpl	Input Shaft Assy	/4360-197/
16	1	F000-5620-00	Drev	Pinion, Bevel, 12T	12T/4360-197/
17	1	F000-3624-00	Lasring	Ring, Retaining	/4360-197/
18	1	F000-3625-00	Kedja	Chain, 24 Pitches	24 link/4360-197/
19	1	F000-5950-00	Lock	Cover, Detent	/4360-197/
20	1	F000-5627-00	Drev 12T	Gear, Spur, 12T	12T/4360-197/
21	1	F000-5303-00	Hylsa	Collar, Clutch	/4360-197/
22	1	F000-4758-00	Sats-Kilar	Assy, Kit, Clutch Keys	/4360-197/
23	1	F000-3847-00	Mutter	Nut	/4360-197/
24	1	F000-5737-00	Mellanaxel	Shaft, Intermediate	/4360-197/
25	1	F000-1375-00	Woodruffkil	Woodruff Key	/4360-197/
26	1	F000-3627-00	Lasring	Ring, Retaining	/4360-197/
27	1	F000-3830-00	Kedjehjul 18T	Sprocket, 18T	18T/4360-197/
28	1	F000-3841-00	Distans	Spacer	/4360-197/
29	1	F000-5365-00	Drev 37T	Gear, Spur, 37T	37T/4360-197/
30	1	F000-3867-00	Drev 30T	Gear, Spur 30T	30T/4360-197/
31	1	F000-3783-00	Drev 25T	Gear, Spur 25T	25T/4360-197/
32	1	F000-3869-00	Drev 22T	Gear, Spur 22T	22T/4360-197/
33	1	F000-5202-00	Drev 19T	Gear, Spur, 19T	19T/4360-197/
34	1	F000-5027-00	Distans	Spacer	/4360-197/
35	1	F000-3628-00	Bricka	Washer	/4360-197/
36	1	F000-1425-00	Bricka	Washer	/4360-197/
37	1	F000-4691-00	Sats-Shims	Assy, Kit, Shim, .750 Shaft	/4360-197/
38	1	F000-6358-00	Drev 12T+30T	Assy, Gear, Comb., 12T & 30T	12T+30T/4360-197/
39	1	F000-3967-00	Axel	Shaft, Idler	/4360-197/
40	1	F000-7003-00	Drev 36T	Gear, Bevel, 36T	36T/4360-197/
41	1	F000-3630-00	Distans	Spacer	/4360-197/
42	1	F000-3645-00	Kedjehjul 9T	Sprocket, 9T	9T/4360-197/
43	1	F000-5016-00	Distans	Spacer	/4360-197/
44	1	F000-5015-00	Drivaxel	Drive Shaft	/4360-197/
45	1	F000-5364-00	Drev 12T	Gear, Spur, 12T	12T/4360-197/
46	1	F000-3866-00	Drev 20T	Gear, Spur 20T	20T/4360-197/
47	1	F000-3719-00	Drev 25T	Gear, Spur, 25T	25T/4360-197/
48	1	F000-3868-00	Drev 28T	Gear, Spur 28T	28T/4360-197/






Utgåva Issue 20 - 2015		Transaxel		Transmission	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
49	1	F000-3683-00	Drev 31T	Gear, Spur, 31T	31T/4360-197/
50	1	F000-3714-00	Distans	Spacer	/4360-197/
51	1	F000-1145-00	Bricka	Washer	/4360-197/
52	2	F000-5130-00	Bricka	Washer	
53	2	F000-3184-00	Bricka	Washer	
54	1	F000-7031-10	Hjulaxel-Vä	Wheel Axle-Lh	/4360-197/
55	2	F000-5622-00	Drev 12T	Gear, Miter, 12T, Splined	12T
56	2	F000-5270-00	Lasring	Ring, Retaining	
57	1	F000-3839-00	Drev 32T	Gear, Spur, 32T	32T/4360-197/
58	1	F000-3919-00	Axel	Shaft, Cross	/4360-197/
59	2	F000-5623-00	Drev 12T	Gear, Miter, 12T, Idler	12T
60	1	F000-7031-20	Hjulaxel-Hö	Wheel Axle-Rh	/4360-197/
61	1	F000-5304-M0	Hus-Undre	Housing-Lower	/4360-197/
62	1	F000-5960-00	Bromsskiva	Disc, Brake	/4360-197/
63	1	F000-3758-00	Distans	Spacer	/4360-197/
64	1	F000-5554-00	Bromshallare	Jaw, Brake	/4360-197/
65	2	F000-3843-00	Sprint	Dowel	
66	2	F000-5562-00	Skruv	Screw	
67	1	F000-7032-00	Bromsarm	Actuating Lever	/4360-197/
68	1	F000-3760-00	Bricka	Washer	/4360-197/
69	1	F000-5555-00	Bricka	Bracket, Anti-Rotation	/4360-197/
70	2	F000-3907-00	Friktionsbelägg	Puck,Friction	
98	1	F000-4300-00	Smörjfett	Grease	Ej ill/not ill.




Utgåva Issue 20 - 2015		Monteringsdetaljer		Accessory Bag	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
0	1	1134-4664-04	Tillbehörspåse	Accessory Bag	
1	1	9595-0262-00	Spännstift	Locating Pin	
2	1	9699-0103-02	Bricka	Washer	0.5 mm
2	1	9699-0114-02	Bricka	Washer	1.0 mm
2	1	9699-0103-02	Bricka	Washer	0.5 mm
2	1	9699-0114-02	Bricka	Washer	1.0 mm
3	2	1134-4185-01	Ansatsbricka	Flange Washer	
5	4	9699-0056-02	Bricka	Washer	
6	2	1134-4481-01	Vingmutter	Wing Nut	
7	1	1134-4627-01	Dragkrok	Tow Bar	
8	2	9959-0820-16	Skruv	Screw	
9	4	9997-0820-16	Skruv	Screw	
10	1	1134-4734-01	Tändningsnyckel	Ignition Key	
11	1	1134-5245-01	Batterirem	Battery Strap	
12	1	1111-2113-01	Stang	Rod	
13	1	1134-2960-02	Nyckel för tändningslas	Spark Plug Wrench	5/8" (16 mm)
13	1	1134-4541-01	Nyckel för tändningslas	Spark Plug Wrench	5/8" (16 mm)/21 mm
20	1	1134-3771-71	Fp.Instr.Bok (Stiga Ready)	Folder W.Manuals (Ready)	
21	1	8211-0209-11	Säkerh. Föreskrifter Front Mowers	Safety Regulations Front Mowers	
21	1	8211-0209-12	Säkerhetsföreskrifter	Safety Regulations	
21	1	8211-0334-01	Monteringsanvisning	Assy Instruction Ready	
21	1	8211-0335-01	Bruksanvisning	Owner's Manual	
21	1	8211-0343-01	Bruksanvisning	Owner's Manual	
21	1	8211-0344-01	Bruksanvisning	Owner's Manual	
21	1	8211-2002-03	Garantikort Rider	Warranty Card	



Utgåva Issue 20 - 2015		Kaross Body Work			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5283-01	Motorhuv (Gra) 7-14	Engine Hood (Grey)	
2	7	9838-9530-12	Skruv	Screw	
3	1	1134-5284-01	Motorlucka Gul	Engine Hood Yellow	
4	1	1134-5307-01	Stötfangare, fram-hö	Mud Guard-Lh (Grey)	
5	1	1134-5307-02	Skärm-Hö (Gra) 7-14	Mud Guard-Rh (Grey)	
6	2	1134-0225-00	Stödplat	Support Plate	
7	4	9699-0056-02	Bricka	Washer	
8	6	9945-0816-16	Skruv	Screw	
9	4	1134-4176-01	Clips	Clips	
10	4	9893-0616-16	Skruv	Screw	
11	1	1134-5306-01	Stötfangare Front-Vä Gra	Bumper Front-Lh (Grey)	
12	1	1134-5306-02	Stötfangare Front-Hö Gra	Bumper Front-Rh (Grey)	
13	1	1134-5305-01	Front Nedre Gul	Lower Hood Yellow	
14	6	9893-0616-16	Skruv	Screw	
15	1	1134-5304-01	Front Övre (Gul) 1-00	Front Upper (Yellow)	
16	2	9946-0525-16	Skruv	Screw	
17	2	1134-4790-02	Styrning	Hood Guide (Black)	
18	2	9838-9530-12	Skruv	Screw	
99	1	1134-5591-01	Dekal	Label	




Utgåva Issue 20 - 2015		Ram	Frame		
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5546-02	Ram	Frame Assy	
2	1	1134-5293-01	Durk (Gra) 7-14	Floor Plate (Grey)	
3	2	9893-0616-16	Skruv	Screw	
4	1	1134-5338-01	Durkmatta-Manuell	Floor Mat-Manual	
5	1	1134-5453-01	Stötfångare-bakre	Rear Bumper (Black)	
6	1	1134-5334-01	Stag-vä	Attachment-Lh	
7	1	1134-5334-02	Stag-hö	Attachment-Rh	
8	2	1134-0240-00	Skruv	Screw	
9	2	1134-4242-01	Distansbricka	Washer	
10	2	9694-0001-00	Bricka	Washer	
11	2	9747-0831-02	Mutter	Nut	
12	2	9943-0516-16	Skruv	Screw	
13	2	9959-0820-16	Skruv	Screw	
14	2	9959-0825-16	Skruv	Screw	
15	1	9739-0831-22	Mutter	Nut	
16	3	9739-0831-22	Mutter	Nut	




1151C




Utgåva Issue 20 - 2015		Pedallyft Pedal lift			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4117-01	Fäste	Bracket	
2	2	9959-1025-16	Skruv	Screw	
2	2	9997-1040-16	Skruv	Screw	
3	2	9739-1031-22	Mutter	Nut	
4	2	1134-2684-01	Lager	Bearing	
5	1	1134-4945-01	Lyftspärr kpl	Lift Catch Assy	
9	1	9404-0027-01	O-ring	O-ring	
10	1	9650-0039-04	Sparring Sga 8	Lock Ring	
11	1	9595-0276-01	Spiralspännstift 8*24	Locating Pin	
12	1	9997-0640-12	Skruv	Screw	
13	1	9747-0631-02	Mutter	Nut	
15	1	9897-0820-16	Skruv	Screw	
16	1	9747-0831-02	Mutter	Nut	
17	1	1134-4860-01	Lyftgaffel	Lift Fork	
18	2	1134-0240-00	Skruv	Screw	
19	1	1134-4938-01	Lyftpedal	Lift Pedal	
20	2	9997-0625-16	Skruv	Screw	
21	2	9739-0631-22	Mutter	Nut	
22	1	4231-0013-00	Fjäder	Spring	




Utgåva Issue 20 - 2015		Sits Seat			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5506-01	Sits "Stiga"	Seat Stiga	
3	1	1134-5301-01	Sitsplatta	Upper Seat Bracket	
4	2	1134-0240-00	Skruv	Screw	
5	2	9747-0831-02	Mutter	Nut	
6	1	1134-5454-01	Spärr	Catch	
7	1	9675-0012-02	Starlock	Locking washer	
12	1	1134-5296-01	Sitskonsol Kpl (Gul) 1-00	Seat Bracket (Gelb)	
12	1	1134-5296-04	Sitskonsol Kpl (Gul) 1-00	Seat Bracket (Yellow)	
12	1	1134-5296-01	Sitskonsol Kpl (Gul) 1-00	Seat Bracket (Gelb)	
12	1	1134-5296-04	Sitskonsol Kpl (Gul) 1-00	Seat Bracket (Yellow)	
13	1	1134-4256-01	Fjäder	Spring	
14	1	9924-1235-19	Skruv	Screw	
15	1	9747-1231-02	Mutter	Nut	
16	1	9997-0840-16	Skruv	Screw	
17	1	1134-1565-06	Distans	Spacer	
18	1	1134-5302-01	Fjäder	Spring	
19	1	1134-5299-01	Tryckplatta	Push Plate	
20	1	9699-0090-02	Bricka   Bricka	Washer   Washer	
21	1	9747-0831-02	Mutter	Nut	
22	1	1134-3156-02	Brytare (gra)	Switch	
28	3	9959-0820-16	Skruv	Screw	L = 20 mm
29	2	9959-0825-16	Skruv	Screw	L = 25 mm
30	2	9699-0056-02	Bricka	Washer	
31	4	9739-0831-22	Mutter	Nut	



Utgåva Issue 20 - 2015		Styrning Steering			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	3	1134-0041-01	Bussning	Bushing	
2	3	1134-0046-00	Wireklämma	Wire Clamp	
2	3	1134-3022-01	Fäste	Bracket	
2	3	1134-0046-00	Wireklämma	Wire Clamp	
2	3	1134-3022-01	Fäste	Bracket	
3	1	1134-9025-01	Linhjul	Steering Pulley	Sats 2 st/kit of 2
4	3	9997-1040-16	Skruv	Screw	
5	2	9739-1031-22	Mutter	Nut	
6	1	1134-2032-04	Styrwire	Steering Cable	
7	1	1134-1310-01	Fjäder	Spring	
8	1	9699-0056-02	Bricka	Washer	
9	1	9747-0831-02	Mutter	Nut	
10	1	9959-0820-16	Skruv	Screw	
11	1	1134-5349-03	Styrkonsol Kpl (Gra) 7-14	Steering Console (Grey)	
12	4	9897-0820-16	Skruv	Screw	
13	4	9739-0831-22	Mutter	Nut	
15	1	1134-1305-05	Rattrör Nedre	Steering Column,Lower	
16	2	1134-1901-01	Lager	Bearing	
17	2	9893-0616-16	Skruv	Screw	
18	2	9699-0060-02	Bricka	Washer	
19	1	1134-5495-01	Rattstang	Steering Rod	
20	1	1134-1933-01	Linhjul	Steering Pulley	
21	1	9595-0262-00	Spännstift	Locating Pin	
22	1	1134-5496-01	Ratt	Steering Wheel	
32	1	1134-3047-01	Distans	Spacer	
33	2	9699-0104-02	Bricka	Washer	
36	2	1134-3047-01	Distans	Spacer	
37	1	1134-0041-05	Bussning	Bushing	
38	1	1134-0046-00	Wireklämma	Wire Clamp	
38	1	1134-3022-01	Fäste	Bracket	
38	1	1134-0046-00	Wireklämma	Wire Clamp	
38	1	1134-3022-01	Fäste	Bracket	
39	1	1134-9025-01	Linhjul	Steering Pulley	Sats 2 st/kit of 2
40	1	9997-1060-12	Skruv	Screw	




Utgåva Issue 20 - 2015		Handreglage Hand Controls			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5286-01	Reglagepanel-Vä (Gra)	Dashboard-Lh (Grey)	
2	2	1134-5531-01	Dämpare	Absorber	
3	3	9893-0616-16	Skruv	Screw	
4	1	1134-5357-01	Fäste	Bracket	
5	2	9838-9516-12	Skruv	Screw	
6	1	1134-4077-01	Gasreglage	Throttle Cable	
7	1	1134-4078-01	Knopp	Knob	
8	1	1134-0240-00	Skruv	Screw	
9	1	9694-0001-00	Bricka	Washer	
10	2	1134-4242-01	Distansbricka	Washer	
11	1	9747-0831-02	Mutter	Nut	
12	1	1134-1597-13	Gasreglage	Throttle Cable	
13	1	9500-9991-00	Kabelklämma	Wire Clamp	
14	1	9943-0516-16	Skruv	Screw	
15	1	9579-0003-00	Buntband	Cable Holder	
20	1	9997-0812-02	Skruv	Screw	
21	1	1134-5274-02	Distans	Spacer	
22	3	1134-3047-01	Distans	Spacer	
23	1	1134-5271-01	Reglagefäste	Control Bracket	
24	1	1134-5275-01	Växelspak Kpl	Gearshift Lever	
25	1	1134-5535-01	Fjäder	Spring	
26	1	9997-0890-12	Skruv	Screw	
27	1	9747-0831-02	Mutter	Nut	
28	1	1134-5268-01	Stang	Shifter Rod	
29	1	9675-0009-02	Starlockbricka	Starlock	
30	1	1134-5271-01	Reglagefäste	Control Bracket	
31	1	1134-5276-01	Reglagespak Kpl	Control Lever	
32	1	9997-0890-12	Skruv	Screw	
33	1	9747-0831-02	Mutter	Nut	
34	1	1134-5356-01	Reaktionsstag	Strut	
35	1	9747-0831-02	Mutter	Nut	
36	2	9400-0312-01	Mikrobrytare	Microswitch	
37	4	9840-7716-16	Skruv	Screw	
38	1	1134-5358-01	Brytarfäste	Switch Bracket	
39	2	9943-0516-16	Skruv	Screw	
40	1	1134-5285-01	Reglagepanel Man-Hö (Gra)	Dashboard Man-Rh (Grey)	
41	2	1134-5531-01	Dämpare	Absorber	
42	4	9893-0616-16	Skruv	Screw	
43	2	1134-2551-01	Knopp	Knob	
44	1	1134-3573-06	Kraftuttagwire	Pto Cable	
45	1	1134-1242-02	Fjäder	Spring	
50	1	1134-4093-01	Tändningslas	Ignition Switch	
51	1	1134-4749-01	Mutter	Nut	
52	1	1134-4734-01	Tändningsnyckel	Ignition Key	








Utgåva Issue 20 - 2015		Fotreglage		Foot Controls	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4802-01	Pedal5-01 F15	Pedal	
2	2	1134-4624-01	Lager	Bearing	
3	4	9898-0635-12	Skruv	Screw	
4	4	9739-0631-22	Mutter	Nut	
5	1	1134-4795-01	Kopplingsstang	Clutch Rod	
6	1	1134-2138-01	Skruvögla	Eye Bolt	
7	1	9739-1031-22	Mutter	Nut	
8	1	9747-1031-02	Mutter	Nut	
9	1	9739-0831-22	Mutter	Nut	
10	1	9747-0831-02	Mutter	Nut	
11	1	9595-0208-00	Spiralspnst Prym N4X20	Locating Pin	
14	1	1134-4777-01	Bromsstang	Brake Rod	
15	1	1134-4617-01	Fjäder	Spring	
16	1	1134-2138-01	Skruvögla	Eye Bolt	
17	3	9699-0035-02	Bricka	Washer	
18	2	9595-0208-00	Spiralspnst Prym N4X20	Locating Pin	
19	1	9739-0831-22	Mutter	Nut	
20	1	9747-0831-02	Mutter	Nut	
26	1	1134-5353-01	Bromsstang	Brake Rod	
27	1	1134-2786-01	Knopp	Knob	
28	1	1131-1497-01	Fjäder	Brake Spring	
29	1	1134-4002-01	Fäste	Brake Rod Attachment	
30	3	9838-9516-12	Skruv	Screw	
31	1	1134-4714-01	Vinkelfäste	Angle Bracket	
32	2	9959-0820-16	Skruv	Screw	
33	2	9739-0831-22	Mutter	Nut	
34	1	1134-4715-01	Plattriangel	Triangular Plate	
35	1	1134-0240-00	Skruv	Screw	
36	1	9694-0001-00	Bricka	Washer	
37	1	9699-0036-02	Bricka	Washer	
38	1	9747-0831-02	Mutter	Nut	
39	1	1134-4717-01	Gängstang	Threaded Rod	
39	1	1134-4717-02	Gängstang	Threaded Rod	
39	1	1134-4717-02	Gängstang	Threaded Rod	
40	2	9570-0004-00	Vinkellänk As 10 Din71802M6	Elbow Link	
41	2	9747-0631-02	Mutter	Nut	
42	2	9739-0631-22	Mutter	Nut	
43	1	1134-4722-01	Växelarm	Shifter Lever	
43	1	1134-5279-01	Växelarm	Shift Lever	
43	1	1134-5279-01	Växelarm	Shift Lever	
44	1	9987-5016-16	Skruv	Screw	
45	1	9699-0060-02	Bricka	Washer	
46	1	9675-0009-02	Starlockbricka	Starlock	
51	1	1134-4793-01	Stopplat	Stop Plate	
52	1	4231-0013-00	Fjäder	Spring	
53	1	1134-4779-01	Bussning	Bushing	
54	2	9595-0208-00	Spiralspnst Prym N4X20	Locating Pin	
55	1	1134-2138-01	Skruvögla	Eye Bolt	
56	1	1134-4779-01	Bussning	Bushing	




Utgåva Issue 20 - 2015		Foot Controls			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
57	1	9739-0831-22	Mutter	Nut	
58	1	9747-0831-02	Mutter	Nut	



Utgåva Issue 20 - 2015		Elutrustning El. Equipment			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4804-01	Batteri	Battery	
8	1	1134-2042-02	Batterikabel	Battery Cable	L = 350 mm
9	1	9838-9516-12	Skruv	Screw	
10	1	9747-0831-02	Mutter	Nut	
11	1	9795-3531-02	Mutter	Nut	1/4 UNC
12	3	9579-0003-00	Buntband	Cable Holder	
12	4	9579-0003-00	Buntband	Cable Holder	
22	1	9699-0060-02	Bricka	Washer	
26	1	1134-2962-01	Solenoid Kpl Service	Solenoid	
27	2	9794-5131-02	Mutter	Nut	
28	1	1134-4702-01	Kabel (+)	Cable (+)	L = 380 mm
29	1	1134-2310-01	Batteriskydd	Guard Cap (+)	
30	1	1134-4702-02	Kabel (+)	Cable	L = 480 mm
32	1	1134-5321-01	Kablage	Harness	
32	1	1134-5766-01	Kablage	Harness (Ready Manual)	




Utgåva Issue 20 - 2015		Motor	Engine		
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	4	9997-0840-16	Skruv	Screw	
2	4	9747-0831-02	Mutter	Nut	
5	1	1134-5266-01	Bränsletank	Fuel Tank	
6	1	1134-2877-03	Tanklock	Fuel Tank Cap	
7	1	1134-3224-01	Bensinkran	Fuel Shut-Off Valve	
8	1	1134-3225-01	Gummibussning	Grommet	
9	1	1134-2975-05	Bensinslang	Fuel Tube	L = 460 mm
10	2	9578-0023-02	Slangklämma D12*8 (Svart)	Hose Clamp	
12	1	1134-4808-01	Tankbygel	Tank Clamp	
13	1	9699-0060-02	Bricka	Washer	
14	1	9747-0631-02	Mutter	Nut	
15	1	1134-4807-02	Fäste	Support	
16	4	9829-8830-12	Skruv	Screw	
19	1	1134-0433-00	Packning	Gasket	
22	2	1134-4930-01	Skruv	Screw	
23	1	1134-5455-01	Ljuddämpare Kpl	Muffler Assy	
24	1	9739-0831-22	Mutter	Nut	
25	1	9959-0820-16	Skruv	Screw	
26	1	1134-5457-01	Värmskydd (Svart) 5-01	Heat Guard (Black)	
27	4	9893-0616-16	Skruv	Screw	













Utgåva Issue 20 - 2015		Transmission		Transmission	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4611-01	Motorremskiva	Engine Belt Pulley	
4	1	1134-5414-01	Remstyrning	Belt Guide	
5	1	9699-0056-02	Bricka	Washer	
6	1	1134-4519-01	Spännarm Kpl. 5-01 F15	Tension Arm	
7	1	1134-3053-01	Spännrulle	Tension Roller	
7	1	1134-9091-01	Spännrulle	Tension Roller	
7	1	1134-3053-01	Spännrulle	Tension Roller	
7	1	1134-9091-01	Spännrulle	Tension Roller	
8	1	1134-4614-01	Distans	Spacer	
9	1	9997-1040-16	Skruv	Screw	
10	1	9699-0035-02	Bricka	Washer	
11	1	9739-1031-22	Mutter	Nut	
12	1	1134-9027-01	Spännrulle (Svart)	Tension Roller (Black)	
13	1	1134-1795-01	Remhallare	Belt Stirrup	
14	1	9997-1040-16	Skruv	Screw	
15	2	9699-0035-02	Bricka	Washer	
16	1	9739-1031-22	Mutter	Nut	
17	1	1134-9065-01	Kilrem	V-Belt	= 9585-0124-01
18	1	1134-1565-08	Distans	Spacer	
19	1	9997-0865-12	Skruv	Screw	
19	1	9997-0870-16	Skruv	Screw	
19	1	9997-0865-12	Skruv	Screw	
19	1	9997-0870-16	Skruv	Screw	
20	2	9699-0056-02	Bricka	Washer	
21	1	9739-0831-22	Mutter	Nut	
22	1	1134-5214-01	Fjäder	Spring	
23	1	1134-5281-01	Transaxel (Dana 4360-197)	Transaxle (Dana 4360-197)	Dana 4360-197
24	4	9997-0865-12	Skruv	Screw	
24	4	9997-0870-16	Skruv	Screw	
24	4	9997-0865-12	Skruv	Screw	
24	4	9997-0870-16	Skruv	Screw	
25	4	9747-0831-02	Mutter	Nut	
26	1	1134-4687-01	Momentstag 5-01 F24	Strut	
27	1	9945-0816-16	Skruv	Screw	
28	1	1134-1849-01	Remskiva	Belt Pulley	
30	1	9650-0016-04	Sparring Sga 16	Circlip	
31	1	1134-4707-01	Remstyrning	Belt Guide	
32	1	9942-0820-16	Skruv	Screw	
41	1	1134-2138-01	Skruvögla	Eye Bolt	
42	1	1134-4779-01	Bussning	Bushing	
43	1	9739-0831-22	Mutter	Nut	
44	1	9747-0831-02	Mutter	Nut	



Utgåva Issue 20 - 2015		Hjul Wheels			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5257-01	Bakaxel	Rear Axle	
2	2	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
3	1	1134-5009-02	Spindel Kpl-Vä (5-01 H40)	Stub Axle	
4	1	1134-5009-01	Spindel Kpl-Hö (5-01 H40)	Right Stub Axle	
5	2	9699-0088-02	Bricka	Washer	
6	2	9650-0020-04	Sparring Sga 20	Circlip	
7	1	1134-5316-01	Linhjul	Steering Pulley	
8	1	1134-5317-01	Axel	Shaft	
9	1	1134-9024-01	Lager (4 St)	Bearing	Sats 4 st/kit of 4
10	1	1134-0341-01	Bricka	Washer	
11	1	9650-0020-04	Sparring Sga 20	Circlip	
12	2	1134-3247-05	Styrstag	Tie Rod	
13	2	9997-0825-16	Skruv	Screw	L = 25 mm
13	1	9997-0835-12	Skruv	Screw	L = 35 mm
13	2	9997-0825-16	Skruv	Screw	L = 25 mm
13	1	9997-0835-12	Skruv	Screw	L = 35 mm
14	2	9699-0028-02	Bricka	Washer	
15	3	9747-0831-02	Mutter	Nut	
16	2	1134-4706-01	Fälg (3.50 X 6)	Rim	
17	1	1134-9026-01	Bussning	Bearing	Sats 4 st/kit of 4
18	2	9545-0117-00	Däck	Tyre	13 x 5.00 - 6
19	2	9545-0500-00	Ventil	Valve Assy.	
20	2	1134-0341-01	Bricka	Washer	
21	2	9650-0020-04	Sparring Sga 20	Circlip	
22	2	1134-4344-01	Kapsel (Svart)	Hub Cap Black	
25	1	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
26	1	9699-0088-02	Bricka	Washer	
27	1	9650-0020-04	Sparring Sga 20	Circlip	
28	2	1134-5255-01	Fälg	Rim	
29	2	9545-0126-01	Däck	Tyre	16 x 6.00 - 8
30	2	9545-0500-00	Ventil	Valve Assy.	
31	6	9699-0035-02	Bricka	Washer	
32	6	9747-1031-02	Mutter	Nut	
33	2	1134-2471-03	Kil	Key	
34	2	04/01/9653			
35	4	1134-0341-01	Bricka	Washer	
36	2	1134-4844-02	Hjulnav Kpl	Wheel Hub Assy	
37	2	1134-4845-01	Navhylsa	Hub Sleeve	
38	2	1134-4981-01	Bricka	Washer	
98	1	9545-0204-00	Innerslang	Inner Tube	Reservdel/spare part
99	1	9545-0203-00	Innerslang	Inner Tube	Reservdel/spare part



Utgåva Issue 20 - 2015		Power Take-Off			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5046-01	Motorremskiva	Engine Pulley	
2	1	1134-5017-01	Bricka	Washer	
3	1	9987-5332-16	Skruv	Screw	
4	1	1134-5058-01	Remstyrning	Belt Guide	
5	1	1134-5057-01	Remstyrning	Belt Guide	
6	1	9600-0251-01	Kil	Key	L = 2 1/2"
8	1	1134-4650-01	Monteringsbygel5-01 H40	Pulley Bracket	
9	2	9945-0816-16	Skruv	Screw	
10	1	1134-4643-01	Mellanremskiva Smst	Intermediate Belt Pulley	
11	1	1134-0051-12	Distans	Spacer	
12	2	9549-0019-00	Kullager	Ball Bearing	
14	2	1134-0052-00	Distans	Spacer	
15	1	9997-1040-16	Skruv	Screw	
16	1	9699-0035-02	Bricka	Washer	
17	1	1134-9079-01	Drivrem	Drive Belt	= 9585-0139-01
18	1	1134-5231-01	Spännarm 5-01 F24	Tension Arm	
19	1	1134-9027-01	Spännrulle (Svart)	Tension Roller (Black)	
20	1	1134-4619-01	Distans	Spacer	
21	1	9997-1060-12	Skruv	Screw	
22	1	9739-1031-22	Mutter	Nut	
23	1	1134-5232-01	Spännarmsfäste	Holder-Tension Arm	
24	1	9997-0640-12	Skruv	Screw	
25	1	9747-0631-02	Mutter	Nut	
26	1	1134-4619-01	Distans	Spacer	
27	1	9997-1040-16	Skruv	Screw	
28	1	9699-0035-02	Bricka	Washer	
29	1	9739-1031-22	Mutter	Nut	
30	1	1134-4708-02	Fäste	Bracket	
31	2	9945-0816-16	Skruv	Screw	
36	1	1131-1507-00	Fjäder	Spring	
40	1	1134-5037-01	Bygel Kpl (Svart) 5-01 F15	Mounting Bracket (Black)	
41	1	1134-1769-02	Remskiva	Belt Pulley	
42	1	1134-0051-09	Distans	Spacer	
43	2	9549-0019-00	Kullager	Ball Bearing	
44	1	1134-1839-02	Mellanaxel	Shaft	
45	1	9699-0035-02	Bricka	Washer	
46	1	9739-1031-22	Mutter	Nut	
47	1	9997-1070-12	Skruv	Screw	
48	1	1134-5541-01	Kopplingsarm	Clutch Lever	
49	1	1134-1565-10	Distans	Spacer	
50	1	9997-0860-16	Skruv	Screw	
51	1	9699-0056-02	Bricka	Washer	
52	1	9739-0831-22	Mutter	Nut	
53	1	1134-9027-01	Spännrulle (Svart)	Tension Roller (Black)	
54	1	1134-1795-01	Remhallare	Belt Stirrup	
55	1	9997-1040-16	Skruv	Screw	
56	2	9699-0035-02	Bricka	Washer	
57	1	9739-1031-22	Mutter	Nut	
58	1	1134-9078-01	Drivrem	Drive Belt	= 9585-0138-01



Utgåva Issue 20 - 2015		Power Take-Off			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
59	1	1134-4164-01	Bromsklots	Brake Pad	
60	1	9959-0820-16	Skruv	Screw	
61	1	9699-0090-02	Bricka   Bricka	Washer   Washer	
62	1	9747-0831-02	Mutter	Nut	
63	2	9959-0820-16	Skruv	Screw	
64	2	9739-0831-22	Mutter	Nut	
65	1	9699-0056-02	Bricka	Washer	
66	1	1131-1506-00	Fjäder	Spring	
67	1	9997-0860-16	Skruv	Screw	
68	2	9739-0831-22	Mutter	Nut	







code	pos.	q.ty	page									
9997-0890-12	32	1	p. 31	691095	12	2	p. 3	697103	43	1	p. 9	
9997-1040-16	2	2	p. 25	691108	18	4	p. 3	697104	10	1	p. 5	
9997-1040-16	4	3	p. 29	691119	7	1	p. 9	697106	28	1	p. 7	
9997-1040-16	9	1	p. 41	691148	21	2	p. 3	697109	9	1	p. 5	
9997-1040-16	14	1	p. 41	691183	10	4	p. 9	697109	26	1	p. 11	
9997-1040-16	15	1	p. 45	691188	19	1	p. 9	697110	27	1	p. 7	
9997-1040-16	27	1	p. 45	691224	17	1	p. 11	697110	34	1	p. 11	
9997-1040-16	55	1	p. 45	691227	14	1	p. 13	697112	8	1	p. 5	
9997-1060-12	21	1	p. 45	691251	8	1	p. 9	697113	11	1	p. 5	
9997-1060-12	40	1	p. 29	691261	10	1	p. 11	697122	35	1	p. 9	
9997-1070-12	47	1	p. 45	691265	3	1	p. 11	697123	30	1	p. 11	
19203	34	1	p. 9	691279	3	1	p. 3	697123	33	1	p. 13	
89838	19	1	p. 5	691279	4	1	p. 3	697123	37	1	p. 9	
95162	4	2	p. 13	691283	6	1	p. 11	697124	12	1	p. 5	
222698	7	1	p. 5	691286	15	1	p. 11	697128	5	1	p. 5	
231855	22	1	p. 13	691293	11	1	p. 11	697133	29	1	p. 9	
272475	14	1	p. 3	691326	10	1	p. 13	697144	5	1	p. 5	
272475	23	1	p. 11	691333	18	1	p. 13	697151	24	1	p. 11	
273280	15	1	p. 3	691374	6	1	p. 9	697155	45	1	p. 9	
273280	20	1	p. 11	691532	16	1	p. 11	697156	14	2	p. 5	
281165	27	1	p. 13	691581	19	1	p. 11	697157	7	2	p. 5	
391086	3	1	p. 5	691620	15	1	p. 5	697184	18	1	p. 5	
391086	25	1	p. 11	691636	9	1	p. 13	697292	44	1	p. 9	
393537	11	1	p. 9	691639	6	1	p. 5	697352	25	1	p. 9	
394358	5	1	p. 13	691657	29	1	p. 13	697359	20	1	p. 5	
399265	2	1	p. 5	691691	14	2	p. 5	697361	20	1	p. 3	
492341	14	1	p. 9	691693	1	2	p. 9	697364	8	1	p. 5	
493880	15	1	p. 9	691751	11	2	p. 3	697377	1	1	p. 5	
494381	25	1	p. 13	691795	5	1	p. 9	697390	4	1	p. 5	
495800	15	1	p. 13	691840	22	1	p. 9	697391	11	1	p. 5	
495856	5	1	p. 3	691841	20	1	p. 9	697392	12	1	p. 5	
495857	8	1	p. 3	691842	21	1	p. 9	697394	22	1	p. 3	
495933	26	1	p. 13	691843	2	1	p. 3	697395	22	1	p. 3	
497608	13	1	p. 11	691909	17	1	p. 5	697396	1	1	p. 3	
498030	17	1	p. 13	691917	29	1	p. 11	697419	41	1	p. 9	
499586	6	2	p. 3	691917	32	1	p. 13	697420	40	1	p. 9	
690227	2	2	p. 13	691917	36	1	p. 9	697607	13	1	p. 5	
690323	14	2	p. 11	691968	23	1	p. 7	697611	15	1	p. 5	
690360	24	8	p. 3	691986	10	2	p. 3	697870	39	1	p. 9	
690372	18	1	p. 11	692012	13	1	p. 5	697897	28	4	p. 9	
690372	31	2	p. 9	692024	5	1	p. 11	698139	27	1	p. 9	
690480	5	1	p. 9	692034	7	1	p. 11	698174	23	1	p. 13	
690525	24	1	p. 13	692125	25	10	p. 7	698282	33	1	p. 9	
690564	23	2	p. 3	692137	16	1	p. 13	698329	26	1	p. 9	
690577	21	1	p. 13	692137	19	1	p. 3	698368	38	1	p. 9	
690602	11	1	p. 13	692137	21	1	p. 11	698371	2	1	p. 5	
690802	13	1	p. 13	692138	16	1	p. 3	698371	2	1	p. 5	
690804	4	1	p. 9	692138	33	1	p. 11	698373	2	1	p. 5	
690822	13	1	p. 3	692255	28	1	p. 13	698373	2	1	p. 5	
690946	24	1	p. 7	692407	6	1	p. 5	698375	1	1	p. 5	
690947	26	1	p. 7	692407	27	1	p. 11	698375	1	1	p. 5	
690947	28	1	p. 11	692492	17	1	p. 3	698377	1	1	p. 5	
690958	1	2	p. 13	692852	9	2	p. 5	698377	1	1	p. 5	
690959	4	2	p. 5	693167	12	1	p. 11	698413	42	1	p. 9	
690964	7	2	p. 3	693551	1	1	p. 11	698469	3	2	p. 5	
690968	9	1	p. 3	693699	2	1	p. 11	698516	12	1	p. 9	
690968	22	1	p. 11	693713	4	1	p. 11	699016	22	1	p. 5	
691003	21	1	p. 5	693757	8	1	p. 11	699027	12	1	p. 13	
691003	24	2	p. 9	694042	2	1	p. 9	699044	32	1	p. 9	
691024	3	1	p. 9	694123	16	1	p. 9	699331	3	1	p. 13	
691029	9	1	p. 11	694524	20	1	p. 13	790019	6	1	p. 13	
691031	17	1	p. 5	696457	9	1	p. 9	790024	8	1	p. 13	
691031	32	1	p. 11	697086	16	1	p. 5	790025	19	1	p. 13	
691032	19	1	p. 5	697088	18	1	p. 9	790028	30	1	p. 13	
691032	31	1	p. 11	697089	17	1	p. 9	790031	31	1	p. 13	
691061	13	2	p. 9	697099	10	1	p. 5	790175	7	1	p. 13	
				697102	30	2	p. 9	F000-1106-00	10	1	p. 15	

code	pos.	q.ty	page				
F000-1145-00	51	1	p. 17	F000-7031-20	60	1	p. 17
F000-1375-00	25	1	p. 15	F000-7032-00	67	1	p. 17
F000-1425-00	36	1	p. 15	F000-7033-00	1	1	p. 15
F000-1746-00	14	1	p. 15	F084-0052-00	5	1	p. 15
F000-1919-00	2	16	p. 15				
F000-3184-00	53	2	p. 17				
F000-3624-00	17	1	p. 15				
F000-3625-00	18	1	p. 15				
F000-3627-00	26	1	p. 15				
F000-3628-00	35	1	p. 15				
F000-3630-00	41	1	p. 15				
F000-3645-00	42	1	p. 15				
F000-3683-00	49	1	p. 17				
F000-3714-00	50	1	p. 17				
F000-3719-00	47	1	p. 15				
F000-3758-00	63	1	p. 17				
F000-3760-00	68	1	p. 17				
F000-3783-00	31	1	p. 15				
F000-3830-00	27	1	p. 15				
F000-3839-00	57	1	p. 17				
F000-3841-00	28	1	p. 15				
F000-3843-00	65	2	p. 17				
F000-3847-00	23	1	p. 15				
F000-3866-00	46	1	p. 15				
F000-3867-00	30	1	p. 15				
F000-3868-00	48	1	p. 15				
F000-3869-00	32	1	p. 15				
F000-3876-00	13	2	p. 15				
F000-3907-00	70	2	p. 17				
F000-3919-00	58	1	p. 17				
F000-3967-00	39	1	p. 15				
F000-4300-00	98	1	p. 17				
F000-4689-00	11	4	p. 15				
F000-4691-00	37	1	p. 15				
F000-4758-00	22	1	p. 15				
F000-5015-00	44	1	p. 15				
F000-5016-00	43	1	p. 15				
F000-5027-00	34	1	p. 15				
F000-5130-00	52	2	p. 17				
F000-5202-00	33	1	p. 15				
F000-5270-00	56	2	p. 17				
F000-5303-00	21	1	p. 15				
F000-5304-M0	61	1	p. 17				
F000-5364-00	45	1	p. 15				
F000-5365-00	29	1	p. 15				
F000-5508-00	9	1	p. 15				
F000-5510-00	8	3	p. 15				
F000-5511-00	12	1	p. 15				
F000-5554-00	64	1	p. 17				
F000-5555-00	69	1	p. 17				
F000-5562-00	66	2	p. 17				
F000-5620-00	16	1	p. 15				
F000-5622-00	55	2	p. 17				
F000-5623-00	59	2	p. 17				
F000-5627-00	20	1	p. 15				
F000-5737-00	24	1	p. 15				
F000-5947-00	3	2	p. 15				
F000-5948-00	4	2	p. 15				
F000-5950-00	19	1	p. 15				
F000-5960-00	62	1	p. 17				
F000-6205-00	15	1	p. 15				
F000-6358-00	38	1	p. 15				
F000-6517-00	6	1	p. 15				
F000-7003-00	40	1	p. 15				
F000-7010-00	7	1	p. 15				
F000-7031-10	54	1	p. 17				