




# Genuine Spare Parts

---







Utgåva Issue		Bildnr Picture No		SD 12,5/96 KAROSS		SD 12,5/96 BODY WORK		Sida Page
2005- 13		1811						2
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571							
1	1			1132-2114-01	Grill- grå.....	Front grill- grey .....		With choke W/o choke
1	1			1132-2116-01	Grill- svart .....	Front grille- black .....		
2	2			1811-2021-01	Skruv .....	Screw .....		
3	2			1132-2059-01	Mutter.....	Nut .....		
4	2			9743-3521-32	Mutter.....	Nut .....		
5	2			9743-3621-32	Mutter.....	Nut .....		
6	2			1132-2104-01	Bricka .....	Washer.....		
7	2			1132-2106-01	Nit.....	Rivet.....		
8	1			1132-2117-01	Strålkastarlins.....	Headlamp lens .....		
9	2			1132-2165-01	Ansattsskruv.....	Shoulder screw .....		
10	2			1132-2193-01	Stödstag- grill .....	Grille support rod .....		
11	1			1132-2219-01	Motorhuv- röd .....	Engine hood- red.....		
11	1			1132-2220-01	Motorhuv- gul .....	Engine hood- yellow .....		
12	1			1132-2018-01	Kablage- strålkastare .....	Harness- headlamp .....		
13	2			9400-0293-01	Glödlampa .....	Bulb .....		
14	2			1132-2092-01	Lampsockel .....	Lampholder.....		
15	2			1132-2095-01	Snabbmutter.....	Speed nut.....		
16	2			1132-2161-01	Ansattsskruv.....	Shoulder screw .....		
21	1			1132-2003-01	Tankfäste .....	Tank bracket .....		
22	6			1132-2038-01	Skruv .....	Screw .....		
23	4			1132-2041-01	Skruv .....	Screw .....		
24	2			1132-2043-01	Skruv .....	Screw .....		
25	2			1132-2105-01	Mutter.....	Nut .....		
26	1			1132-2109-01	Instrumentpanel .....	Dashboard .....		
26	1			1132-2110-01	Instrumentpanel .....	Dashboard .....		
27	1			1132-2115-01	Rattstångsbälg.....	Steer. rubber bellows .....		
28	2			9699-0100-02	Bricka .....	Washer.....		



Utgåva Issue		Bildnr Picture No		SD 12,5/96 RAM		SD 12,5/96 FRAME		Sida Page	
2005- 13		1809						4	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	1				1132-2004- 01	Stödstag- hö .....	Axle support brkt- RH.....		
2	1				1132-2005- 01	Stödstag- vä .....	Axle support brkt- LH .....		
3	2				1132-2012- 01	Brytarplatta.....	Switch plate .....		
4	1				1132-2029- 01	Lyftspak .....	Lift handle .....		
5	1				1132-2031- 01	Lyftaxel .....	Lift shaft.....		
6	4				1811-2018- 01	Skruv .....	Hex bolt.....		
7	4				1132-2038- 01	Skruv .....	Screw .....		
8	1				9987-5119- 16	Skruv .....	Screw .....		
9	1				1811-2021- 01	Skruv .....	Screw .....		
10	13				1811-2023- 01	Skruv .....	Hex bolt.....		
11	4				9988-3619- 16	Skruv .....	Screw .....		
12	1				9988-3645- 16	Skruv .....	Screw .....		
13	5				9743-3621- 32	Mutter.....	Nut .....		
14	2				9795-3531- 02	Mutter.....	Nut .....		
15	1				1132-2066- 01	Låsring .....	Lock ring .....		
16	1				1132-2080- 01	Handtag .....	Grip .....		
17	1				1132-2119- 01	Tryckfjäder .....	Comp spring .....		
18	1				1132-2129- 01	Bandfjäder .....	Switch actuat. spring .....		
19	2				9678-0008- 02	Låsbricka .....	Lock washer .....		
20	2				9683-0025- 02	Låsbricka .....	Lock washer .....		
21	2				1132-2171- 01	Flänslager .....	Flange bushing.....		
22	1				1132-2180- 01	Batteribygel .....	Battery hold down rod .....		
23	1				1132-2188- 01	Förbindning .....	Lift shaft connector .....		
24	1				1132-2222- 01	Batterihylla.....	Battery tray .....		
25	1				1132-2223- 01	Dragplatta .....	Hitch plate .....		
26	1				1132-2224- 01	Nedre ram.....	Lower frame.....		
27	1				1132-2225- 01	Ramplåt- vä .....	Frame side panel- LH .....		
28	1				1132-2226- 01	Ramplåt- hö .....	Frame side panel- RH .....		
29	1				1132-2234- 01	Fäste .....	Deck anti-sway brkt.....		
31	1				1134-5751- 01	Batteri .....	Battery .....		




Utgåva Issue  2005- 13		Bildnr Picture No  1810		SD 12,5/96 SKÄRM		SD 12,5/96 FENDER		Sida Page  6	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	1				1132-2006-01	Fotplatta, hö- gul.....	Foot rest, RH- yellow.....		
1	1				1132-2006-02	Fotplatta, hö- röd .....	Foot rest, RH- red .....		
2	1				1132-2009-01	Bakskärm- gul.....	Fender- yellow .....		
2	1				1132-2009-02	Bakskärm- röd .....	Fender- red .....		
3	2				1811-2023-01	Skruv .....	Hex bolt.....		
4	4				9988-3516-16	Skruv .....	Screw .....		
5	2				1132-2047-01	Skruv .....	Screw .....		
6	6				9988-3619-16	Skruv .....	Screw .....		
7	6				9743-3621-32	Mutter.....	Nut .....		
8	4				9743-3521-32	Mutter.....	Nut .....		
9	2				1132-2196-01	Distans .....	Spacer .....		
10	1				1132-2231-01	Fotplatta, vä- gul .....	Foot rest, LH- yellow .....		
10	1				1132-2231-02	Fotplatta, vä- röd .....	Foot rest, LH- red .....		
21	1				1132-2084-01	Fotstegsmatta- hö .....	Foot rest pad- RH .....		
22	1				1132-2083-01	Fotstegsmatta- vä .....	Foot rest pad- LH .....		
31	2				1132-2037-01	Skruv .....	Screw .....		
32	2				1132-2038-01	Skruv .....	Screw .....		
33	1				1132-2091-01	Fjäderbrytare .....	Switch spring .....		
34	1				1132-2103-01	Isolerplatta.....	Insulator plate .....		
35	2				1132-2105-01	Mutter.....	Nut .....		
36	1				1132-2228-01	Växelplåt .....	Shift cover panel .....		









Utgåva Issue		Bildnr Picture No		SD 12,5/96 SITS		SD 12,5/96 SEAT		Sida Page
2005- 13		1812						8
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571							
1	1			1132-2001-01	Fäste-sitslyft .....	Seat lift bracket .....		
2	1			1132-2010-01	Sitsfäste- hö .....	Seat support brkt- RH .....		
3	1			1132-2011-01	Sitsfäste- vä .....	Seat support brkt- LH .....		
4	2			1132-2037-01	Skruv .....	Screw .....		
5	4			1132-2023-01	Remskiva .....	Belt pulley .....		
6	2			9743-3621-32	Mutter .....	Nut .....		
7	1			1132-2087-01	Fjäderbrytare- yttre .....	Seat spr switch- outer .....		
8	1			1132-2090-01	Fjäderbrytare- inre .....	Seat spr switch- inner .....		
9	1			1132-2101-01	Isolerplatta .....	Insulator plate boss .....		
10	2			1132-2102-01	Isolerplatta .....	Insulator plate .....		
11	1			1132-2127-01	Fjäder .....	Spring .....		
12	2			1132-2156-01	Ansattsskruv .....	Shoulder screw .....		
21	2			1132-2044-01	Skruv .....	Screw .....		
22	2			1132-2122-01	Tryckfjäder .....	Comp spring .....		
23	2			1132-2160-01	Ansattsskruv .....	Spacer screw .....		
24	1			1132-2229-01	Sitsfäste .....	Seat pivot bracket .....		
25	1			1132-2215-01	Sits .....	Seat .....		




Utgåva Issue		Bildnr Picture No		SD 12,5/96 STYRNING		SD 12,5/96 STEERING		Sida Page	
2005- 13		1813						10	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	1				1132-2000-01	Hållare-sektordrev.....	Gear segm. plate ret.....		15 x 6 x 6
2	1				1132-2025-01	Framaxel .....	Pivot bar .....		
3	1				9988-3725-16	Skruv .....	Screw .....		
4	1				9988-3625-16	Skruv .....	Screw .....		
5	4				1811-2023-01	Skruv .....	Hex bolt.....		
6	1				9988-3638-12	Skruv .....	Screw .....		
7	1				9931-3619-16	Skruv .....	Screw .....		
8	1				9743-5321-32	Mutter.....	Nut .....		
9	1				9743-5221-32	Mutter.....	Nut .....		
10	1				9743-3621-32	Mutter.....	Nut .....		
11	3				1132-0695-01	Mutter.....	Nut .....		
12	2				9727-3641-22	Mutter.....	Nut .....		
13	2				9599-0070-02	Saxsprint .....	Split pin.....		
14	1				1132-2073-01	Styrsektordrev .....	Steering segment gear .....		
16	1				1132-2085-01	Kulled .....	Ball joint.....		
17	1				1132-2097-01	Lock.....	Cap.....		
18	2				1132-2108-01	Skyddslock .....	Axle end cap.....		
19	1				1132-2135-01	Bricka .....	Washer.....		
20	1				1811-2062-01	Bricka .....	Bell washer .....		
21	1				1132-2148-01	Tallriksbricka.....	Washer.....		
23	1				1132-2155-01	Ansattsskruv.....	Shoulder screw .....		
24	2				1132-2162-01	Ansattsskruv.....	Shoulder screw .....		
25	1				1132-2163-01	Rattstång .....	Steering shaft.....		
26	1				1132-2170-01	Bussning .....	Bushing.....		
27	4				1132-2171-01	Flänslager .....	Flange bushing.....		
28	1				1132-2172-01	Flänslager .....	Hex flange bushing .....		
29	1				1132-2178-01	Styrstag .....	Tie rod.....		
30	1				1132-2186-01	Styrstag .....	Steering drag link.....		
31	1				1132-2187-01	Skyddslock .....	Cap.....		
32	1				1132-2189-01	Styrarm .....	Steering arm .....		
33	1				1132-2190-01	Distans .....	Spacer .....		
34	1				1132-2197-01	Distansbricka .....	Spacer washer .....		
35	1				1132-2218-01	Framaxelfäste .....	Pivot bar bracket .....		
41	2				1132-2021-01	Framhjul kpl.....	Front wheel assy .....		
41A	1				1132-2242-01	• Däck .....	• Tire.....		
41B	1				1132-2241-01	• Fälg .....	• Rim .....		
41C	1				9545-0500-00	• Ventil .....	• Valve .....		
42	1				1132-2027-01	Hjulspindel- vä.....	Wheel spindle- LH.....		
43	1				1132-2028-01	Hjulspindel- hö.....	Wheel spindle- RH.....		
44	2				9599-0070-02	Saxsprint .....	Split pin.....		
45	2				1132-2134-01	Bricka .....	Washer.....		
46	2				1132-2140-01	Bricka .....	Washer.....		
47	2				1132-2113-01	Navkapsel .....	Hub cap.....		
51	1				1132-2020-01	Ratt.....	Steering wheel .....		
52	1				1132-2107-01	Rattlock .....	Steering wheel cap.....		



Utgåva Issue  2005- 13		Bildnr Picture No  1818		SD 12,5/96 REGLAGE		SD 12,5/96 CONTROLS		Sida Page  12	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	1				1132-2054-01 Länk.....	Ferrule.....			
2	1				1132-2062-01 Saxpinne.....	Cotter pin .....			
3	1				1132-2081-01 Handtag .....	Shift handle grip.....			
4	1				1132-2120-01 Tryckfjäder.....	Comp spring .....			
5	1				1132-2141-01 Bricka .....	Washer.....			
6	1				1132-2181-01 Reglagestång.....	Speed control rod .....			
7	1				1132-2194-01 Distans .....	Spacer.....			
8	1				1132-2227-01 Växelspak .....	Speed select lever .....			
9	1				1132-2121-01 Dragfjäder.....	Extension spring .....			
10	1				1132-2226-01 Ramplåt- hö .....	Frame side panel- RH .....			
11	1				1132-2008-01 Pedalfäste.....	Pedal mounting brkt.....			
12	1				1132-2026-01 Koppling/bromspedal .....	Clutch/brake pedal .....			
13	4				9988-3619- 16 Skruv .....	Screw .....			
14	4				9743-3621-32 Mutter.....	Nut .....			
15	1				1132-2097-01 Lock.....	Cap.....			
16	1				1132-2133-01 Pedalgummi .....	Foot pad .....			
17	1				1132-2199-01 Distans .....	Spacer.....			




Utgåva Issue 2005- 13		Bildnr Picture No 1814		SD 12,5/96 ELSYSTEM		SD 12,5/96 EL. SYSTEM		Sida Page 14	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2571								
1	1			1132-2088-01	Tändningslås kpl.....	Ignition switch assy .....			
1A	2			1132-2239-01	• Tändningsnyckel.....	• Ignition key .....			
2	2			9400-0293-01	Glödlampa .....	Bulb .....			
3	2			1132-2092-01	Lampsockel .....	Lampholder .....			
4	1			1132-2089-01	Solenoid .....	Solenoid .....			
5	1			1132-2093-01	Brytare .....	Safety switch .....			
6	1			1134-5751-01	Batteri .....	Battery .....			
7	2			1132-2086-01	Brytare .....	Switch .....			
8	1			1132-2091-01	Fjäderbrytare .....	Switch spring .....			
8A	1			1132-2103-01	Isolerplatta .....	Insulator plate .....			
9	1			1132-2017-01	Kablage .....	Harness .....			
10	1			1132-2018-01	Kablage- strålkastare .....	Harness- headlamp .....			
21	1			1132-2017-01	Kablage .....	Harness .....			
22	2			1132-2086-01	Brytare .....	Switch .....			
23	1			1132-2088-01	Tändningslås kpl.....	Ignition switch assy .....			
23A	1			1132-2239-01	• Tändningsnyckel.....	• Ignition key .....			
24	1			1132-2089-01	Solenoid .....	Solenoid .....			







Utgåva Issue  2005- 13		Bildnr Picture No  1815		SD 12,5/96 MOTOR (Briggs & Stratton)		SD 12,5/96 ENGINE (Briggs & Stratton)		Sida Page  16	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	4				1132-2036-01	Skruv .....	Screw .....		
2	2				1811-2023-01	Skruv .....	Hex bolt.....		
3	4				1132-2045-01	Skruv .....	Screw .....		
4	1				1132-2048-01	Skruv .....	Screw .....		
5	2				9931-3619-16	Skruv .....	Screw .....		
6	4				9955-3732-12	Skruv .....	Screw .....		
7	1				9795-3531-02	Mutter.....	Nut .....		
8	1				1134-0433-00	Ljuddämparpackning .....	Muffler gasket .....		
9	1				9579-0008-00	Buntband .....	Cable holder .....		
10	2				1132-2096-01	Slangklämma .....	Hose clamp .....		
11	1				1132-2118-01	Oljeavtappningsränna .....	Oil drain sleeve.....		
13	1				213146	Klämma .....	Clamp .....		
14	1				1132-2202-01	Bränsleslang .....	Fuel hose .....		
15	1				1132-2204-01	Deflektor .....	Muffler deflector .....		
16	1				1132-2206-01	Ljuddämpare .....	Muffler .....		
17	1				1132-2208-01	Avgasrör .....	Exhaust tube .....		
18	1				1132-2238-01	Ljuddämparskydd .....	Muffler heat shield .....		
21	1				9987-5332-16	Skruv .....	Screw .....		
22	2				1132-2056-01	Remstyrning.....	Belt keeper pin .....		
23	2				9683-0030-02	Låsbricka .....	Lock washer .....		
24	1				9683-0045-02	Bricka .....	Washer .....		
25	1				1132-2142-01	Bricka .....	Washer .....		
26	1				1132-2200-01	Distans .....	Spacer.....		
27	1				1132-2213-01	Motorremskiva .....	Engine belt pulley .....		
31	1				1132-2098-01	Buntband .....	Cable tie .....		
32	1				1132-2203-01	Bränsletank.....	Fuel tank .....		
33	1				1132-2205-01	Tanklock .....	Fuel tank cap .....		
41	1				1132-2176-01	Gasreglage.....	Throttle cable .....		
42	1				1132-2177-01	Chokereglage.....	Choke cable.....		




Utgåva Issue 2005- 13		Bildnr Picture No 1816		SD 12,5/96 MOTOR (Tecumseh)		SD 12,5/96 ENGINE (Tecumseh)		Sida Page 18	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	4				1132- 2036- 01	Skruv .....	Screw .....		
2	2				1811- 2023- 01	Skruv .....	Hex bolt .....		
3	4				1132- 2045- 01	Skruv .....	Screw .....		
4	2				9931- 3619- 16	Skruv .....	Screw .....		
5	4				9955- 3732- 12	Skruv .....	Screw .....		
6	1				9795- 3531- 02	Mutter .....	Nut .....		
7	1				1134- 0433- 00	Ljuddämparpackning .....	Muffler gasket .....		
9	1				9579- 0008- 00	Buntband .....	Cable holder .....		
10	2				1132- 2096- 01	Slangklämma .....	Hose clamp .....		
11	1				1132- 2100- 01	Kabelklämma .....	Cable clamp .....		
12	1				1132- 2153- 01	Oljeavtappningsplugg .....	Oil drain plug .....		
14	1				1132- 2154- 01	Oljeavtappningsrör .....	Oil drain tube .....		
15	1				1132- 2202- 01	Bränsleslang .....	Fuel hose .....		
16	1				1132- 2204- 01	Deflektor .....	Muffler deflector .....		
17	1				1132- 2206- 01	Ljuddämpare .....	Muffler .....		
18	1				1132- 2207- 01	Avgasrör .....	Exhaust pipe .....		
19	1				1132- 2238- 01	Ljuddämparskydd .....	Muffler heat shield .....		
21	1				9987- 5332- 16	Skruv .....	Screw .....		
22	2				1132- 2056- 01	Remstyrning .....	Belt keeper pin .....		
23	2				9683- 0030- 02	Låsbricka .....	Lock washer .....		
24	1				9683- 0045- 02	Bricka .....	Washer .....		
25	1				1132- 2142- 01	Bricka .....	Washer .....		
26	1				1132- 2200- 01	Distans .....	Spacer .....		
27	1				1132- 2213- 01	Motorremskiva .....	Engine belt pulley .....		
31	1				1132- 2098- 01	Buntband .....	Cable tie .....		
32	1				1132- 2203- 01	Bränsletank .....	Fuel tank .....		
33	1				1132- 2205- 01	Tanklock .....	Fuel tank cap .....		
41	1				1132- 2175- 01	Gasreglage .....	Throttle cable .....		



Utgåva Issue		Bildnr Picture No		SD 12,5/96 TRANSMISSION		SD 12,5/96 TRANSMISSION		Sida Page	
2005- 13		1817						20	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	1				1132-2002- 01	Fäste .....	Bracket .....		
2	2				1132-2007- 01	Monteringsplatta .....	Mounting bracket .....		
4	1				1132-2022- 01	Växelspak .....	Shift lever .....		
5	4				9988-3670- 12	Skruv .....	Screw .....		
6	2				1132-2038- 01	Skruv .....	Screw .....		
7	4				1811-2023- 01	Skruv .....	Hex bolt .....		
8	2				1811-2024- 01	Skruv .....	Screw .....		
9	2				9988-3619- 16	Skruv .....	Screw .....		
10	1				1132-2054- 01	Länk .....	Ferrule .....		
11	1				1132-2055- 01	Länk .....	Ferrule .....		
12	6				9743-3621- 32	Mutter .....	Nut .....		
13	1				9599-0036- 02	Saxsprint .....	Split pin .....		
14	2				9599-0070- 02	Saxsprint .....	Split pin .....		
15	1				1132-2111- 01	Hylsa- vä .....	Sleeve- LH .....		
16	1				1132-2112- 01	Hylsa- hö .....	Sleeve- RH .....		
17	1				1132-2121- 01	Dragfjäder .....	Extension spring .....		
18	1				1132-2124- 01	Fjäderklämma .....	Spring clip .....		
19	1				1132-2125- 01	Dragfjäder .....	Extension spring .....		
20	1				1132-2126- 01	Dragfjäder .....	Extension spring .....		
21	1				1132-2139- 01	Bricka .....	Washer .....		
22	1				1132-2183- 01	Reglagestång .....	Speed control rod .....		
23	2				1132-2198- 01	Distans .....	Spacer .....		
24	1				1132-2237- 01	Plåt .....	Plate .....		
25	1				1132-2079- 01	Reglageknopp .....	Shift knob .....		
31	2				9987-5119- 16	Skruv .....	Screw .....		
32	2				1132-2132- 01	Hjul kpl .....	Wheel assy .....		20 x 8.00 - 8
32A	1				1132-2243- 01	• Däck .....	• Tire .....		
32B	1				1132-2240- 01	• Fälg .....	• Rim .....		
32C	1				9545-0500- 00	• Ventil .....	• Vallve .....		
33	2				1811-2062- 01	Bricka .....	Bell washer .....		




Utgåva Issue  2005- 13		Bildnr Picture No  1819		SD 12,5/96 TRANSMISSION		SD 12,5/96 TRANSMISSION		Sida Page  22	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2571								
1	1			1132-2015-01	Transaxel kpl.....	Transaxle assy .....			
2	1			1132-2023-01	Remskiva .....	Belt pulley .....			
3	1			1132-2032-01	Tvärstag.....	Torque bracket .....			
4	1			1132-2033-01	Remskivsfäste .....	Speed bracket .....			
5	1			1132-2034-01	Länkarm .....	Speed bracket .....			
6	2			9988-3725-16	Skruv .....	Screw .....			
7	2			1132-2039-01	Skruv .....	Screw .....			
8	1			1132-2040-01	Skruv .....	Screw .....			
9	1			9987-5119-16	Skruv .....	Screw .....			
10	2			9988-3519-16	Skruv .....	Screw .....			
11	2			1132-0695-01	Mutter.....	Nut .....			
12	1			1132-2061-01	Flänsmutter .....	Flange nut .....			
13	3			9743-3521-32	Mutter.....	Nut .....			
14	1			1132-2064-01	Låsnål.....	Hair pin .....			
15	1			1132-2075-01	Lagerhållare.....	Bearing cup .....			
16	1			1132-2076-01	Remskivsnäv .....	Pulley hub .....			
17	1			1132-2149-01	Bricka .....	Washer.....			
19	2			1132-2158-01	Distans .....	Shoulder spacer .....			
20	2			9549-0019-00	Kullager .....	Ball bearing .....			
21	1			1132-2185-01	Växelsång .....	Shift rod .....			
22	1			1132-2195-01	Distans .....	Stepped spacer .....			
23	1			1132-2210-01	Drivrem .....	Belt.....			
24	1			1132-2211-01	Drivrem .....	Belt.....			
25	1			1132-2212-01	Remskiva.....	Transmission pulley .....			






Utgåva Issue		Bildnr Picture No		SD 12,5/96 TRANSAXEL		SD 12,5/96 TRANSAXLE		Sida Page	
2005- 13		1820						24	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
0	1				1132-2015-01	Transaxel kpl.....	Transaxle assy .....		
1	1				1132-2128-01	Ring .....	Ring .....		
2	1				1132-2068-01	Låsring .....	E- ring .....		
3	1				1132-2145-01	Planbricka.....	Flat washer .....		0.030"
3A	1				1132-2146-01	Planbricka.....	Flat washer .....		0.040"
3B	1				1132-2147-01	Planbricka.....	Flat washer .....		0.020"
4	1				1132-2144-01	Bricka .....	Thrust washer .....		
5	13				1132-2050-01	Skruv .....	Screw .....		
6	1				1132-2077-01	Hus- övre .....	Housing- upper .....		
7	1				1132-2057-01	Ingående axel .....	Input shaft.....		
8	2				1132-2166-01	Nållager .....	Needle bearing .....		
9	1				1132-2072-01	Drev .....	Bevel pinion .....	14T	
10	1				1132-2067-01	Låsring .....	Retainer ring .....		
11	2				1132-2169-01	Lagerhylsa .....	Sleeve bearing.....		
12	2				1132-2082-01	Tätning .....	Seal .....		
14	1				1132-2167-01	Flänslager .....	Flange bearing .....		
15	1				1132-2070-01	Drev .....	Bevel gear .....	42T	
16	1				1132-2071-01	Drev .....	Bevel gear .....	42T	
17	1				1132-2074-01	Kopplingshylsa .....	Clutch collar .....		
18	1				1132-2151-01	Planbricka.....	Flat washer.....		
19	1				1132-2053-01	Drivaxel .....	Drive shaft.....		
20	1				1132-2150-01	Bricka .....	Thrust washer .....		
21	1				1132-2168-01	Flänslager .....	Flange bearing.....		
22	1				1132-2013-01	Regleraxel.....	Detent shaft.....		
23	1				1132-2173-01	Kula .....	Detent ball .....		
24	1				1132-2130-01	Tryckfjäder.....	Comp spring .....		
25	1				1132-2078-01	Hus- nedre .....	Housing- lower .....		
26	1				1132-2069-01	Bromsbelägg .....	Brake puck .....		
27	1				1132-2217-01	Bromsskiva.....	Brake disc .....		
28	2				1132-2046-01	Skruv .....	Screw .....		



Utgåva Issue  2005- 13		Bildnr Picture No  1821		SD 12,5/96 AGGREGATSUPPHÄNGNING		SD 12,5/96 MOWER DECK SUSPENSION		Sida Page  26	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	1				1132-2030-01	Stödaxel.....	Stabilizer shaft .....		
2	4				1132-2042-01	Vagnsbult .....	Carriage bolt .....		
3	2				9988-3619-16	Skruv .....	Screw .....		
4	1				1132-2052-01	Länk.....	Ferrule.....		
5	1				1132-2054-01	Länk.....	Ferrule.....		
6	2				1132-2058-01	Bult.....	Bolt .....		
7	2				9743-3721-32	Mutter.....	Nut .....		
8	4				9743-3521-32	Mutter.....	Nut .....		
9	2				9743-3621-32	Mutter.....	Nut .....		
10	2				1132-2063-01	Låsnål.....	Hair pin .....		
11	8				1132-2065-01	Låsnål.....	Hair pin .....		
12	2				1132-2066-01	Låsring .....	Lock ring .....		
13	1				1132-2123-01	Dragfjäder.....	Extension spring .....		
14	2				1132-2136-01	Bricka .....	Bell washer .....		
15	1				1132-2137-01	Bricka .....	Washer.....		
16	2				1132-2152-01	Bricka .....	Washer.....		
17	2				1132-2157-01	Ansatsbult .....	Shoulder bolt .....		
18	2				1132-2171-01	Flänslager .....	Flange bushing.....		
19	5				1132-2179-01	Upphångningslänk.....	Deck hanger link .....		
20	1				1132-2182-01	Aggr.urkopplingsstång .....	Deck disengagem. rod .....		
21	1				1132-2184-01	Upphångningslänk.....	Deck hanger link .....		
22	2				1132-2191-01	Distans .....	Spacer .....		
23	2				1132-2216-01	Knivbroms .....	Blade brake .....		
24	1				1132-2230-01	Höjdinställn.segment.....	Lift index bracket .....		
25	1				1132-2235-01	Stödaxelfäste .....	Deck stabilizer brkt.....		
26	4				1132-2236-01	Lyftlänk.....	Lift link.....		



Utgåva Issue  2005- 13		Bildnr Picture No  1822		SD 12,5/96 KLIPPAGGREGAT		SD 12,5/96 MOWER DECK		Sida Page  28	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2571								
1	2				1132-2014-01	Lagerbox kpl.....	Blade spindle assy .....		Inkl. pos 32 - 38  