












# **Genuine Spare Parts**

---








Utgåva Issue		Bildnr Picture No		VILLA MONTERINGDETALJER		VILLA ASSEMBLY PARTS		Sida Page	
2005- 11		1148C						232	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723								
0	1				1134-4664-05	Monteringsdetaljer.....	Assembly parts .....		
1	1				9595-0262-00	• Spännstift .....	• Locating pin .....		
2A	1				9699-0103-02	• Shims .....	• Flat washer .....		0.5 mm
2B	1				9699-0114-02	• Shims .....	• Flat washer .....		1.0 mm
3	2				1134-4185-01	• Ansatsbricka .....	• Flange washer .....		
4	2				9959-0820-16	• Skruv .....	• Screw .....		
5	4				9699-0056-02	• Planbricka .....	• Flat washer .....		
6	2				1134-2609-01	• Ratt .....	• Knob .....		
7	1				1134-4627-01	• Dragögla .....	• Tow bar .....		
8	2				9959-0820-16	• Skruv .....	• Screw .....		
10	1				1134-4734-01	• Tändningsnyckel.....	• Ignition key .....		
11	2				9837-8914-12	• Skruv .....	• Screw .....		
12	1				1111-2113-01	• Vridpinne .....	• Rod .....		
13A	1				1134-2960-02	• Tändstiftshylsa- lång.....	• Spark plug wrench .....		5/8" (16 mm)
13B	1				1134-4541-01	• Tändstiftshylsa .....	• Spark plug wrench .....		5/8" (16 mm)/21 mm
14	1				1134-5245-01	• Batterirem .....	• Battery strap.....		
20	1				1134-3771-66	Mapp m.trycksaker .....	Folder w.manuals .....		
21	1				8211-0209-11	• Säkerhetsföreskrifter .....	• Safety regulations .....		
21	1				8211-0288-05	• Bruksanvisning .....	• Owner's manual .....		
21	1				8211-0289-03	• Servicebok .....	• Service book .....		
21	1				8211-0290-05	• Monteringsanvisning .....	• Assy instructions .....		
21	1				8211-2002-03	• Garantikort.....	• Warranty card .....		





Utgåva Issue		Bildnr Picture No		VILLA KAROSS		VILLA BODY WORK		Sida Page	
2005- 11		1150D						234	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
1	1	1			1134-5067-01	Huv- framdel .....	Hood- front.....		Royal Comfort De Luxe
2	2	2			9893-0616-16	Skruv .....	Screw .....		
3	2	2			1134-4444-01	Stag .....	Stay .....		
4	4	4			9959-0820-16	Skruv .....	Screw .....		
5	4	4			9739-0831-22	Mutter .....	Nut .....		
6	1	1			1134-4787-01	Huv- bakdel.....	Hood- rear .....		
7	2	2			1134-5381-01	Huvinfästning .....	Hood attachment.....		
8	4	4			9893-0616-16	Skruv .....	Screw .....		
9	2	2			1134-4904-01	Huvlås kpl.....	Hood lock kit .....		
12	1	1			1134-4789-01	Motorlucka- grå .....	Engine cover- grey .....		
13	1				1134-3944-03	Stötfångare .....	Bumper .....		
13		1			1134-4220-03	Stötfångare (m. hål) .....	Bumper (w. hole) .....		
14	4	4			1134-4176-01	Clips .....	Clips .....		
15	6	6			9893-0616-16	Skruv .....	Screw .....		
16	1	1			1134-4592-01	Frontkonsol .....	Front plate .....		
17	2	2			9946-0525-16	Skruv .....	Screw .....		
21	2	2			1134-4790-02	Styrning.....	Hood guide .....		
22	2	2			9838-9530-12	Skruv .....	Screw .....		
23	2	2			1134-5078-01	Stag .....	Stay .....		
24	2	2			9893-0616-16	Skruv .....	Screw .....		
99		1			1134-5244-05	Dekalsats .....	Label kit .....		
99	1				1134-5244-06	Dekalsats .....	Label kit .....		
99	1				1134-5244-07	Dekalsats .....	Label kit .....		





Utgåva Issue  2005- 11		Bildnr Picture No  1149C		VILLA RAM		VILLA FRAME		Sida Page  236	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 2724								
1	1				1134-5546-01	Ram.....	Frame.....		
2	1				1134-5293-01	Durk.....	Floor plate.....		
3	2				9893-0616-16	Skruv.....	Screw.....		
4	1				1134-5339-01	Durkmatta.....	Floor mat.....		
5	1				1134-5382-01	Stötfångare.....	Bumper.....		
6	2				9959-0820-16	Skruv.....	Screw.....		
7	2				9959-0825-16	Skruv.....	Screw.....		
8	3				9739-0831-22	Mutter.....	Nut.....		
9	1				9739-0831-22	Mutter.....	Nut.....		




Utgåva Issue  2005- 11		Bildnr Picture No  1151C		VILLA REDSKAPSLYFT		VILLA LIFTING DEVICE		Sida Page  238	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
1	1	1			1134-4117-01	Fäste .....	Bracket .....		L = 40 mm L = 70 mm
2	2				9997-1040-16	Skruv .....	Screw .....		
2		2			9997-1070-12	Skruv .....	Screw .....		
3	2	2			9739-1031-22	Mutter .....	Nut .....		
4	2	2			1134-2684-01	Lager .....	Bearing .....		
5	1	1			1134-4945-01	Lyftspärr kpl .....	Lift catch assy .....		
9	1	1			9404-0027-01	• O-ring.....	• O-ring .....		
10	1	1			9650-0039-04	• Seegersäkring .....	• Lock ring .....		
11	1	1			9595-0276-01	• Spännstift .....	• Locating pin .....		
12	1	1			9997-0640-12	• Skruv .....	• Screw .....		
13	1	1			9747-0631-02	• Låsmutter .....	• Lock nut.....		
15	1	1			9897-0820-16	• Skruv .....	• Screw .....		
16	1	1			9747-0831-02	Mutter.....	Lock nut .....		
17	1	1			1134-4860-01	Lyftgaffel.....	Lift fork .....		
18	2	2			1134-0240-00	Ansattsskruv .....	Shoulder screw .....		
19	1	1			1134-4938-01	Lyftpedal.....	Lift pedal .....		
20	2	2			9997-0625-16	Skruv .....	Screw .....		
21	2	2			9739-0631-22	Mutter.....	Nut .....		
22	1	1			4231-0013-00	Fjäder.....	Spring .....		




Utgåva Issue		Bildnr Picture No		VILLA SITS		VILLA SEAT		Sida Page	
2005- 11		1159F						240	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 - 35	2723 - 75 2724							
2	1	1			1134-4223-01	Sits .....	Seat .....		Ø = 8 mm
3	1	1			1134-4628-05	Överdel .....	Seat plate .....		
4	2	2			1134-0240-00	Ansattsskruv .....	Shoulder screw .....		
5	2	2			9747-0831-02	Mutter .....	Lock nut .....		
6	1	1			1134-5179-01	Spärr .....	Catch .....		
7	1	1			9675-0012-02	Starlock .....	Locking washer .....		
12	1	1			1134-4211-08	Sitskonsol .....	Seat bracket .....		
13	1	1			1134-4256-01	Sitsfjäder .....	Seat spring .....		
14	1	1			9924-1235-19	Skruv .....	Screw .....		
15	1	1			9747-1231-02	Låsmutter .....	Lock nut .....		
18	1	1			1134-5032-01	Distans .....	Spacer .....		
19	1				1134-4950-02	Sitsbrytarplåt .....	Seat switch bracket .....		
20	1				1134-3399-01	Brytare .....	Switch .....		
21	2				9852-8013-16	Skruv .....	Screw .....		
22	2				9893-0616-16	Skruv .....	Screw .....		
28	3	3			9959-0820-16	Skruv .....	Screw .....	L = 20 mm	
29	1	1			9959-0825-16	Skruv .....	Screw .....	L = 25 mm	
31	6	6			9739-0831-22	Mutter .....	Nut .....		
32	2	2			9897-0820-16	Skruv .....	Screw .....		




Utgåva Issue 2005- 11		Bildnr Picture No 1152D		VILLA COMFORT- DE LUXE STYRNING		VILLA COMFORT- DE LUXE STEERING		Sida Page 242	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723								
1	3				1134-0041-01	Linhjulshylsa .....	Bushing .....	Sats 2 st/kit of 2 L = 40 mm	Sats 2 st/kit of 2 L = 60 mm
2	3				1134-3022-01	Linhållare .....	Cable holder .....		
3	1				1134-9025-01	Linhjul- sats .....	Steering pulley- kit .....		
4	3				9997-1040-16	Skruv .....	Screw .....		
5	2				9739-1031-22	Mutter .....	Nut .....		
6	1				1134-9083-01	Styrwire .....	Steering cable .....		
7	1				1134-1310-01	Tryckfjäder .....	Compression spring .....		
8	1				9699-0056-02	Planbricka .....	Flat washer .....		
9	1				9747-0831-02	Mutter .....	Lock nut .....		
10	1				9959-0820-16	Skruv .....	Screw .....		
11	1				1134-4120-04	Styrkonsol .....	Steering console .....		
12	4				9897-0820-16	Skruv .....	Screw .....		
13	4				9739-0831-22	Mutter .....	Nut .....		
14	1				1134-4483-01	Bussning .....	Bushing .....		
15	1				1134-1305-03	Rattrör- nedre .....	Steering column- lower .....		
16	2				1134-1901-01	Lager .....	Bearing .....		
17	2				9893-0616-16	Skruv .....	Screw .....		
18	2				9699-0060-02	Planbricka .....	Flat washer .....		
19	1				1134-4431-01	Rattstång .....	Steering rod .....		
20	1				1134-1933-01	Styrrulle .....	Steering pulley .....		
21	1				9595-0262-00	Spännstift .....	Locating pin .....		
23	1				1134-5173-02	Ratt kpl .....	Steering wheel assy .....		
24	1				1134-3769-01	• Styrknopp kpl .....	• Steering wheel button .....		
25	1				1134-3752-01	• Knoppfäste .....	• Knob holder .....		
26	1				9997-0865-12	• Skruv .....	• Screw .....		
27	1				1134-1565-06	• Distans .....	• Spacer .....		
28	3				9699-0090-02	• Planbricka .....	• Flat washer .....		
29	1				9747-0831-02	• Mutter .....	• Lock nut .....		
30	1				9403-0043-70	• Plugg .....	• Plug .....		
31	1				9403-0113-00	• Mutterhatt .....	• Nut cap .....		
32	1				1134-3047-01	Distans .....	Spacer .....		
33	2				9699-0104-02	Bricka .....	Washer .....		
36	2				1134-3047-01	Distans .....	Spacer .....		
37	1				1134-0041-05	Hylsa .....	Bushing .....		
38	1				1134-3022-01	Linhållare .....	Cable holder .....		
39	1				1134-9025-01	Linhjul- sats .....	Steering pulley- kit .....		
40	1				9997-1060-12	Skruv .....	Screw .....		
41	1				1134-5216-01	Rattrör- inre kpl .....	Steering tube- inner .....		
42	1				1134-5177-01	• Slid .....	• Slide .....		
43	1				9710-0631-12	• Fyrkantmutter .....	• Square nut .....		
44	1				1134-4481-02	Vingmutter .....	Wing nut .....		
45	1				9997-0630-12	Skruv .....	Screw .....		




34




Utgåva Issue		Bildnr Picture No		VILLA ROYAL STYRNING		VILLA ROYAL STEERING		Sida Page
2005- 11		1513B						244
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2724							
1	4			1134-0041-01	Linhjulshylsa .....	Bushing .....		Sats 2 st/kit of 2
2	2			1134-3022-01	Linhållare .....	Cable holder .....		
3	1			1134-9025-01	Linhjul- sats .....	Steering pulley- kit .....		L = 40 mm
4	2			1134-3547-01	Kedjehjul .....	Sprocket .....		
5	4			9997-1040-16	Skruv .....	Screw .....		75 länk Sats vä+hö/kit L+R
6	2			9739-1031-22	Mutter .....	Nut .....		
7	2			9699-0035-02	Planbricka .....	Flat washer .....		
8	2			1134-0041-07	Hylsa .....	Bushing .....		
9	2			1134-2816-01	Kedjehjul .....	Sprocket .....		
10	2			9699-0035-02	Planbricka .....	Flat washer .....		
11	2			9739-1031-22	Mutter .....	Nut .....		
12	1			1134-2820-08	Kedja .....	Chain .....		
13	1			1134-9085-01	Styrwire kpl (vä+hö) .....	Steering cable assy .....		
15	2			1134-2824-01	Kedjelås .....	Chain lock .....		
16	1			1134-1310-01	Tryckfjäder .....	Compression spring .....		
17	1			9699-0056-02	Planbricka .....	Flat washer .....		
18	1			9747-0831-02	Mutter .....	Lock nut .....		
19	1			9959-0820-16	Skruv .....	Screw .....		
20	1			1134-4120-04	Styrkonsol .....	Steering console .....		
21	4			9897-0820-16	Skruv .....	Screw .....		
22	4			9739-0831-22	Mutter .....	Nut .....		
23	1			1134-4483-01	Bussning .....	Bushing .....		
24	1			1134-1305-03	Rattrör- nedre .....	Steering column- lower .....		
25	2			1134-1901-01	Lager .....	Bearing .....		
26	2			9893-0616-16	Skruv .....	Screw .....		
27	2			9699-0060-02	Planbricka .....	Flat washer .....		
28	1			1134-2821-02	Rattstång .....	Steering rod .....		
29	2			1134-3047-01	Distans .....	Spacer .....		
30	1			9699-0104-02	Bricka .....	Washer .....		
31	1			1134-2837-02	Distans .....	Spacer .....		
33	1			1134-5173-02	Ratt kpl .....	Steering wheel assy .....		
34	1			1134-3769-01	• Styrknopp kpl .....	• Steering wheel button .....		
35	1			1134-3752-01	• Knoppfäste .....	• Knob holder .....		
36	1			9997-0865-12	• Skruv .....	• Screw .....		
37	1			1134-1565-06	• Distans .....	• Spacer .....		
38	3			9699-0090-02	• Planbricka .....	• Flat washer .....		
39	1			9747-0831-02	• Mutter .....	• Lock nut .....		
40	1			9403-0043-70	• Plugg .....	• Plug .....		
41	1			9403-0113-00	• Mutterhatt .....	• Nut cap .....		
51	1			1134-5216-01	Rattrör- inre kpl .....	Steering tube- inner .....		
52	1			1134-5177-01	• Slid .....	• Slide .....		
53	1			9710-0631-12	• Fyrkantmutter .....	• Square nut .....		
54	1			1134-4481-02	Vingmutter .....	Wing nut .....		
55	1			9997-0630-12	Skruv .....	Screw .....		



Utgåva Issue		Bildnr Picture No		VILLA COMFORT HANDREGLAGE		VILLA COMFORT HAND CONTROLS		Sida Page	
2005- 11		1511A						246	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 -35								
1	1				1134-5077-01	Konsol .....	Panel bracket .....		
2	2				9959-0820-16	Skruv .....	Screw .....		
3	2				9739-0831-22	Mutter.....	Nut .....		
4	2				9893-0616-16	Skruv .....	Screw .....		
5	1				1134-4487-02	Frontfäste .....	Panel bracket .....		
6	1				1134-3986-01	Frontplåt .....	Front plate .....		
7	4				9893-0616-16	Skruv .....	Screw .....		
10	1				1134-4065-01	Reglageaxel .....	Control shaft .....		
11	1				1134-4080-03	Reglagehylsa .....	Control sleeve .....		
12	1				1134-4079-01	Fjäder.....	Spring .....		
13	2				9959-0820-16	Skruv .....	Screw .....		
21	1				1134-4590-01	Gasreglage.....	Throttle control .....		
22	1				1134-4078-01	Knopp.....	Knob .....		
23	1				1134-0240-00	Ansattsskruv .....	Shoulder screw .....		
24	1				9694-0001-00	Fjäderbricka .....	Washer .....		
25	2				1134-4242-01	Distansbricka .....	Spacer washer .....		
26	1				9747-0831-02	Mutter.....	Lock nut .....		
27	1				1134-1597-11	Gaswire .....	Throttle cable .....		
28	1				9500-9991-00	Wireklämma .....	Cable clamp .....		
29	1				9943-0516-16	Skruv .....	Screw .....		
30	1				1134-4093-01	Tändningslås .....	Ignition switch .....		
31	1				1134-4749-01	Mutter.....	Nut .....		
33	1				1134-4734-01	Tändningsnyckel.....	Ignition key .....		
34	1				1134-4472-01	Fästplatta .....	Attachment plate .....		
35	2				9943-0516-16	Skruv .....	Screw .....		
36	1				1134-4470-02	Reglagepanel .....	Dashboard .....		
37	4				9943-0516-16	Skruv .....	Screw .....		
38	3				1134-4129-01	Täckbricka .....	Cover .....		
39	1				1134-4100-01	Täckpropp .....	Plug .....		
43	1				1134-4950-02	Sitsbrytarplåt .....	Seat switch bracket .....		
44	2				9893-0616-16	Skruv .....	Screw .....		
45	1				9695-0011-00	Bricka .....	Washer .....		
46	1				1134-5061-01	Aggregatsspak.....	Control lever .....		
47	1				1134-2551-01	Reglageknopp.....	Knob .....		
48	1				1134-5358-01	Brytarfäste .....	Switch bracket .....		
49	2				9852-8013-16	Skruv .....	Screw .....		
50	1				9400-0285-01	Microbrytare.....	Switch .....		
51	2				9840-7716-16	Skruv .....	Screw .....		
52	1				1134-3573-04	Krafttuttagswire .....	PTO cable.....		
53	1				1134-1242-02	Fjäder.....	Spring .....		
60	1				9959-0820-16	Skruv .....	Screw .....		
61	1				9739-0831-22	Mutter.....	Nut .....		
62	1				9699-0056-02	Planbricka.....	Flat washer .....		




Utgåva Issue 2005- 11		Bildnr Picture No 1164E		VILLA DE LUXE- ROYAL HANDREGLAGE		VILLA DE LUXE- ROYAL HAND CONTROLS		Sida Page 248	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 - 75	2724							
1	1	1			1134-5077-01	Konsol .....	Panel bracket .....		Tillbehör/Accessory
2	2	2			9959-0820-16	Skruv .....	Screw .....		
3	2	2			9739-0831-22	Mutter.....	Nut .....		
4	2	2			9893-0616-16	Skruv .....	Screw .....		
5	1	1			1134-4487-02	Frontfäste .....	Panel bracket .....		
6	1	1			1134-3986-01	Frontplåt .....	Front plate .....		
7	4	4			9893-0616-16	Skruv .....	Screw .....		
21	1	1			1134-4590-01	Gasreglage.....	Throttle control .....		
22	1	1			1134-4078-01	Knopp .....	Knob .....		
23	1	1			1134-0240-00	Ansattsskruv .....	Shoulder screw .....		
24	1	1			9694-0001-00	Fjäderbricka .....	Washer .....		
25	2	2			1134-4242-01	Distansbricka .....	Spacer washer .....		
26	1	1			9747-0831-02	Mutter.....	Lock nut .....		
27	1				1134-1597-11	Gaswire .....	Throttle cable .....		
27		1			1134-1597-12	Gaswire .....	Throttle cable .....		
28	1	1			9500-9991-00	Wireklämma .....	Cable clamp .....		
29	1	1			9943-0516-16	Skruv .....	Screw .....		
30	1	1			1134-4093-01	Tändningslås .....	Ignition switch .....		
31	1	1			1134-4749-01	Mutter.....	Nut .....		
33	1	1			1134-4734-01	Tändningsnyckel.....	Ignition key .....		
34	1	1			1134-4472-01	Fästplatta .....	Attachment plate .....		
35	2	2			9943-0516-16	Skruv .....	Screw .....		
36	1	1			1134-4470-03	Reglagepanel .....	Dashboard .....		
37	4	4			9943-0516-16	Skruv .....	Screw .....		
38	2	1			1134-4129-01	Täckbricka .....	Cover .....		
39	1	2			9400-0282-01	Brytare m.diod.....	Switch w.diode.....		
40	1	1			9400-0280-01	Vippa- kraftuttag .....	Cover- PTO .....		
41		1			9400-0280-03	Vippa- höjdinställning .....	Cover- height adjust .....		
44	1				1134-4100-01	Täckpropp .....	Plug .....		
45		1			1134-2872-04	Chokereglage.....	Choke control .....		
45A		1			1134-4338-01	• Reglageknopp .....	• Control knob .....		
46		1			9699-0028-02	Planbricka.....	Flat washer .....		
60	1	1			9959-0820-16	Skruv .....	Screw .....		
61	1	1			9739-0831-22	Mutter.....	Nut .....		
62	1	1			9699-0056-02	Planbricka.....	Flat washer .....		
99	1	1			9400-0290-01	Verktyg f.vippa.....	Tool for cover .....		




Utgåva Issue		Bildnr Picture No		VILLA FOTREGLAGE		VILLA FOOT CONTROLS		Sida Page	
2005- 11		1161C						250	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 2724								
1	1				1134-4802-01	Pedal .....	Pedal .....		
2	2				1134-4624-01	Lager .....	Bearing .....		
3	4				9898-0635-12	Skruv .....	Screw .....		
4	4				9739-0631-22	Mutter .....	Nut .....		
5	1				1134-4949-01	Kopplingsstång .....	Clutch rod .....		
6	1				1134-2138-01	Skruvögla .....	Eye bolt .....		
7	2				9739-1031-22	Mutter .....	Nut .....		
9	1				9739-0831-22	Mutter .....	Nut .....		
10	1				9747-0831-02	Mutter .....	Lock nut .....		
11	1				9595-0208-00	Spännstift .....	Locating pin .....		
12	2				9699-0035-02	Planbricka .....	Flat washer .....		
13	1				1134-4617-01	Fjäder .....	Spring .....		
14	1				1134-2138-01	Skruvögla .....	Eye bolt .....		
15	1				9739-0831-22	Mutter .....	Nut .....		
16	1				9747-0831-02	Mutter .....	Lock nut .....		
18	1				9598-0002-02	Låsnål .....	Pin lock .....		
20	1				1134-5101-01	Bromsstång .....	Brake rod .....		
21	1				1134-3808-01	Knopp .....	Knob .....		
22	1				1131-1497-01	Fjäder .....	Spring .....		
23	1				1134-4002-01	Fäste .....	Brake rod attachment .....		
24	3				9838-9516-12	Skruv .....	Screw .....		
25	1				1134-4008-03	Drivpedal .....	Drive pedal .....		
26	2				1134-2780-01	Lager .....	Bearing .....		
27	2				1134-2700-01	Fäste .....	Bracket .....		
28	2				9959-0820-16	Skruv .....	Screw .....		
29	2				9739-0831-22	Mutter .....	Nut .....		
30	1				9997-0870-16	Skruv .....	Screw .....		
31	2				9739-0831-22	Mutter .....	Nut .....		
34	1				1134-4440-01	Axel .....	Shaft .....		
35	1				1134-4793-01	Stopplåt .....	Stop plate .....		
36	1				1134-4441-01	Stag .....	Link .....		
37	2				1134-0240-00	Ansattsskruv .....	Shoulder screw .....		
38	2				9694-0001-00	Fjäderbricka .....	Washer .....		
39	2				9747-0831-02	Mutter .....	Lock nut .....		
40	1				1134-5288-01	Reglagestång .....	Control rod .....		
41	2				9675-0012-02	Starlock .....	Locking washer .....		
51	1				4231-0013-00	Fjäder .....	Spring .....		
52	1				1134-4779-01	Plastbussning .....	Plastic bushing .....		
53	1				1134-4972-01	Bromslänk .....	Brake link .....		
54	1				9747-0831-02	Mutter .....	Lock nut .....		
55	1				9959-0820-16	Skruv .....	Screw .....		


X





Utgåva Issue		Bildnr Picture No		VILLA ELUTRUSTNING		VILLA EL. EQUIPMENT		Sida Page	
2005- 11		1162E						252	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 -35	2723 -75	2724						
1	1	1	1		1134-4804-01	Batteri.....	Battery .....		
3		1	1		1134-4194-02	Sitsbrytare .....	Seat switch .....		
4	1	1	1		1134-4610-01	Fäste .....	Switch bracket .....		
5	1	1	1		1134-3399-02	Brytare.....	Switch .....		
6	2	2	2		9852-8013-16	Skruv .....	Screw .....		
7	3	3	3		9579-0003-00	Buntband .....	Cable holder .....		
8A	1	1			1134-2042-02	Kabel- svart.....	Cable- black.....		L =350 mm
8B			1		1134-4701-02	Kabel- svart.....	Cable- black.....		L = 180 mm
9	1	1	2		9838-9516-12	Skruv .....	Screw .....		
10	1	1			9747-0831-02	Mutter.....	Lock nut.....		
11A	1	1			9795-3531-02	Mutter.....	Nut .....		1/4 UNC
11B			1		9747-0831-02	Mutter.....	Lock nut.....		M8
12	3	3	3		9579-0003-00	Buntband .....	Cable holder .....		
13			1		9400-0223-00	Ringkabelsko .....	Cable fitting .....		
22	1	1	1		9699-0060-02	Planbricka.....	Flat washer .....		
24		1	1		1134-4970-02	Kabel- röd .....	Cable- red .....		L = 310 mm
25		1	1		1134-2871-03	Relä .....	Relay .....		
26	1	1	1		1134-2962-01	Solenoid kpl .....	Solenoid assy.....		
27	2	2	2		9794-5131-02	• Mutter.....	• Nut .....		
28	1	1	1		1134-4702-01	Kabel- röd .....	Cable- red .....		L = 380 mm
29	1	1	1		1134-2310-01	Batteriskydd.....	Guard cap .....		
30A	1	1			1134-4702-02	Kabel- röd .....	Cable- red .....		L = 480 (6 mm - 8 mm)
30B			1		1134-4703-02	Kabel- röd .....	Cable- red .....		L = 510 (8 mm - 8 mm)
31			1		1134-4704-02	Kabel- vit.....	Cable- white .....		L = 510 mm
32			1		1134-4836-01	Kablage.....	Harness.....		
32		1			1134-5160-01	Kablage.....	Harness.....		
32	1				1134-5318-01	Kablage.....	Harness.....		
35			1		1134-4056-01	Honkontakt .....	Female terminal.....		
36			1		1134-4052-01	Stödbricka .....	Support washer.....		
37			2		9840-7716-16	Skruv .....	Screw .....		
38		1	1		1134-3491-01	Säkringshållare .....	Fuse holder .....		
39		1	1		1134-3631-01	Lock- säkringsdosa.....	Cover- fuse holder.....		
40		2	2		9838-9516-12	Skruv .....	Screw .....		
41		1	1		1134-3496-01	Säkring .....	Fuse .....		10A
41		1	1		1134-3496-06	Säkring .....	Fuse .....		20A




Utgåva Issue 2005- 11		Bildnr Picture No 1625A		VILLA COMFORT- DE LUXE MOTOR		VILLA COMFORT- DE LUXE ENGINE		Sida Page 254	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723								
1	4				9997-0840-16	Skruv .....	Screw .....		H = 39.5 mm
2	4				9747-0831-02	Mutter.....	Lock nut.....		
3A	1				1134-4468-01	Distans .....	Spacer.....		
4	1				1134-4222-02	Tätningsring .....	Seal ring.....		
5	1				1134-5066-01	Bränsletank.....	Fuel tank .....		
6	1				1134-5532-01	Tanklock .....	Fuel tank cap .....		
7	1				1134-3224-01	Bensinkran.....	Fuel shut- off valve .....		
8	1				1134-3225-01	Gummibussning .....	Grommet.....		
9	1				1134-2975-05	Bensinslang .....	Fuel hose.....		
10	2				9578-0023-02	Slangklämma.....	Hose clamp .....		L = 460 mm
12	1				1134-4808-01	Tankbygel .....	Tank clamp .....		
13	1				9699-0060-02	Planbricka.....	Flat washer.....		
14	1				9747-0631-02	Låsmutter .....	Lock nut.....		
15	1				1134-4807-02	Tank/batterihylla .....	Tank/battery shelf.....		
16	4				9829-8830-12	Skruv .....	Screw .....		
18	1				1134-5379-01	Grenrör.....	Exhaust pipe .....		
19	1				1134-0433-00	Ljuddämparpackning .....	Muffler gasket .....		
22	2				1134-4930-01	Skruv .....	Screw .....		
23	1				1134-5378-01	Ljuddämpare .....	Muffler .....		
24	1				9578-0011-00	Ljuddämparklämma.....	Clamp.....		
25	1				9959-0820-16	Skruv .....	Screw .....		
26	1				1134-5163-01	Beröringsskydd .....	Muffler guard .....		
27	4				9893-0616-16	Skruv .....	Screw .....		







Utgåva Issue 2005- 11		Bildnr Picture No 1154D		VILLA ROYAL MOTOR		VILLA ROYAL ENGINE		Sida Page 256	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2724								
1	1				1134-4978-01	Oljeavtapn.rör kpl .....	Oil drain pipe assy.....		L = 40 mm L = 50 mm
2	1				1134-4977-01	• Kopparbricka .....	• Copper washer .....		
3	1				1134-4976-01	• Plugg .....	• Plug.....		
5	3				9997-0840-16	Skruv .....	Screw .....		L = 460 mm
5	1				9997-0850-16	Skruv .....	Screw .....		
6	4				9747-0831-02	Mutter.....	Lock nut.....		
8	1				1134-4557-02	Tätningsring .....	Seal ring.....		Inkl. pos 30
9	1				1134-5066-01	Bränsletank.....	Fuel tank .....		
10	1				1134-5532-01	Tanklock .....	Fuel tank cap .....		
11	1				1134-3224-01	Bensinkran.....	Fuel shut-off valve .....		
12	1				1134-3225-01	Gummibussning .....	Grommet.....		
13	1				1134-2975-05	Bensinslang .....	Fuel hose .....		
14	2				9579-0003-00	Buntband .....	Cable holder .....		
15	2				9578-0023-02	Slangklämma.....	Hose clamp .....		
16	1				1134-4808-01	Tankbygel .....	Tank clamp.....		
17	1				9699-0060-02	Planbricka.....	Flat washer .....		
18	1				9747-0631-02	Låsmutter .....	Lock nut .....		
19	1				1134-4807-02	Tank/batterihylla .....	Tank/battery shelf.....		
20	4				9829-8830-12	Skruv .....	Screw .....		
22	1				1134-4638-01	Grenrör.....	Exhaust manifold .....		
23	1				1134-4953-02	Ljuddämpare kpl.....	Muffler assy .....		
24	1				9578-0011-00	Ljuddämparklämma.....	Clamp.....		
25	1				9959-0820-16	Skruv .....	Screw .....		
26	1				1134-5163-01	Beröringsskydd .....	Muffler guard .....		
27	4				9893-0616-16	Skruv .....	Screw .....		
30	1				1134-4955-01	• Ljuddämparinsats .....	• Muffler insert .....		





Utgåva Issue		Bildnr Picture No		VILLA TRANSMISSION		VILLA TRANSMISSION		Sida Page	
2005- 11		1157D						258	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 2724								
1	1				1134-4611-01	Motorremskiva .....	Engine belt pulley .....		= 9585-0099- 01   <



Utgåva Issue		Bildnr Picture No		VILLA HJUL		VILLA WHEELS		Sida Page	
2005- 11		1155D						260	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	Old 2723 2724	New 2723 2724							
1		1			1134-5893-01	Bakaxel .....	Rear axle .....		
1 A	1				1134-5012-01	Bakaxel .....	Rear axle .....		
2	2	2			9501-0500-00	Smörjnippel .....	Grease joint .....		
3	1	1			1134-5009-02	Spindel- vä .....	Spindle- L.H .....		
4	1	1			1134-5009-01	Spindel- hö .....	Spindle- R.H .....		
5	2	2			9699-0088-02	Planbricka .....	Flat washer .....		
6	2	2			9650-0020-04	Spårring .....	Circlip .....		
7		1			1134-5316-01	Styrskiva .....	Steering pulley .....		
7 A	1				1134-1500-03	Styrskiva .....	Steering pulley .....		
8		1			1134-5575-01	Distans .....	Spacer .....		L = 52,8 mm
8 A	1				1134-5575-02	Distans .....	Spacer .....		L = 72,8 mm
9	1	1			1134-9024-01	Lager .....	Bearing .....		Sats 4 st/kit of 4
10	1	1			9699-0104-02	Bricka .....	Washer .....		
11		1			9997-1680-12	Skruv .....	Screw .....		L = 80 mm
11 A	1				9997-1690-12	Skruv .....	Screw .....		L = 90 mm
12	2	2			1134-3247-05	Styrstag .....	Tie rod .....		
13 A	2	2			9997-0825-16	Skruv .....	Screw .....		L = 25 mm
13 B	1	1			9997-0835-12	Skruv .....	Screw .....		L = 35 mm
14	2	2			9699-0028-02	Planbricka .....	Flat washer .....		
15	3	3			9747-0831-02	Mutter .....	Lock nut .....		
16	2	2			1134-4706-01	Fälg .....	Rim .....		
17	1	1			1134-9026-01	Lagerbussning .....	Bearing bush kit .....		Sats 4 st/kit of 4
18	2	2			9545-0125-01	Däck .....	Tyre .....		14 x 5.50 - 6
19	2	2			9545-0500-00	Ventil .....	Valve .....		
20	2	2			1134-0341-01	Bricka .....	Washer .....		
21	2	2			9650-0020-04	Spårring .....	Circlip .....		
22	2	2			1134-4344-01	Navkapsel .....	Hub cap .....		
25	1	1			9501-0500-00	Smörjnippel .....	Grease joint .....		
26	1	1			9699-0088-02	Planbricka .....	Flat washer .....		
27	1	1			9650-0020-04	Spårring .....	Circlip .....		
28	2	2			1134-4558-01	Fälg .....	Rim .....		
29	2	2			9545-0116-00	Däck .....	Tyre .....		16 x 7.50 - 8
30	2	2			9545-0500-00	Ventil .....	Valve .....		
31	6	6			9699-0035-02	Planbricka .....	Flat washer .....		
32	6	6			9747-1031-02	Låsmutter .....	Lock nut .....		
33	2	2			1134-2471-03	Kil .....	Key .....		
34	2	2			9653-0001-04	Spårryttare .....	Lock ring .....		
35	4	4			1134-0341-01	Bricka .....	Washer .....		
36	2	2			1134-4844-02	Hjulnav .....	Wheel hub .....		
37	2	2			1134-4845-01	Navhylsa .....	Hub sleeve .....		
38	2	2			1134-4981-01	Bricka .....	Washer .....		
98					9545-0204-00	Innerslang .....	Inner tube .....		Reservdel/spare part
99					9545-0203-00	Innerslang .....	Inner tube .....		Reservdel/spare part



Utgåva Issue 2005- 11		Bildnr Picture No 1512B		VILLA COMFORT KRAFTUTTAG		VILLA COMFORT POWER TAKE- OFF		Sida Page 262	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 - 35								
1	1				1134-5046-01	Motorremskiva .....	Engine belt pulley .....		L = 2 1/2"
2	1				1134-5017-01	Bricka .....	Washer .....		
3	1				9987-5332-16	Skruv .....	Screw .....		
4	1				1134-5058-01	Remstyrning .....	Belt guide .....		
5	1				1134-5057-01	Remstyrning .....	Belt guide .....		
6	1				9600-0251-01	Kil .....	Key .....		
8	1				1134-4650-01	Monteringsbygel .....	Pulley bracket .....		
9	2				9945-0816-16	Skruv .....	Screw .....		
10	1				1134-4643-01	Mellanremskiva kpl .....	Intermediate pulley .....		
11	1				1134-0051-12	• Distans .....	• Spacer .....		
12	2				9549-0019-00	• Kullager .....	• Ball bearing .....		
14	2				1134-0052-00	Lagerdistans .....	Bearing spacer .....		
15	1				9997-1040-16	Skruv .....	Screw .....		
16	1				9699-0035-02	Planbricka .....	Flat washer .....		
17	1				1134-9079-01	Drivrem .....	Drive belt .....		
18	1				1134-5231-01	Spännarm .....	Tension arm .....		
19	1				1134-9027-01	Spännrulle .....	Tension roller .....		
20	1				1134-4619-01	Distans .....	Spacer .....		
21	1				9997-1060-12	Skruv .....	Screw .....		
22	1				9739-1031-22	Mutter .....	Nut .....		
23	1				1134-5232-01	Spännarmsfäste .....	Attachment .....		
24	1				9997-0640-12	Skruv .....	Screw .....		
25	1				9747-0631-02	Låsmutter .....	Lock nut .....		
26	1				1134-4619-01	Distans .....	Spacer .....		
27	1				9997-1040-16	Skruv .....	Screw .....		
28	1				9699-0035-02	Planbricka .....	Flat washer .....		
29	1				9739-1031-22	Mutter .....	Nut .....		
30	1				1134-4708-02	Fäste .....	Bracket .....		
31	2				9945-0816-16	Skruv .....	Screw .....		
36	1				1131-1507-00	Fjäder .....	Spring .....		
40	1				1134-5037-01	Bygel .....	Bracket .....		
41	1				1134-1769-02	Remskiva kpl .....	Belt pulley assy .....		
42	1				1134-0051-09	• Distans .....	• Spacer .....		
43	2				9549-0019-00	• Kullager .....	• Ball bearing .....		
44	1				1134-1839-02	Mellanaxel .....	Shaft .....		
45	1				9699-0035-02	Planbricka .....	Flat washer .....		
46	1				9739-1031-22	Mutter .....	Nut .....		
47	1				9997-1070-12	Skruv .....	Screw .....		
48	1				1134-5541-01	Kopplingsarm .....	Clutch lever .....		
49	1				1134-1565-10	Distans .....	Spacer .....		
50	1				9997-0860-16	Skruv .....	Screw .....		
51	1				9699-0056-02	Planbricka .....	Flat washer .....		
52	1				9739-0831-22	Mutter .....	Nut .....		
53	1				1134-9027-01	Spännrulle .....	Tension roller .....		
54	1				1134-1795-01	Rembygel .....	Belt stirrup .....		
55	1				9997-1040-16	Skruv .....	Screw .....		
56	2				9699-0035-02	Planbricka .....	Flat washer .....		
57	1				9739-1031-22	Mutter .....	Nut .....		
58	1				1134-9078-01	Drivrem .....	Drive belt .....		
59	1				1134-4164-01	Bromsklots .....	Brake pad .....		
60	1				9959-0820-16	Skruv .....	Screw .....		
61	1				9699-0090-02	Planbricka .....	Flat washer .....		
62	1				9747-0831-02	Mutter .....	Lock nut .....		
63	2				9959-0820-16	Skruv .....	Screw .....		
64	2				9739-0831-22	Mutter .....	Nut .....		
65	1				9699-0056-02	Planbricka .....	Flat washer .....		
66	1				1131-1506-00	Fjäder .....	Spring .....		
67	1				9997-0860-16	Skruv .....	Screw .....		
68	2				9739-0831-22	Mutter .....	Nut .....		
									= 9585-0139-01
									= 9585-0138-01



Utgåva Issue 2005- 11		Bildnr Picture No 1158D		VILLA DE LUXE- ROYAL KRAFTUTTAG		VILLA DE LUXE- ROYAL POWER TAKE- OFF		Sida Page 264	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 - 75 2724								
1	1				1134-4672- 01	Magnetkoppling.....	Electric PTO- clutch.....		
1 A	1				1134-5016- 01	• Bussning.....	• Bushing.....		
2	1				1134-4679- 01	Momentstag .....	Strut.....		
3	1				9959-0820- 16	Skruv .....	Screw .....		
4	1				1134-4538- 02	Spännrullsfäste.....	Tension roller brkt.....		
5	1				1134-9091- 01	Spännrulle .....	Tension roller .....		
6	1				9699-0056- 02	Planbricka.....	Flat washer.....		
7	1				9959-0820- 16	Skruv .....	Screw .....		
8	1				1134-4650- 01	Monteringsbygel.....	Pulley bracket .....		
9	2				9945-0816- 16	Skruv .....	Screw .....		
10	1				1134-4643- 01	Mellanremskiva kpl.....	Intermediate pulley .....		
11	1				1134-0051- 12	• Distans .....	• Spacer.....		
12	2				9549-0019- 00	• Kullager .....	• Ball bearing .....		
14	2				1134-0052- 00	Lagerdistans .....	Bearing spacer .....		
15	1				9997-1040- 16	Skruv .....	Screw .....		
16	1				9699-0035- 02	Planbricka.....	Flat washer.....		
17	1				1134-9066- 01	Drivrem .....	Drive belt.....		= 9585-0125- 01
18	1				1134-5231- 01	Spännarm .....	Tension arm .....		
19	1				1134-9027- 01	Spännrulle .....	Tension roller .....		
20	1				1134-4619- 01	Distans .....	Spacer.....		
21	1				9997-1060- 12	Skruv .....	Screw .....		
22	1				9739-1031- 22	Mutter.....	Nut .....		
23	1				1134-5232- 01	Spännarmsfäste.....	Attachment.....		
24	1				9997-0640- 12	Skruv .....	Screw .....		
25	1				9747-0631- 02	Låsmutter .....	Lock nut.....		
26	1				1134-4619- 01	Distans .....	Spacer.....		
27	1				9997-1040- 16	Skruv .....	Screw .....		
28	1				9699-0035- 02	Planbricka.....	Flat washer.....		
29	1				9739-1031- 22	Mutter.....	Nut .....		
30	1				1134-4708- 02	Fäste .....	Bracket .....		
31	2				9945-0816- 16	Skruv .....	Screw .....		
36	1				1131-1507- 00	Fjäder.....	Spring .....		
37	1				9739-0831- 22	Mutter.....	Nut .....		
38	1				9987-5357- 12	Skruv .....	Screw .....		
39	1				9600-0251- 00	Plattkil .....	Key.....		L = 3/4"