



Genuine Spare Parts







Utgåva Issue		Bildnr Picture No		VILLA MONTERINGDETALJER		VILLA ASSEMBLY PARTS		Sida Page	
2006- 11		1148D						276	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
0	1				1134-4664-07	Monteringsdetaljer.....	Assembly parts		0.5 mm 1.0 mm
1	1				9595-0262-00	• Spännstift	• Locating pin		
2A	1				9699-0103-02	• Shims	• Flat washer		
2B	1				9699-0114-02	• Shims	• Flat washer		
3	2				1134-4185-01	• Ansatsbricka	• Flange washer		
4	2				9959-0820-16	• Skruv	• Screw		
5	4				9699-0056-02	• Planbricka	• Flat washer		
6	2				1134-2609-01	• Ratt.....	• Knob		
7	1				1134-4627-01	• Dragögla	• Tow bar		
8	2				9959-0820-16	• Skruv	• Screw		
10	1				1134-4734-01	• Tändningsnyckel.....	• Ignition key		
11	2				9837-8914-12	• Skruv	• Screw		
12	1				1134-6113-01	• Batteriskruvar	• Battery screws		
14	1				1134-5245-01	• Batterirem.....	• Battery strap		
20	1				1134-3771-81	Mapp m.trycksaker.....	Folder w.manuals		
21	1				8211-0209-13	• Säkerhetsföreskrifter	• Safety regulations		
21	1				8211-0290-07	• Monteringsanvisning	• Assembly instructions.....		
21	1				8211-0341-03	• Bruksanvisning	• Owner's manual		
21	1				8211-0341-04	• Bruksanvisning	• Owner's manual		
21	1				8211-0549-01	• Servicebok	• Service book		
21	1				8211-2002-03	• Garantikort.....	• Warranty card		

Utgåva Issue 2006- 11		Bildnr Picture No 1150D		VILLA KAROSS		VILLA BODY WORK		Sida Page 278	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
1	1	1			1134- 5067- 01	Huv- framdel	Hood- front.....		Royal Comfort Elite
2	2	2			9893- 0616- 16	Skruv	Screw		
3	2	2			1134- 4444- 01	Stag	Stay		
4	4	4			9959- 0820- 16	Skruv	Screw		
5	4	4			9739- 0831- 22	Mutter	Nut		
6	1	1			1134- 4787- 01	Huv- bakdel	Hood- rear		
7	2	2			1134- 5381- 01	Huvinfästning	Hood attachment.....		
8	4	4			9893- 0616- 16	Skruv	Screw		
9	2	2			1134- 4904- 01	Huvlås kpl.....	Hood lock kit		
12	1	1			1134- 4789- 01	Motorlucka- grå	Engine cover- grey		
13	1				1134- 3944- 03	Stötfångare	Bumper		
13		1			1134- 4220- 03	Stötfångare (m. hål)	Bumper (w. hole)		
14	4	4			1134- 4176- 01	Clips	Clips		
15	6	6			9893- 0616- 16	Skruv	Screw		
16	1	1			1134- 4592- 01	Frontkonsol	Front plate		
17	2	2			9946- 0525- 16	Skruv	Screw		
21	2	2			1134- 4790- 02	Styrning.....	Hood guide		
22	2	2			9838- 9530- 12	Skruv	Screw		
23	2	2			1134- 5078- 01	Stag	Stay		
24	2	2			9893- 0616- 16	Skruv	Screw		
99		1			1134- 5244- 05	Dekalsats	Label kit		
99	1				1134- 5244- 06	Dekalsats	Label kit		
99	1				1134- 5244- 07	Dekalsats	Label kit		





Utgåva Issue 2006- 11		Bildnr Picture No 1149C		VILLA RAM			VILLA FRAME			Sida Page 280	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes		
	2723 2724										
1	1				1134- 5546- 02	Ram.....	Frame.....				
2	1				1134- 5293- 01	Durk.....	Floor plate.....				
3	2				9893- 0616- 16	Skruv.....	Screw.....				
4	1				1134- 5339- 01	Durkmatta.....	Floor mat.....				
5	1				1134- 5382- 01	Stötfångare.....	Bumper.....				
6	2				9959- 0820- 16	Skruv.....	Screw.....				
7	2				9959- 0825- 16	Skruv.....	Screw.....				
8	3				9739- 0831- 22	Mutter.....	Nut.....				
9	1				9739- 0831- 22	Mutter.....	Nut.....				




Utgåva Issue 2006- 11		Bildnr Picture No 1151C		VILLA REDSKAPSLYFT		VILLA LIFTING DEVICE		Sida Page 282	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
1	1	1			1134-4117-01	Fäste	Bracket		L = 40 mm L = 70 mm
2	2				9959-1025-16	Skruv	Screw		
2		2			9997-1070-12	Skruv	Screw		
3	2	2			9739-1031-22	Mutter	Nut		
4	2	2			1134-2684-01	Lager	Bearing		
5	1	1			1134-4945-01	Lyftspärr kpl	Lift catch assy		
9	1	1			9404-0027-01	• O-ring	• O-ring		
10	1	1			9650-0039-04	• Seegersäkring	• Lock ring		
11	1	1			9595-0276-01	• Spännstift	• Locating pin		
12	1	1			9997-0640-12	• Skruv	• Screw		
13	1	1			9747-0631-02	• Låsmutter	• Lock nut		
15	1	1			9897-0820-16	• Skruv	• Screw		
16	1	1			9747-0831-02	Mutter	Lock nut		
17	1	1			1134-4860-01	Lyftgaffel	Lift fork		
18	2	2			1134-0240-00	Ansattsskruv	Shoulder screw		
19	1	1			1134-4938-01	Lyftpedal	Lift pedal		
20	2	2			9997-0625-16	Skruv	Screw		
21	2	2			9739-0631-22	Mutter	Nut		
22	1	1			4231-0013-00	Fjäder	Spring		


Utgåva Issue		Bildnr Picture No		VILLA SITS		VILLA SEAT		Sida Page	
2006- 11		1159F						284	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
2	1	1			1134-4223-01	Sits	Seat.....		Ø = 8 mm
3	1	1			1134-4628-05	Överdel	Seat plate		
4	2	2			1134-0240-00	Ansattsskruv	Shoulder screw		
5	2	2			9747-0831-02	Mutter	Lock nut		
6	1	1			1134-5179-01	Spärr	Catch		
7	1	1			9675-0012-02	Starlock	Locking washer		
12	1	1			1134-4211-08	Sitskonsol	Seat bracket		
13	1	1			1134-4256-01	Sitsfjäder	Seat spring		
14	1	1			9924-1235-19	Skruv	Screw		
15	1	1			9747-1231-02	Låsmutter	Lock nut		
18	1	1			1134-5032-01	Distans	Spacer		
19	1				1134-4950-02	Sitsbrytarplåt	Seat switch bracket		
20	1				1134-3399-01	Brytare	Switch		
21	2				9852-8013-16	Skruv	Screw		
22	2				9893-0616-16	Skruv	Screw		
28	3	3			9959-0820-16	Skruv	Screw	L = 20 mm	
29	1	1			9959-0825-16	Skruv	Screw	L = 25 mm	
31	6	6			9739-0831-22	Mutter	Nut		
32	2	2			9897-0820-16	Skruv	Screw		




Utgåva Issue 2006- 11		Bildnr Picture No 1152D		VILLA COMFORT- ELITE STYRNING		VILLA COMFORT- ELITE STEERING		Sida Page 286	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2723								
1	3			1134- 0041- 01	Linhjulshylsa	Bushing.....		Sats 2 st/kit of 2 L = 40 mm	
2	3			1134- 3022- 01	Linhållare.....	Cable holder			
3	1			1134- 9025- 01	Linhjul- sats	Steering pulley- kit			
4	3			9997- 1040- 16	Skruv	Screw			
5	2			9739- 1031- 22	Mutter.....	Nut			
6	1			1134- 9083- 01	Styrwire.....	Steering cable			
7	1			1134- 1310- 01	Tryckfjäder.....	Compression spring.....			
8	1			9699- 0056- 02	Planbricka.....	Flat washer.....			
9	1			9747- 0831- 02	Mutter.....	Lock nut			
10	1			9959- 0820- 16	Skruv	Screw			
11	1			1134- 4120- 04	Styrkonsol	Steering console			
12	4			9897- 0820- 16	Skruv	Screw			
13	4			9739- 0831- 22	Mutter.....	Nut			
14	1			1134- 4483- 01	Bussning	Bushing.....			
15	1			1134- 1305- 03	Rattrör- nedre	Steering column- lower.....			
16	2			1134- 1901- 01	Lager	Bearing.....			
17	2			9893- 0616- 16	Skruv	Screw			
18	2			9699- 0060- 02	Planbricka.....	Flat washer.....			
19	1			1134- 4431- 01	Rattstång	Steering rod			
20	1			1134- 1933- 01	Styrrulle.....	Steering pulley			
21	1			9595- 0262- 00	Spännstift	Locating pin			
23	1			1134- 5173- 02	Ratt kpl.....	Steering wheel assy			
24	1			1134- 3769- 01	• Styrknopp kpl	• Steering wheel button			
25	1			1134- 3752- 01	• Knoppfäste.....	• Knob holder.....			
26	1			9997- 0865- 12	• Skruv	• Screw			
27	1			1134- 1565- 06	• Distans.....	• Spacer			
28	3			9699- 0090- 02	• Planbricka.....	• Flat washer			
29	1			9747- 0831- 02	• Mutter.....	• Lock nut			
30	1			9403- 0043- 70	• Plugg	• Plug.....			
31	1			9403- 0113- 00	• Mutterhatt.....	• Nut cap.....			
32	1			1134- 3047- 01	Distans	Spacer			
33	2			9699- 0104- 02	Bricka	Washer			
36	2			1134- 3047- 01	Distans	Spacer.....			
37	1			1134- 0041- 05	Hylsa	Bushing.....			
38	1			1134- 3022- 01	Linhållare.....	Cable holder			
39	1			1134- 9025- 01	Linhjul- sats	Steering pulley- kit			
40	1			9997- 1060- 12	Skruv	Screw	Sats 2 st/kit of 2 L = 60 mm		
41	1			1134- 5216- 01	Rattrör- inre kpl	Steering tube- inner.....			
42	1			1134- 5177- 01	• Slid	• Slide			
43	1			9710- 0631- 12	• Fyrkantmutter	• Square nut			
44	1			1134- 4481- 02	Vingmutter.....	Wing nut			
45	1			9997- 0630- 12	Skruv	Screw			




34




Utgåva Issue 2006- 11		Bildnr Picture No 1513B		VILLA ROYAL STYRNING		VILLA ROYAL STEERING		Sida Page 288	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2724								
1	4				1134-0041-01	Linhjulshylsa	Bushing.....		Sats 2 st/kit of 2 L = 40 mm
2	2				1134-3022-01	Linhållare.....	Cable holder		
3	1				1134-9025-01	Linhjul- sats	Steering pulley- kit		75 länk Sats vä+hö/kit L+R
4	2				1134-3547-01	Kedjehjul.....	Sprocket.....		
5	4				9997-1040-16	Skruv	Screw		
6	2				9739-1031-22	Mutter.....	Nut		
7	2				9699-0035-02	Planbricka.....	Flat washer.....		
8	2				1134-0041-07	Hylsa	Bushing.....		
9	2				1134-2816-01	Kedjehjul.....	Sprocket.....		
10	2				9699-0035-02	Planbricka.....	Flat washer.....		
11	2				9739-1031-22	Mutter.....	Nut		
12	1				1134-2820-08	Kedja	Chain		
13	1				1134-9085-01	Styrwire kpl (vä+hö)	Steering cable assy		
15	2				1134-2824-01	Kedjelås	Chain lock		
16	1				1134-1310-01	Tryckfjäder.....	Compression spring.....		
17	1				9699-0056-02	Planbricka.....	Flat washer.....		
18	1				9747-0831-02	Mutter.....	Lock nut.....		
19	1				9959-0820-16	Skruv.....	Screw		
20	1				1134-4120-04	Styrkonsol	Steering console		
21	4				9897-0820-16	Skruv	Screw		
22	4				9739-0831-22	Mutter.....	Nut		
23	1				1134-4483-01	Bussning	Bushing.....		
24	1				1134-1305-03	Rattrör- nedre	Steering column- lower.....		
25	2				1134-1901-01	Lager	Bearing.....		
26	2				9893-0616-16	Skruv	Screw		
27	2				9699-0060-02	Planbricka.....	Flat washer.....		
28	1				1134-2821-02	Rattstång.....	Steering rod		
29	2				1134-3047-01	Distans	Spacer.....		
30	1				9699-0104-02	Bricka	Washer		
31	1				1134-2837-02	Distans	Spacer.....		
33	1				1134-5173-02	Ratt kpl.....	Steering wheel assy		
34	1				1134-3769-01	• Styrknopp kpl	• Steering wheel button		
35	1				1134-3752-01	• Knoppfäste.....	• Knob holder.....		
36	1				9997-0865-12	• Skruv	• Screw		
37	1				1134-1565-06	• Distans.....	• Spacer		
38	3				9699-0090-02	• Planbricka.....	• Flat washer.....		
39	1				9747-0831-02	• Mutter	• Lock nut		
40	1				9403-0043-70	• Plugg	• Plug		
41	1				9403-0113-00	• Mutterhatt.....	• Nut cap.....		
51	1				1134-5216-01	Rattrör- inre kpl	Steering tube- inner.....		
52	1				1134-5177-01	• Slid	• Slide		
53	1				9710-0631-12	• Fyrkantmutter	• Square nut		
54	1				1134-4481-02	Vingmutter.....	Wing nut		
55	1				9997-0630-12	Skruv.....	Screw		




Utgåva Issue 2006- 11		Bildnr Picture No 1511A		VILLA COMFORT- ELITE HANDREGLAGE		VILLA COMFORT- ELITE HAND CONTROLS		Sida Page 290	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723								
1	1				1134- 5077- 01	Konsol	Panel bracket		
2	2				9959- 0820- 16	Skruv	Screw		
3	2				9739- 0831- 22	Mutter	Nut		
4	2				9893- 0616- 16	Skruv	Screw		
5	1				1134- 4487- 02	Frontfäste	Panel bracket		
6	1				1134- 3986- 01	Frontplåt	Front plate		
7	4				9893- 0616- 16	Skruv	Screw		
10	1				1134- 4065- 01	Reglageaxel	Control shaft		
11	1				1134- 4080- 03	Reglagehylsa	Control sleeve		
12	1				1134- 4079- 01	Fjäder	Spring		
13	2				9959- 0820- 16	Skruv	Screw		
21	1				1134- 4590- 01	Gasreglage	Throttle control		
22	1				1134- 4078- 01	Knopp	Knob		
23	1				1134- 0240- 00	Ansattsskruv	Shoulder screw		
24	1				9694- 0001- 00	Fjäderbricka	Washer		
25	2				1134- 4242- 01	Distansbricka	Spacer washer		
26	1				9747- 0831- 02	Mutter	Lock nut		
27	1				1134- 1597- 11	Gaswire	Throttle cable		
28	1				9500- 9991- 00	Wireklämma	Cable clamp		
29	1				9943- 0516- 16	Skruv	Screw		
30	1				1134- 4093- 01	Tändningslås	Ignition switch		
31	1				1134- 4749- 01	Mutter	Nut		
33	1				1134- 4734- 01	Tändningsnyckel	Ignition key		
34	1				1134- 4472- 01	Fästplatta	Attachment plate		
35	2				9943- 0516- 16	Skruv	Screw		
36	1				1134- 4470- 02	Reglagepanel	Dashboard		
37	4				9943- 0516- 16	Skruv	Screw		
38	3				1134- 4129- 01	Täckbricka	Cover		
39	1				1134- 4100- 01	Täckpropp	Plug		
43	1				1134- 4950- 02	Sitsbrytarplåt	Seat switch bracket		
44	2				9893- 0616- 16	Skruv	Screw		
45	1				9695- 0011- 00	Bricka	Washer		
46	1				1134- 5061- 01	Aggregatsspak	Control lever		
47	1				1134- 2551- 01	Reglageknopp	Knob		
48	1				1134- 5358- 01	Brytarfäste	Switch bracket		
49	2				9852- 8013- 16	Skruv	Screw		
50	1				9400- 0285- 01	Microbrytare	Switch		
51	2				9840- 7716- 16	Skruv	Screw		
52	1				1134- 3573- 04	Kraftuttagswire	PTO cable		
53	1				1134- 1242- 02	Fjäder	Spring		
60	1				9959- 0820- 16	Skruv	Screw		
61	1				9739- 0831- 22	Mutter	Nut		
62	1				9699- 0056- 02	Planbricka	Flat washer		



Utgåva Issue 2006- 11		Bildnr Picture No 1164D		VILLA ROYAL HANDREGLAGE		VILLA ROYAL HAND CONTROLS		Sida Page 292	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2724								
1	1				1134- 5077- 01	Konsol	Panel bracket		Tillbehör/Accessory
2	2				9959- 0820- 16	Skruv	Screw		
3	2				9739- 0831- 22	Mutter	Nut		
4	2				9893- 0616- 16	Skruv	Screw		
5	1				1134- 4487- 02	Frontfäste	Panel bracket		
6	1				1134- 3986- 01	Frontplåt	Front plate		
7	4				9893- 0616- 16	Skruv	Screw		
21	1				1134- 4590- 01	Gasreglage	Throttle control		
22	1				1134- 4078- 01	Knopp	Knob		
23	1				1134- 0240- 00	Ansattsskruv	Shoulder screw		
24	1				9694- 0001- 00	Fjäderbricka	Washer		
25	2				1134- 4242- 01	Distansbricka	Spacer washer		
26	1				9747- 0831- 02	Mutter	Lock nut		
27	1				1134- 1597- 12	Gaswire	Throttle cable		
28	1				9500- 9991- 00	Wireklämma	Cable clamp		
29	1				9943- 0516- 16	Skruv	Screw		
30	1				1134- 4093- 01	Tändningslås	Ignition switch		
31	1				1134- 4749- 01	Mutter	Nut		
33	1				1134- 4734- 01	Tändningsnyckel	Ignition key		
34	1				1134- 4472- 01	Fästplatta	Attachment plate		
35	2				9943- 0516- 16	Skruv	Screw		
36	1				1134- 4470- 03	Reglagepanel	Dashboard		
37	4				9943- 0516- 16	Skruv	Screw		
38	1				1134- 4129- 01	Täckbricka	Cover		
39	2				9400- 0282- 01	Brytare m.diod	Switch w.diode		
40	1				9400- 0280- 01	Vippa- kraftuttag	Cover- PTO		
41	1				9400- 0280- 03	Vippa- höjdställning	Cover- height adjust		
45	1				1134- 2872- 04	Chokereglage	Choke control		
45A	1				1134- 4338- 01	• Reglageknopp	• Control knob		
46	1				9699- 0028- 02	Planbricka	Flat washer		
60	1				9959- 0820- 16	Skruv	Screw		
61	1				9739- 0831- 22	Mutter	Nut		
62	1				9699- 0056- 02	Planbricka	Flat washer		
99	1				9400- 0290- 01	Verktyg f.vippa	Tool for cover		





Utgåva Issue		Bildnr Picture No		VILLA FOTREGLAGE		VILLA FOOT CONTROLS		Sida Page	
2006- 11		1161D						294	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
1	1				1134-4802-01	Pedal	Pedal		
2	2				1134-4624-01	Lager	Bearing		
3	4				9897-0640-12	Skruv	Screw		
4	4				9739-0631-22	Mutter	Nut		
5	1				1134-4949-01	Kopplingsstång	Clutch rod		
6	2				1134-2138-01	Skruvögla	Eye bolt		
7	2				9739-1031-22	Mutter	Nut		
9	1				9739-0831-22	Mutter	Nut		
10	1				9747-0831-02	Mutter	Lock nut		
11	1				9595-0208-00	Spännstift	Locating pin		
12	2				9699-0035-02	Planbricka	Flat washer		
13	1				1134-4617-01	Fjäder	Spring		
15	1				9739-0831-22	Mutter	Nut		
16	1				9747-0831-02	Mutter	Lock nut		
18	1				9598-0002-02	Låsnål	Pin lock		
20	1				1134-5101-01	Bromsstång	Brake rod		
21	1				1134-3808-01	Knopp	Knob		
22	1				1131-1497-01	Fjäder	Spring		
23	1				1134-4002-01	Fäste	Brake rod attachment		
24	3				9838-9516-12	Skruv	Screw		
25	1				1134-4008-03	Drivpedal	Drive pedal		
26	2				1134-2780-01	Lager	Bearing		
27	2				1134-2700-01	Fäste	Bracket		
28	2				9959-0820-16	Skruv	Screw		
29	2				9739-0831-22	Mutter	Nut		
30	1				9997-0870-16	Skruv	Screw		
31	2				9739-0831-22	Mutter	Nut		
34	1				1134-4440-01	Axel	Shaft		
35	1				1134-4793-01	Stopplåt	Stop plate		
36	1				1134-4441-01	Stag	Link		
37	2				1134-0240-00	Ansattsskruv	Shoulder screw		
38	2				9694-0001-00	Fjäderbricka	Washer		
39	2				9747-0831-02	Mutter	Lock nut		
40	1				1134-5288-01	Reglagestång	Control rod		
41	2				9675-0012-02	Starlock	Locking washer		
51	1				4231-0013-00	Fjäder	Spring		
52	1				1134-4779-01	Plastbussning	Plastic bushing		
53	1				1134-4972-01	Bromslänk	Brake link		
54	1				9747-0831-02	Mutter	Lock nut		
55	1				9997-0820-16	Skruv	Screw		



Utgåva Issue		Bildnr Picture No		VILLA ELUTRUSTNING		VILLA EL. EQUIPMENT		Sida Page	
2006- 11		1162E						296	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
1	1	1			1134-4804-01	Batteri.....	Battery		
3		1			1134-4194-02	Sitsbrytare.....	Seat switch		
4	1	1			1134-4610-01	Fäste.....	Switch bracket		
5	1	1			1134-3399-02	Brytare.....	Switch.....		
6	2	2			9852-8013-16	Skruv.....	Screw.....		
7	3	3			9579-0003-00	Buntband.....	Cable holder		
8A	1				1134-2042-02	Kabel- svart.....	Cable- black.....		L = 350 mm
8B		1			1134-4701-02	Kabel- svart.....	Cable- black.....		L = 180 mm
9	1	2			9838-9516-12	Skruv.....	Screw		
10	1				9747-0831-02	Mutter.....	Lock nut.....		
11A	1				9795-3531-02	Mutter.....	Nut		1/4 UNC
11B		1			9747-0831-02	Mutter.....	Lock nut.....		M8
12	3	3			9579-0003-00	Buntband.....	Cable holder		
13		1			9400-0223-00	Ringkabelsko	Cable fitting		
22	1	1			9699-0060-02	Planbricka	Flat washer.....		
24		1			1134-4970-02	Kabel- röd	Cable- red.....		L = 310 mm
25		1			1134-2871-03	Relä	Relay		
26	1	1			1134-2962-01	Solenoid kpl	Solenoid assy.....		
27	2	2			9794-5131-02	• Mutter.....	• Nut		
28	1	1			1134-4702-01	Kabel- röd	Cable- red.....		L = 380 mm
29	1	1			1134-2310-01	Batteriskydd.....	Guard cap		
30A	1				1134-4702-02	Kabel- röd	Cable- red.....		L = 480 (6 mm - 8 mm)
30B		1			1134-4703-02	Kabel- röd	Cable- red.....		L = 510 (8 mm - 8 mm)
31		1			1134-4704-02	Kabel- vit.....	Cable- white		L = 510 mm
32		1			1134-5997-01	Kablage.....	Harness.....		
32	1				1134-6093-01	Kablage.....	Harness.....		
35		1			1134-4056-01	Honkontakt.....	Female terminal.....		
36		1			1134-4052-01	Stödbricka	Support washer.....		
37		2			9840-7716-16	Skruv.....	Screw.....		
38		1			1134-3491-01	Säkringshållare	Fuse holder		
39		1			1134-3631-01	Lock- säkringsdosa.....	Cover- fuse holder.....		
40		2			9838-9516-12	Skruv.....	Screw		
41		1			1134-3496-01	Säkring.....	Fuse		10A
41		1			1134-3496-06	Säkring.....	Fuse		20A



X
X





Utgåva Issue 2006- 11		Bildnr Picture No 1625B		VILLA COMFORT- ELITE MOTOR		VILLA COMFORT- ELITE ENGINE		Sida Page 298	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723 -36	2723 -76							
1	4	4			9997-0840-16	Skruv	Screw		H = 39.5 mm L = 460 mm
2	4	4			9747-0831-02	Mutter	Lock nut		
3A	1	1			1134-4468-01	Distans	Spacer		
4	1	1			1134-4222-02	Tätningsring	Seal ring		
5	1	1			1134-5066-01	Bränsletank	Fuel tank		
6	1	1			1134-5532-01	Tanklock	Fuel tank cap		
7	1	1			1134-3224-01	Bensinkran	Fuel shut- off valve		
8	1	1			1134-3225-01	Gummibussning	Grommet		
9	1	1			1134-2975-05	Bensinslang	Fuel hose		
10	2	2			9578-0023-02	Slangklämma	Hose clamp		
12	1	1			1134-4808-01	Tankbygel	Tank clamp		
13	1	1			9699-0060-02	Planbricka	Flat washer		
14	1	1			9747-0631-02	Låsmutter	Lock nut		
15	1	1			1134-4807-02	Tank/batterihylla	Tank/battery shelf		
16	4	4			9829-8830-12	Skruv	Screw		
18A		1			1134-5379-01	Grenrör	Exhaust pipe		
18B	1				1134-5380-01	Grenrör	Exhaust pipe		
19	1	1			1134-0433-00	Ljuddämparpackning	Muffler gasket		
22	2	2			1134-4930-01	Skruv	Screw		
23A		1			1134-5378-01	Ljuddämpare	Muffler		
23B	1				1134-5377-01	Ljuddämpare	Muffler		
24	1	1			9578-0011-01	Klämma	Clamp		
25	1	1			9959-0820-16	Skruv	Screw		
26	1	1			1134-5163-01	Beröringsskydd	Muffler guard		
27	4	4			9893-0616-16	Skruv	Screw		







Utgåva Issue 2006- 11		Bildnr Picture No 1154E		VILLA ROYAL MOTOR		VILLA ROYAL ENGINE		Sida Page 300	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2724								
5	3				9997-0840-16	Skruv	Screw		L = 40 mm
5	1				9997-0850-16	Skruv	Screw		L = 50 mm
6	4				9747-0831-02	Mutter	Lock nut		
8	1				1134-4557-02	Tätningsring	Seal ring		
9	1				1134-5066-01	Bränsletank	Fuel tank		
10	1				1134-5532-01	Tanklock	Fuel tank cap		
11	1				1134-3224-01	Bensinkran	Fuel shut- off valve		
12	1				1134-3225-01	Gummibussning	Grommet		
13	1				1134-2975-05	Bensinslang	Fuel hose		L = 460 mm
14	2				9579-0003-00	Buntband	Cable holder		
15	2				9578-0023-02	Slangklämma	Hose clamp		
16	1				1134-4808-01	Tankbygel	Tank clamp		
17	1				9699-0060-02	Planbricka	Flat washer		
18	1				9747-0631-02	Låsmutter	Lock nut		
19	1				1134-4807-02	Tank/batterihylla	Tank/battery shelf		
20	4				9829-8830-12	Skruv	Screw		
22	1				1134-4638-01	Grenrör	Exhaust manifold		
23	1				1134-4953-02	Ljuddämpare kpl	Muffler assy		Inkl. pos 30
24	1				9578-0011-01	Klämma	Clamp		
25	1				9959-0820-16	Skruv	Screw		
26	1				1134-5163-01	Beröringsskydd	Muffler guard		
27	4				9893-0616-16	Skruv	Screw		
30	1				1134-4955-01	• Ljuddämparinsats	• Muffler insert		
31	1				1134-5827-03	Oljeavtappning kpl	Oil drain assy		Inkl. pos 32 - 35
32	1				1134-5825-01	• Nippel	• Nipple		
33	1				9578-0023-04	• Slangklämma	• Hose clamp		
34	1				1134-3499-02	• Slangklämma	• Hose clamp		
35	1				1134-5826-01	• Plugg	• Plug		




Utgåva Issue		Bildnr Picture No		VILLA TRANSMISSION		VILLA TRANSMISSION		Sida Page	
2006- 11		1157D						302	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
1	1				1134-4611-01	Motorremskiva	Engine belt pulley		= 9585-0099-01
4	1				1134-5414-01	Remstyrning	Belt guide		
5	1				9699-0056-02	Planbricka	Flat washer		
6	1				1134-4519-01	Spännarm	Tension arm		
7	1				1134-9091-01	Spännrulle	Tension roller		
8	1				1134-4614-01	Ansats	Shoulder spacer		
9	1				9997-1040-16	Skruv	Screw		
10	1				9699-0035-02	Planbricka	Flat washer		
11	1				9739-1031-22	Mutter	Nut		
12	1				1134-9027-01	Spännrulle	Tension roller		
13	1				1134-1795-01	Rembygel	Belt stirrup		
14	1				9997-1040-16	Skruv	Screw		
15	2				9699-0035-02	Planbricka	Flat washer		
16	1				9739-1031-22	Mutter	Nut		
17	1				1134-9064-01	Drivrem	Drive belt		
18	1				1134-1565-08	Distans	Spacer		
19	1				9997-0865-12	Skruv	Screw		
20	2				9699-0056-02	Planbricka	Flat washer		
21	1				9739-0831-22	Mutter	Nut		
22	1				1134-5214-01	Fjäder	Spring		
23	1				1134-4846-01	Transaxel	Transaxle	Kanzaki K46AG	
24	4				9997-0865-12	Skruv	Screw		
25	4				9747-0831-02	Mutter	Lock nut		
26	1				1134-4588-01	Momentstag	Strut		
27	1				9945-0816-16	Skruv	Screw		
28	1				9997-0840-16	Skruv	Screw		
29	1				9747-0831-02	Mutter	Lock nut		
40	1				1134-4713-01	Vinkel	Bracket		
41	1				1134-2790-01	Gummihylsa	Rubber grommet		
42	1				1134-5156-01	Dragstång	Pull rod		
43	1				1134-4014-01	Plastknopp	Plastic button		
44	1				9675-0009-02	Starlock	Starlock		
45	1				9945-0816-16	Skruv	Screw		
51	1				1134-2138-01	Skruvögla	Eye bolt		
52	1				1134-4779-01	Plastbussning	Plastic bushing		
53	1				9739-0831-22	Mutter	Nut		
54	1				9747-0831-02	Mutter	Lock nut		
55	1				1134-5319-01	Remstyrning	Belt guide		
56	1				9699-0056-02	Planbricka	Flat washer		



Utgåva Issue 2006- 11		Bildnr Picture No 1155E		VILLA HJUL		VILLA WHEELS		Sida Page 304	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723	2724							
1	1				1134-5893-01	Bakaxel	Rear axle		
2	2				9501-0500-00	Smörjnippel	Grease joint		
3	1				1134-5009-02	Spindel- vå	Spindle- LH		
4	1				1134-5009-01	Spindel- hö	Spindle- RH		
5	2				9699-0088-02	Planbricka	Flat washer		
6	2				9650-0020-04	Spårring	Circlip		
7	1				1134-5316-01	Styrskiva	Steering pulley		
8	1				1134-5575-01	Distans	Spacer		L = 52,8 mm
9	1				1134-9024-01	Lager	Bearing		Sats 4 st/kit of 4
10	1				9699-0104-02	Bricka	Washer		
11	1				9997-1680-12	Skruv	Screw		L = 80 mm
12	2				1134-3247-05	Styrstag	Tie rod		
13A	2				9997-0825-16	Skruv	Screw		L = 25 mm
13B	1				9997-0835-12	Skruv	Screw		L = 35 mm
14	2				9699-0028-02	Planbricka	Flat washer		
15	3				9747-0831-02	Mutter	Lock nut		
16	2				1134-4706-01	Fälg	Rim		
17	1				1134-9026-01	Lagerbussning	Bearing bush kit		Sats 4 st/kit of 4
18	2				9545-0125-01	Däck	Tyre		14 x 5.50 - 6
19	2				9545-0500-00	Ventil	Valve		
20	2				1134-0341-01	Bricka	Washer		
21	2				9650-0020-04	Spårring	Circlip		
22	2				1134-4344-01	Navkapsel	Hub cap		
25	1				9501-0500-00	Smörjnippel	Grease joint		
26	1				9699-0088-02	Planbricka	Flat washer		
27	1				9650-0020-04	Spårring	Circlip		
28	2				1134-4558-01	Fälg	Rim		
29	2				9545-0116-00	Däck	Tyre		16 x 7.50 - 8
30	2				9545-0500-00	Ventil	Valve		
31	6				9699-0035-02	Planbricka	Flat washer		
32	6				9747-1031-02	Låsmutter	Lock nut		
33	2				1134-2471-03	Kil	Key		
34	2				9653-0001-04	Spårryttare	Lock ring		
35	4				1134-0341-01	Bricka	Washer		
36	2				1134-4844-02	Hjulnav	Wheel hub		
37	2				1134-4845-01	Navhylsa	Hub sleeve		
38	2				1134-4981-01	Bricka	Washer		
98					9545-0204-00	Innerslang	Inner tube		Reservdel/spare part
99					9545-0203-00	Innerslang	Inner tube		Reservdel/spare part



Utgåva Issue		Bildnr Picture No		VILLA COMFORT- ELITE KRAFTUTTAG		VILLA COMFORT- ELITE POWER TAKE- OFF		Sida Page	
2006- 11		1512C						306	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2723								
1	1				1134- 5046- 01	Motorremskiva	Engine belt pulley		L = 2 1/2"
2	1				1134- 5017- 01	Bricka	Washer		
3	1				9987- 5332- 16	Skruv	Screw		
4	1				1134- 5058- 01	Remstyrning	Belt guide		
5	1				1134- 5057- 01	Remstyrning	Belt guide		
6	1				9600- 0251- 01	Kil	Key		
7	2				9699- 0056- 02	Planbricka	Flat washer		
8	1				1134- 4650- 01	Monteringsbygel	Pulley bracket		
9	2				9945- 0816- 16	Skruv	Screw		
10	1				1134- 4643- 01	Mellanremskiva kpl	Intermediate pulley		
11	1				1134- 0051- 12	• Distans	• Spacer		
12	2				9549- 0019- 00	• Kullager	• Ball bearing		
14	2				1134- 0052- 00	Lagerdistans	Bearing spacer		
15	1				9997- 1040- 16	Skruv	Screw		
16	1				9699- 0035- 02	Planbricka	Flat washer		
17	1				1134- 9079- 01	Drivrem	Drive belt	= 9585- 0139- 01	
18	1				1134- 5231- 01	Spännarm	Tension arm		
19	1				1134- 9027- 01	Spännrulle	Tension roller		
20	1				1134- 4619- 01	Distans	Spacer		
21	1				9997- 1060- 12	Skruv	Screw		
22	1				9747- 1031- 02	Låsmutter	Lock nut		
23	1				1134- 5232- 01	Spännarmsfäste	Attachment		
24	1				9997- 0640- 12	Skruv	Screw		
25	1				9747- 0631- 02	Låsmutter	Lock nut		
26	1				1134- 4619- 01	Distans	Spacer		
27	1				9997- 1050- 16	Skruv	Screw		
28	1				9699- 0035- 02	Planbricka	Flat washer		
29	1				9747- 1031- 02	Låsmutter	Lock nut		
30	1				1134- 4708- 02	Fäste	Bracket		
31	2				9945- 0816- 16	Skruv	Screw		
36	1				1131- 1507- 00	Fjäder	Spring		
40	1				1134- 5037- 01	Bygel	Bracket		
41	1				1134- 1769- 03	Centrumremskiva kpl	Centre pulley assy		
42	1				1134- 0051- 09	• Distans	• Spacer		
43	2				9549- 0019- 00	• Kullager	• Ball bearing		
44	1				1134- 1839- 02	Mellanaxel	Shaft		
45	1				9699- 0035- 02	Planbricka	Flat washer		
46	1				9739- 1031- 22	Mutter	Nut		
47	1				9997- 1070- 12	Skruv	Screw		
48	1				1134- 5541- 01	Kopplingsarm	Clutch lever		
49	1				1134- 1565- 10	Distans	Spacer		
50	1				9997- 0860- 16	Skruv	Screw		
51	1				9699- 0056- 02	Planbricka	Flat washer		
52	1				9739- 0831- 22	Mutter	Nut		
53	1				1134- 9027- 01	Spännrulle	Tension roller		
54	1				1134- 1795- 01	Rembygel	Belt stirrup		
55	1				9997- 1040- 16	Skruv	Screw		
56	2				9699- 0035- 02	Planbricka	Flat washer		
57	1				9739- 1031- 22	Mutter	Nut		
58	1				1134- 9078- 01	Drivrem	Drive belt	= 9585- 0138- 01	
59	1				1134- 4164- 03	Bromsklots	Brake pad		
60	1				9959- 0820- 16	Skruv	Screw		
61	1				9699- 0090- 02	Planbricka	Flat washer		
62	1				9747- 0831- 02	Mutter	Lock nut		
63	2				9959- 0820- 16	Skruv	Screw		
64	2				9739- 0831- 22	Mutter	Nut		
65	1				9699- 0056- 02	Planbricka	Flat washer		
66	1				1131- 1506- 00	Fjäder	Spring		
67	1				9997- 0860- 16	Skruv	Screw		
68	2				9739- 0831- 22	Mutter	Nut		



Utgåva Issue 2006- 11		Bildnr Picture No 1158D		VILLA ROYAL KRAFTUTTAG		VILLA ROYAL POWER TAKE-OFF		Sida Page 308	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2724								
1	1				1134-4672-01	Magnetkoppling.....	Electric PTO- clutch		
1A	1				1134-5016-01	• Bussning.....	• Bushing		
2	1				1134-4679-01	Momentstag	Strut.....		
3	1				9959-0820-16	Skruv	Screw.....		
4	1				1134-4538-02	Spännrullsfäste.....	Tension roller brkt.		
5	1				1134-9091-01	Spännrulle	Tension roller		
6	1				9699-0056-02	Planbricka.....	Flat washer.....		
7	1				9959-0820-16	Skruv	Screw.....		
8	1				1134-4650-01	Monteringsbygel.....	Pulley bracket		
9	2				9945-0816-16	Skruv	Screw.....		
10	1				1134-4643-01	Mellanremskiva kpl.....	Intermediate pulley		
11	1				1134-0051-12	• Distans	• Spacer.....		
12	2				9549-0019-00	• Kullager	• Ball bearing		
14	2				1134-0052-00	Lagerdistans.....	Bearing spacer		
15	1				9997-1040-16	Skruv	Screw.....		
16	1				9699-0035-02	Planbricka.....	Flat washer.....		
17	1				1134-9066-01	Drivrem	Drive belt.....		= 9585-0125-01
18	1				1134-5231-01	Spännarm	Tension arm		
19	1				1134-9027-01	Spännrulle	Tension roller		
20	1				1134-4619-01	Distans	Spacer		
21	1				9997-1060-12	Skruv	Screw.....		
22	1				9747-1031-02	Låsmutter	Lock nut.....		
23	1				1134-5232-01	Spännarmsfäste.....	Attachment.....		
24	1				9997-0640-12	Skruv	Screw.....		
25	1				9747-0631-02	Låsmutter	Lock nut.....		
26	1				1134-4619-01	Distans	Spacer.....		
27	1				9997-1050-16	Skruv	Screw.....		
28	1				9699-0035-02	Planbricka.....	Flat washer.....		
29	1				9747-1031-02	Låsmutter	Lock nut.....		
30	1				1134-4708-02	Fäste	Bracket.....		
31	2				9945-0816-16	Skruv	Screw.....		
36	1				1131-1507-00	Fjäder.....	Spring		
37	1				9739-0831-22	Mutter	Nut		
38	1				9987-5357-12	Skruv	Screw.....		
39	1				9600-0251-00	Plattkil	Key.....		L = 3/4"