


















Genuine Spare Parts








Utgåva Issue 2007- 11		Bildnr Picture No 2196		VILLA MONTERINGSDETALJER		VILLA ASSEMBLY PARTS		Sida Page 228	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717 2718 2719								
1	1				9595- 0262- 00	Spännstift	Locating pin		0.5 mm 1.0 mm
2A	1				9699- 0103- 02	Shims	Flat washer		
2B	1				9699- 0114- 02	Shims	Flat washer		
3	2				1134- 4185- 01	Ansatsbricka	Flange washer		
5	4				9699- 0056- 02	Planbricka	Flat washer		
6	2				1134- 4481- 01	Vingmutter	Wing nut		
7	1				1134- 4627- 01	Dragögla	Tow bar		
8	2				9959- 0820- 16	Skruv	Screw		
9	4				9997- 0820- 16	Skruv	Screw		
10	1				1134- 6125- 01	Tändningsnyckel	Ignition key		
11	1				1134- 5245- 01	Batterirem	Battery strap		
12	1				1134- 6113- 01	Batteriskruvar	Battery screws		
13	2				9898- 1035- 16	Skruv	Screw		
14	2				9739- 1031- 22	Mutter	Nut		
21	1				8211- 0011- 70	Bruksanvisning	Owner's manual		
21	1				8211- 0012- 70	Bruksanvisning	Owner's manual		
21	1				8211- 0603- 70	Monteringsanvisning	Assy instruction		
21	1				8211- 0701- 70	Säkerhetsföreskrifter	Safety regulations		
21	1				8211- 0950- 70	Garantikort	Warranty card		






Utgåva Issue 2007- 11		Bildnr Picture No 2197		VILLA KAROSS		VILLA BODY WORK		Sida Page 230	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718	2719						
X	1	1	1	1		1134- 5283- 02 Motorhuv- gul	Engine hood- yellow		
	2	7	7	7		9838- 9530- 12 Skruv	Screw		
X	3	1	1	1		1134- 5284- 02 Motorlucka- grå	Engine cover- grey		
	4	1	1	1		1134- 5307- 01 Stänkskärm- vä, grå	Mud guard- LH, grey		
	5	1	1	1		1134- 5307- 02 Stänkskärm- hö, grå	Mud guard- RH, grey		
	6	2	2	2		1134- 0225- 00 Stödplåt	Support plate		
	7	4	4	4		9699- 0056- 02 Planbricka	Flat washer		
	8	6	6	6		9945- 0816- 16 Skruv	Screw		
	9	4	4	4		1134- 4176- 01 Clips	Clips		
	10	4	4	4		9893- 0616- 16 Skruv	Screw		
	11	1	1	1		1134- 5306- 01 Stötfångare, front- vä	Bumper, front- LH		
	12	1	1	1		1134- 5306- 02 Stötfångare, front- hö	Bumper, front- RH		
	13	1	1	1		1134- 5305- 01 Front- nedre	Front plate- lower		
	14	6	6	6		9893- 0616- 16 Skruv	Screw		
	15A	1				1134- 5304- 01 Front- övre	Front- upper		
	15B		1			1134- 5320- 02 Front- övre	Front- upper		
X	15C			1		1134- 5320- 05 Front- övre	Front- upper		
	16	2	2	2		9946- 0525- 16 Skruv	Screw		
	17	2	2	2		1134- 4790- 02 Styrning	Hood guide		
	18	2	2	2		9838- 9530- 12 Skruv	Screw		
	19	2	2	2		9699- 0060- 02 Planbricka	Flat washer		
	20			1		1134- 6199- 01 Deflektor	Deflector		
X	99	1				1134- 6426- 01 Dekalsats	Label kit		Villa 12
X	99		1			1134- 6426- 02 Dekalsats	Label kit		Villa 14 HST
X	99			1		1134- 6426- 03 Dekalsats	Label kit		Villa 16 HST



Utgåva Issue 2007- 11		Bildnr Picture No 1642A		VILLA RAM		VILLA FRAME		Sida Page 232	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718 2719							
1	1	1			1134-5546-02	Ram.....	Frame.....		L = 20 mm L = 25 mm
2	1	1			1134-5293-01	Durk.....	Floor plate		
3	2	2			9893-0616-16	Skruv	Screw.....		
4	1				1134-5338-01	Durkmatta.....	Floor mat.....		
4		1			1134-5339-01	Durkmatta.....	Floor mat.....		
5	1	1			1134-5453-03	Stötfångare- bak, grå	Bumper- rear, grey		
6	1	1			1134-5334-01	Stag- vä	Attachment- LH		
7	1	1			1134-5334-02	Stag- hö	Attachment- RH.....		
8	2	2			1134-0240-00	Ansatsskruv	Shoulder screw		
9	2	2			1134-4242-01	Distansbricka.....	Spacer washer		
10	2	2			9694-0001-00	Fjäderbricka	Washer.....		
11	2	2			9747-0831-02	Mutter.....	Lock nut.....		
12	2	2			9943-0516-16	Skruv	Screw.....		
13	2	2			9959-0820-16	Skruv	Screw.....		
14	2	2			9959-0825-16	Skruv	Screw.....		
15	1	1			9739-0831-22	Mutter.....	Nut.....		
16	3	3			9739-0831-22	Mutter.....	Nut.....		




Utgåva Issue 2007- 11		Bildnr Picture No 1151C		VILLA REDSKAPSLYFT		VILLA LIFTING DEVICE		Sida Page 234	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717 2718 2719								
1	1				1134- 4117- 01	Fäste	Bracket		
2	2				9959- 1025- 16	Skruv	Screw		
3	2				9739- 1031- 22	Mutter.....	Nut		
4	2				1134- 2684- 01	Lager	Bearing.....		
5	1				1134- 4945- 01	Lyftspärr kpl	Lift catch assy		
9	1				9404- 0027- 01	• O- ring.....	• O- ring		
10	1				9650- 0039- 04	• Seegersäkring.....	• Lock ring		
11	1				9595- 0276- 01	• Spännstift	• Locating pin		
12	1				9997- 0640- 12	• Skruv	• Screw		
13	1				9747- 0631- 02	• Låsmutter	• Lock nut		
15	1				9897- 0820- 16	• Skruv	• Screw		
16	1				9747- 0831- 02	Mutter.....	Lock nut.....		
17	1				1134- 4860- 01	Lyftgaffel.....	Lift fork		
18	2				1134- 0240- 00	Ansattsskruv.....	Shoulder screw.....		
19	1				1134- 4938- 01	Lyftpedal	Lift pedal		
20	2				9997- 0625- 16	Skruv	Screw		
21	2				9739- 0631- 22	Mutter.....	Nut.....		
22	1				4231- 0013- 00	Fjäder.....	Spring		




Utgåva Issue 2007- 11		Bildnr Picture No 2198		VILLA SITS		VILLA SEAT		Sida Page 236	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718 2719							
1	1				1134-5506-01	Sits	Seat.....		
2		1			1134-6444-01	Sits	Seat.....		
3	1	1			1134-5301-01	Sitsplatta	Seat plate		
4	2	2			1134-0240-00	Ansattsskruv.....	Shoulder screw		
5	2	2			9747-0831-02	Mutter.....	Lock nut.....		
6	1	1			1134-5454-01	Spärr	Catch.....		
7	1	1			9675-0012-02	Starlock	Locking washer.....		
12	1	1			1134-5296-04	Sitskonsol- gul.....	Seat bracket- yellow		
13	1	1			1134-4256-01	Sitsfjäder	Seat spring.....		
14	1	1			9924-1235-19	Skruv	Screw.....		
15	1	1			9747-1231-02	Låsmutter	Lock nut.....		
16	1	1			9997-0840-16	Skruv	Screw.....		
17	1	1			1134-1565-06	Distans	Spacer.....		
18	1	1			1134-5302-01	Fjäder.....	Spring		
19	1	1			1134-5299-01	Tryckplatta	Push plate		
20	1	1			9699-0090-02	Planbricka.....	Flat washer.....		
21	1	1			9747-0831-02	Mutter.....	Lock nut.....		
22	1	1			1134-3156-02	Brytare (grå)	Switch (grey)		
28	4	3			9959-0820-16	Skruv	Screw.....		L = 20 mm
29	2	1			9959-0825-16	Skruv	Screw.....		L = 25 mm
30	2				9699-0056-02	Planbricka.....	Flat washer.....		
31	6	4			9739-0831-22	Mutter.....	Nut		
32		2			9897-0820-16	Skruv	Screw.....		
33		2			9757-0821-02	Hattmutter	Cap nut		
34		2			9699-0090-02	Planbricka.....	Flat washer.....		




Utgåva Issue		Bildnr Picture No		VILLA STYRNING		VILLA STEERING		Sida Page	
2007- 11		2199						238	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718 2719							
1	3	3			1134- 0041- 01	Linhjulshylsa	Bushing.....	Sats 2 st/kit of 2	
2	3	3			1134- 3022- 01	Linhållare	Cable holder		
3	1	1			1134- 9025- 01	Linhjul- sats	Steering pulley- kit		
4	3	3			9997- 1040- 16	Skruv	Screw		
5	2	2			9739- 1031- 22	Mutter	Nut		
6	1	1			1134- 2032- 04	Styrwire	Steering cable		
7	1	1			1134- 1310- 01	Tryckfjäder	Compression spring		
8	1	1			9699- 0056- 02	Planbricka	Flat washer		
9	1	1			9747- 0831- 02	Mutter	Lock nut		
10	1	1			9959- 0820- 16	Skruv	Screw		
11	1	1			1134- 5349- 03	Styrkonsol- grå	Steering console- grey		
12	4	4			9897- 0820- 16	Skruv	Screw		
13	4	4			9739- 0831- 22	Mutter	Nut		
15	1	1			1134- 1305- 05	Rattrör- nedre	Steering column- lower		
16	2	2			1134- 1901- 01	Lager	Bearing		
17	2	2			9893- 0616- 16	Skruv	Screw		
18	2	2			9699- 0060- 02	Planbricka	Flat washer		
19	1	1			1134- 5495- 01	Rattstång	Steering rod		
20	1	1			1134- 1933- 01	Styrrulle	Steering pulley		
21	1	1			9595- 0262- 00	Spännstift	Locating pin		
22	1				1134- 5496- 01	Ratt	Steering wheel	Sats 2 st/kit of 2	
32	1	1			1134- 3047- 01	Distans	Spacer		
33	2	2			9699- 0104- 02	Bricka	Washer		
36	2	2			1134- 3047- 01	Distans	Spacer		
37	1	1			1134- 0041- 05	Hylsa	Bushing		
38	1	1			1134- 3022- 01	Linhållare	Cable holder		
39	1	1			1134- 9025- 01	Linhjul- sats	Steering pulley- kit		
40	1	1			9997- 1060- 12	Skruv	Screw		
50		1			1134- 6330- 02	Ratt	Steering wheel		
51		1			1134- 3769- 01	• Styrknopp kpl	• Steering wheel button		
52		1			1134- 3752- 01	• Knoppfäste	• Knob holder		
53		1			9997- 0870- 16	• Skruv	• Screw		
54		1			1134- 1565- 06	• Distans	• Spacer		
55		3			9699- 0090- 02	• Planbricka	• Flat washer		
56		1			9747- 0831- 02	• Mutter	• Lock nut		
57		1			9403- 0043- 70	• Plugg	• Plug		
58		1			9403- 0113- 00	• Mutterhatt	• Nut cap		
60		1			1134- 5216- 02	Rattrör- inre	Steering tube- inner		
61		1			1134- 5177- 01	• Slid	• Slide		
62		1			9710- 0631- 12	• Fyrkantmutter	• Square nut		
63		1			1134- 4481- 02	Vingmutter	Wing nut		
64		1			9997- 0630- 12	Skruv	Screw		




Utgåva Issue		Bildnr Picture No		VILLA HANDREGLAGE		VILLA HAND CONTROLS		Sida Page	
2007- 11		1654						240	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
1	1				1134-5286-01	Reglagepanel- vä	Control panel- LH		
2	2				1134-5531-01	Dämpare	Absorber		
3	3				9893-0616-16	Skruv	Screw		
4	1				1134-5357-01	Fäste	Bracket		
5	2				9838-9516-12	Skruv	Screw		
6	1				1134-4077-01	Gasreglage.....	Throttle control		
7	1				1134-4078-01	Knopp	Knob		
8	1				1134-0240-00	Ansattsskruv	Shoulder screw		
9	1				9694-0001-00	Fjäderbricka	Washer		
10	2				1134-4242-01	Distansbricka.....	Spacer washer		
11	1				9747-0831-02	Mutter.....	Lock nut.....		
12	1				1134-1597-13	Gaswire	Throttle cable		
13	1				9500-9991-00	Wireklämma	Cable clamp		
14	1				9943-0516-16	Skruv	Screw		
15	1				9579-0003-00	Buntband	Cable holder		
20	1				9997-0812-02	Skruv	Screw		
21	1				1134-5274-02	Distans	Spacer.....		
22	3				1134-3047-01	Distans	Spacer.....		
23	1				1134-5271-01	Reglagefäste.....	Control bracket		
24	1				1134-5275-01	Växelspak	Gear shift lever		
25	1				1134-5535-01	Fjäder.....	Spring		
26	1				9997-0890-12	Skruv	Screw		
27	1				9747-0831-02	Mutter.....	Lock nut.....		
28	1				1134-5268-01	Stag	Shifter rod		
29	1				9675-0009-02	Starlock	Starlock		
30	1				1134-5271-01	Reglagefäste.....	Control bracket		
31	1				1134-5276-01	Reglagespak	Control lever		
32	1				9997-0890-12	Skruv	Screw		
33	1				9747-0831-02	Mutter.....	Lock nut.....		
34	1				1134-5356-01	Stag	Strut.....		
35	1				9747-0831-02	Mutter.....	Lock nut.....		
36	2				9400-0312-01	Mikrobrytare.....	Micro switch		
37	4				9840-7716-16	Skruv	Screw		
38	1				1134-5358-01	Brytarfäste.....	Switch bracket		
39	2				9943-0516-16	Skruv	Screw		
40	1				1134-5285-01	Reglagepanel- hö	Control panel- RH.....		
41	2				1134-5531-01	Dämpare	Absorber		
42	4				9893-0616-16	Skruv	Screw		
43	2				1134-2551-01	Reglageknopp.....	Knob		
44	1				1134-3573-06	Krafttuttagswire	PTO cable.....		
45	1				1134-1242-02	Fjäder.....	Spring		
50	1				1134-4093-01	Tändningslås	Ignition switch		
51	1				1134-4749-01	Mutter.....	Nut.....		
52	1				1134-4734-01	Tändningsnyckel.....	Ignition key		



Utgåva Issue 2007- 11		Bildnr Picture No 2201		VILLA HST HANDREGLAGE		VILLA HST HAND CONTROLS		Sida Page 242	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718 2719								
1	1				1134- 5286- 04	Reglagepanel- vä	Control panel- LH		
2	2				1134- 5531- 01	Dämpare	Absorber		
3	3				9893- 0616- 16	Skruv	Screw		
4	1				1134- 5464- 01	Fäste	Bracket		
6	1				1134- 5465- 01	Gasreglage.....	Throttle lever		
7	1				1134- 4078- 01	Knopp	Knob		
8	1				1134- 0240- 00	Ansattsskruv	Shoulder screw		
9	1				9694- 0001- 00	Fjäderbricka	Washer		
10	2				1134- 4242- 01	Distansbricka	Spacer washer		
11	1				9747- 0831- 02	Mutter.....	Lock nut.....		
12	1				1134- 4197- 03	Gaswire	Throttle cable		
13	1				9500- 9991- 00	Wireklämma	Cable clamp		
14	1				9943- 0516- 16	Skruv	Screw		
16	1				1134- 6370- 01	Wirestyrning.....	Wire guide.....		
19	1				1134- 5508- 01	Reglagehylsa	Control sleeve		
20	1				9997- 0812- 02	Skruv	Screw		
21	1				1134- 5274- 02	Distans	Spacer.....		
22	1				1134- 3047- 01	Distans	Spacer.....		
30	1				1134- 5271- 01	Reglagefäste.....	Control bracket		
31	1				1134- 5276- 01	Reglagespak	Control lever		
32	1				9997- 0890- 12	Skruv	Screw		
33	1				9747- 0831- 02	Mutter.....	Lock nut.....		
34	1				1134- 5356- 01	Stag.....	Strut.....		
35	1				9747- 0831- 02	Mutter.....	Lock nut.....		
36	1				9400- 0312- 01	Mikrobrytare.....	Micro switch		
37	2				9840- 7716- 16	Skruv	Screw		
40	1				1134- 5285- 02	Reglagepanel- hö	Control panel- RH.....		
41	2				1134- 5531- 01	Dämpare	Absorber		
42	4				9893- 0616- 16	Skruv	Screw		
43	1				1134- 2551- 01	Reglageknopp.....	Knob		
44	1				1134- 3573- 06	Krafttuttagswire	PTO cable.....		
45	1				1134- 1242- 02	Fjäder.....	Spring		





Utgåva Issue 2007- 11		Bildnr Picture No 1644B		VILLA FOTREGLAGE		VILLA FOOT CONTROLS		Sida Page 244	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
1	1				1134- 4802- 01	Pedal	Pedal		Dana 4360- 197 Dana 6800- 7
2	2				1134- 4624- 01	Lager	Bearing		
3	4				9897- 0640- 12	Skruv	Screw		
4	4				9739- 0631- 22	Mutter.....	Nut		
5	1				1134- 4795- 01	Kopplingsstång.....	Clutch rod		
6	1				1134- 2138- 01	Skruvögla	Eye bolt		
7	1				9739- 1031- 22	Mutter.....	Nut		
8	1				9731- 1031- 22	Mutter.....	Nut		
9	1				9739- 0831- 22	Mutter.....	Nut		
10	1				9747- 0831- 02	Mutter.....	Lock nut.....		
11	1				9595- 0208- 00	Spännstift	Locating pin		
14	1				1134- 4777- 01	Bromsstag	Brake rod		
15	1				1134- 4617- 01	Fjäder.....	Spring		
16	2				1134- 2138- 01	Skruvögla	Eye bolt		
17	2				9699- 0035- 02	Planbricka.....	Flat washer.....		
18	4				9595- 0208- 00	Spännstift	Locating pin		
19	2				9739- 0831- 22	Mutter.....	Nut		
20	1				9747- 0831- 02	Mutter.....	Lock nut.....		
26	1				1134- 5353- 01	Bromsstång	Brake rod		
27	1				1134- 2786- 01	Plastknopp.....	Plastic knob		
28	1				1131- 1497- 01	Fjäder.....	Spring		
29	1				1134- 4002- 01	Fäste	Brake rod attachment.....		
30	3				9838- 9516- 12	Skruv	Screw		
31	1				1134- 4714- 01	Fästvinkel.....	Angle bracket		
32	2				9959- 0820- 16	Skruv	Screw		
33	2				9739- 0831- 22	Mutter.....	Nut		
34	1				1134- 4715- 01	Triangel.....	Triangular plate		
35	1				1134- 0240- 00	Ansattsskruv	Shoulder screw		
36	1				9694- 0001- 00	Fjäderbricka	Washer		
37	1				9699- 0036- 02	Planbricka.....	Flat washer.....		
38	1				9747- 0831- 02	Mutter.....	Lock nut.....		
39	1				1134- 4717- 02	Gångstång	Threaded rod.....		
40	2				9570- 0004- 00	Vinkellänk	Elbow link		
41	2				9747- 0631- 02	Låsmutter	Lock nut.....		
42	2				9739- 0631- 22	Mutter.....	Nut		
43	1				1134- 5279- 01	Växelarm	Shift lever.....		
43	1				1134- 6351- 01	Växelarm	Shift lever.....		
44	1				9987- 5016- 16	Skruv	Screw		
45	1				9699- 0060- 02	Planbricka.....	Flat washer.....		
46	1				9675- 0009- 02	Starlock	Starlock		
51	1				1134- 4793- 01	Stopplåt.....	Stop plate.....		
52	1				4231- 0013- 00	Fjäder.....	Spring		
53	2				1134- 4779- 01	Plastbussning	Plastic bushing		
58	1				9747- 0831- 02	Mutter.....	Lock nut.....		






Utgåva Issue 2007- 11		Bildnr Picture No 1645B		VILLA HST FOTREGLAGE		VILLA HST FOOT CONTROLS		Sida Page 246	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718 2719								
1	1				1134-4802-01	Pedal	Pedal		
2	2				1134-4624-01	Lager	Bearing.....		
3	4				9897-0640-12	Skruv	Screw		
4	4				9739-0631-22	Mutter.....	Nut		
5	1				1134-4949-01	Kopplingsstång.....	Clutch rod		
6	2				1134-2138-01	Skruvögla	Eye bolt		
7	2				9739-1031-22	Mutter.....	Nut		
9	1				9739-0831-22	Mutter.....	Nut		
10	1				9747-0831-02	Mutter.....	Lock nut.....		
11	1				9595-0208-00	Spännstift	Locating pin		
12	2				9699-0035-02	Planbricka.....	Flat washer.....		
13	1				1134-4617-01	Fjäder.....	Spring		
15	1				9739-0831-22	Mutter.....	Nut		
16	1				9747-0831-02	Mutter.....	Lock nut.....		
18	1				9598-0002-02	Låsnål.....	Pin lock		
20	1				1134-5353-01	Bromsstång	Brake rod		
21	1				1134-2786-01	Plastknopp.....	Plastic knob		
22	1				1131-1497-01	Fjäder.....	Spring		
23	1				1134-4002-01	Fäste.....	Brake rod attachment.....		
24	3				9838-9516-12	Skruv	Screw		
25	1				1134-6353-01	Drivpedal	Drive pedal		
26	2				1134-6313-01	Lager	Bearing.....		
27	2				1134-2700-01	Fäste.....	Bracket.....		
28	2				9959-0820-16	Skruv	Screw		
29	2				9739-0831-22	Mutter.....	Nut		
30	1				9997-0870-16	Skruv	Screw		
31	2				9739-0831-22	Mutter.....	Nut		
34	1				1134-4440-01	Axel	Shaft		
35	1				1134-4793-01	Stopplåt.....	Stop plate.....		
36	1				1134-4441-01	Stag.....	Link		
37	2				1134-0240-00	Ansattsskruv	Shoulder screw		
38	2				9694-0001-00	Fjäderbricka	Washer.....		
39	2				9747-0831-02	Mutter.....	Lock nut.....		
40	1				1134-5288-01	Reglagestång.....	Control rod.....		
41	2				9675-0012-02	Starlock	Locking washer.....		
51	1				4231-0013-00	Fjäder.....	Spring		
52	1				1134-4779-01	Plastbussning	Plastic bushing		
53	1				1134-4972-01	Bromslänk	Brake link		
54	1				9747-0831-02	Mutter.....	Lock nut.....		
55	1				9997-0820-16	Skruv	Screw		

X
X



Utgåva Issue 2007- 11		Bildnr Picture No 2202		VILLA ELUTRUSTNING		VILLA EL. EQUIPMENT		Sida Page 248	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718	2719						
1	1	1	1		1134-4804-01	Batteri.....	Battery		
4		1	1		1134-4610-01	Fäste.....	Switch bracket		
5		1	1		1134-3399-02	Brytare.....	Switch		
6		2	2		9852-8013-16	Skruv.....	Screw.....		
7		3	3		9579-0003-00	Buntband.....	Cable holder		
8	1	1	1		1134-2042-02	Kabel- svart.....	Cable- black.....		L = 350 mm
9	1	1	1		9838-9516-12	Skruv.....	Screw		
10	1	1	1		9747-0831-02	Mutter.....	Lock nut.....		
11	1	1	1		9795-3531-02	Mutter.....	Nut		1/4 UNC
12	3	3	3		9579-0003-00	Buntband.....	Cable holder		
22	1	1	1		9699-0060-02	Planbricka.....	Flat washer.....		
26	1	1	1		1134-2962-01	Solenoid kpl	Solenoid assy.....		
27	2	2	2		9794-5131-02	• Mutter.....	• Nut		
28	1	1	1		1134-0234-02	Batterikabel (+).....	Battery cable (+).....		L = 395 mm
29	1	1	1		1134-2310-01	Batteriskydd.....	Guard cap		
30	1	1	1		1134-4702-02	Kabel- röd	Cable- red.....		L = 480 mm
32	1				1134-5766-01	Kablage.....	Harness.....		
32		1	1		1134-6308-01	Kablage.....	Harness.....		
32 A	1	1	1		1134-3496-06	• Säkring	• Fuse		20A
39			1		1134-6309-01	Kablage.....	Harness.....		- 2006.11.30
39		1			1134-6348-01	Kablage.....	Harness.....		
39			1		1134-6442-01	Kablage.....	Harness.....		2006.12.01 -
40		1	1		1134-4734-01	Tändningsnyckel.....	Ignition key		
41		1	1		1134-4093-01	Tändningslås	Ignition switch		
42		1	1		1134-4749-01	Mutter.....	Nut		
43 A			1		1134-4056-01	Honkontakt	Female terminal.....		- 2006.11.30
43 B			1		1134-6291-01	Honkontakt	Female terminal.....		2006.12.01 -
45			1		1134-4052-01	Stödbricka	Support washer.....		- 2006.11.30
46		2			9840-7716-16	Skruv	Screw		- 2006.11.30
47			1		1134-6424-01	Kabel	Cable		- 2006.11.30
48			1		9400-0282-01	Brytare m.diod.....	Switch w.diode.....		
49			1		9400-0280-03	Vippa- höjdinställning	Cover- height adjust		





Utgåva Issue 2007- 11		Bildnr Picture No 2200		VILLA MOTOR		VILLA ENGINE		Sida Page 250	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717 2718	2719							
1	4	4			9997-0840-16	Skruv	Screw		L = 460 mm
2	4	4			9747-0831-02	Mutter	Lock nut		
5	1	1			1134-5266-01	Bränsletank	Fuel tank		
6	1	1			1134-5532-01	Tanklock	Fuel tank cap		
7	1	1			1134-3224-01	Bensinkran	Fuel shut-off valve		
8	1	1			1134-3225-01	Gummibussning	Grommet		
9	1	1			1134-2975-05	Bensinslang	Fuel hose		
10	2	2			9578-0023-02	Slangklämma	Hose clamp		
12	1	1			1134-4808-01	Tankbygel	Tank clamp		
13	1	1			9699-0060-02	Planbricka	Flat washer		
14	1	1			9747-0631-02	Låsmutter	Lock nut		
15	1	1			1134-4807-02	Tank/batterihylla	Tank/battery shelf		
16	4	4			9829-8830-12	Skruv	Screw		
19	1	1			1134-0433-00	Ljuddämparpackning	Muffler gasket		
22	2	2			1134-4930-01	Skruv	Screw		
23 A	1				1134-5455-01	Ljuddämpare	Muffler		
23 B		1			1134-5456-01	Ljuddämpare	Muffler		
24	1	1			9739-0831-22	Mutter	Nut		
25	1	1			9959-0820-16	Skruv	Screw		
26	1	1			1134-5457-01	Värmeskydd	Heat guard		
27	4	4			9893-0616-16	Skruv	Screw		





Utgåva Issue		Bildnr Picture No		VILLA TRANSMISSION		VILLA TRANSMISSION		Sida Page	
2007- 11		1643A						252	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
1	1				1134- 4611- 01	Motorremskiva	Engine belt pulley		= 9585- 0124- 01
4	1				1134- 5414- 01	Remstyrning	Belt guide		
5	1				9699- 0056- 02	Planbricka	Flat washer		
6	1				1134- 4519- 01	Spännarm	Tension arm		
7	1				1134- 9091- 01	Spännrulle	Tension roller		
8	1				1134- 4614- 01	Ansats	Shoulder spacer		
9	1				9997- 1040- 16	Skruv	Screw		
10	1				9699- 0035- 02	Planbricka	Flat washer		
11	1				9739- 1031- 22	Mutter	Nut		
12	1				1134- 9027- 02	Spännrulle- grå	Tension roller- grey		
13	1				1134- 1795- 01	Rembygel	Belt stirrup		
14	1				9997- 1040- 16	Skruv	Screw		
15	2				9699- 0035- 02	Planbricka	Flat washer		
16	1				9739- 1031- 22	Mutter	Nut		
17	1				1134- 9065- 01	Drivrem	Drive belt		
18	1				1134- 1565- 08	Distans	Spacer		
19	1				9997- 0870- 16	Skruv	Screw		
20	2				9699- 0056- 02	Planbricka	Flat washer		
21	1				9739- 0831- 22	Mutter	Nut		
22	1				1134- 5214- 01	Fjäder	Spring		
23A	1				1134- 5281- 01	Transaxel kpl.	Transaxle assy		
23B	1				1134- 6338- 01	Transaxel kpl.	Transaxle assy		
24	4				9960- 0860- 12	Skruv	Screw		
25	4				9747- 0831- 02	Mutter	Lock nut		
26	1				1134- 4687- 01	Momentstag	Strut		
27	1				9945- 0816- 16	Skruv	Screw		
28	1				1134- 1849- 01	Remskiva	Belt pulley		
30	1				9650- 0016- 04	Spärring	Lock ring		
31	1				1134- 4707- 01	Remstyrning	Belt guide		
32	1				9942- 0820- 16	Skruv	Screw		
41	1				1134- 2138- 01	Skruvögla	Eye bolt		
42	1				1134- 4779- 01	Plastbussning	Plastic bushing		
43	1				9739- 0831- 22	Mutter	Nut		
44	1				9747- 0831- 02	Mutter	Lock nut		

Dana 4360- 197
Dana 6800- 7

Utgåva Issue		Bildnr Picture No		VILLA HST TRANSMISSION		VILLA HST TRANSMISSION		Sida Page	
2007- 11		1157E						254	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718 2719								
1	1				1134- 4611- 01	Motorremskiva	Engine belt pulley		
4	1				1134- 5414- 01	Remstyrning	Belt guide		
5	1				9699- 0056- 02	Planbricka	Flat washer		
6	1				1134- 4519- 01	Spännarm	Tension arm		
7	1				1134- 9091- 01	Spännrulle	Tension roller		
8	1				1134- 4614- 01	Ansats	Shoulder spacer		
9	1				9997- 1040- 16	Skruv	Screw		
10	1				9699- 0035- 02	Planbricka	Flat washer		
11	1				9739- 1031- 22	Mutter	Nut		
12	1				1134- 9027- 02	Spännrulle- grå	Tension roller- grey		
13	1				1134- 1795- 01	Rembygel	Belt stirrup		
14	1				9997- 1040- 16	Skruv	Screw		
15	2				9699- 0035- 02	Planbricka	Flat washer		
16	1				9739- 1031- 22	Mutter	Nut		
17	1				1134- 9064- 01	Drivrem	Drive belt		= 9585- 0099- 01
18	1				1134- 1565- 08	Distans	Spacer		
19	1				9997- 0870- 16	Skruv	Screw		
20	2				9699- 0056- 02	Planbricka	Flat washer		
21	1				9739- 0831- 22	Mutter	Nut		
22	1				1134- 5214- 01	Fjäder	Spring		
23	1				1134- 4846- 01	Transaxel kpl.	Transaxle assy		Kanzaki K46AG
24	4				9960- 0860- 12	Skruv	Screw		
25	4				9747- 0831- 02	Mutter	Lock nut		
26 A	1				1134- 4588- 01	Momentstag	Strut		- 2006.10.20
26 B	1				1134- 6290- 01	Momentstag	Strut		2006.10.21 -
27	1				9945- 0816- 16	Skruv	Screw		
28	1				9997- 0840- 16	Skruv	Screw		
29	1				9747- 0831- 02	Mutter	Lock nut		
40	1				1134- 4713- 01	Vinkel	Bracket		- 2006.10.20
41	1				1134- 2790- 01	Gummihylsa	Rubber grommet		- 2006.10.20
42	1				1134- 5156- 01	Dragstång	Pull rod		
43	1				1134- 4014- 01	Plastknopp	Plastic button		
44	1				9675- 0009- 02	Starlock	Starlock		
45	1				9945- 0816- 16	Skruv	Screw		
51	1				1134- 2138- 01	Skruvögla	Eye bolt		
52	1				1134- 4779- 01	Plastbussning	Plastic bushing		
53	1				9739- 0831- 22	Mutter	Nut		
54	1				9747- 0831- 02	Mutter	Lock nut		
55	1				1134- 5319- 01	Remstyrning	Belt guide		
56	1				9699- 0056- 02	Planbricka	Flat washer		



Utgåva Issue		Bildnr Picture No		VILLA HJUL		VILLA WHEELS		Sida Page	
2007- 11		1646B						256	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718	2719						
1	1				1134-5894-01	Bakaxel	Rear axle		
2	2				9501-0500-00	Smörjnippel	Grease joint		
3	1				1134-5009-02	Spindel- vä	Spindle- LH		
4	1				1134-5009-01	Spindel- hö	Spindle- RH		
5	2				9699-0088-02	Planbricka	Flat washer		
6	2				9650-0020-04	Spårring	Circlip		
7	1				1134-5316-01	Styrskiva	Steering pulley		
8	1				1134-5575-01	Distans	Spacer		
9	1				1134-9024-01	Lager	Bearing		Sats 4 st/kit of 4
10	1				9699-0104-02	Bricka	Washer		
11	1				9997-1680-12	Skruv	Screw		
12	2				1134-3247-05	Styrstag	Tie rod		
13A	2				9997-0825-16	Skruv	Screw		L = 25 mm
13B	1				9997-0835-12	Skruv	Screw		L = 35 mm
14	2				9699-0090-02	Planbricka	Flat washer		
15	3				9747-0831-02	Mutter	Lock nut		
16	2				1134-4706-01	Fälg	Rim		
17	1				1134-9026-01	Lagerbussning	Bearing bush kit		Sats 4 st/kit of 4
18	2				9545-0117-00	Däck	Tyre		13 x 5.00 - 6
19	2				9545-0500-00	Ventil	Valve		
20	2				1134-0341-01	Bricka	Washer		
21	2				9650-0020-04	Spårring	Circlip		
22	2				1134-4344-01	Navkapsel	Hub cap		
25	1				9501-0500-00	Smörjnippel	Grease joint		
26	1				9699-0088-02	Planbricka	Flat washer		
27	1				9650-0020-04	Spårring	Circlip		
28	2				1134-5255-01	Fälg	Rim		
29	2				9545-0126-01	Däck	Tyre		16 x 6.00 - 8
30	2				9545-0500-00	Ventil	Valve		
32	6				9731-1031-22	Mutter	Nut		
33	2				1134-2471-03	Kil	Key		
34	2				9653-0001-04	Spårryttare	Lock ring		
35	2				1134-0341-01	Bricka	Washer		
36	2				1134-4844-02	Hjulnav	Wheel hub		
37	2				1134-4845-02	Navhylsa	Hub sleeve		
38	2				1134-4981-01	Bricka	Washer		
50	2				1134-6274-01	Redskapsfäste kpl	Attachment assy		
51	1				1134-9026-01	• Lagerbussning	• Bearing bush kit		Sats 4 st/kit of 4
52	1				9501-0502-00	• Smörjnippel	• Grease joint		
98					9545-0204-00	Innerslang	Inner tube		Reservdel/spare part
99					9545-0203-00	Innerslang	Inner tube		Reservdel/spare part



Utgåva Issue		Bildnr Picture No		VILLA KRAFTUTTAG		VILLA POWER TAKE- OFF		Sida Page	
2007- 11		1512D						258	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718	2719						
1	1				1134- 5046- 01	Motorremskiva	Engine belt pulley		L = 2 1/2"
2	1				1134- 5017- 01	Bricka	Washer		
3	1				9987- 5332- 16	Skruv	Screw		
4	1				1134- 5058- 01	Remstyrning	Belt guide		
5	1				1134- 5057- 01	Remstyrning	Belt guide		
6	1				9600- 0251- 01	Kil	Key		
7	2				9699- 0056- 02	Planbricka	Flat washer		
8	1				1134- 4650- 01	Monteringsbygel	Pulley bracket		
9	2				9945- 0816- 16	Skruv	Screw		
10	1				1134- 4643- 01	Mellanremskiva kpl	Intermediate pulley		
11	1				1134- 0051- 12	• Distans	• Spacer		
12	2				9549- 0019- 00	• Kullager	• Ball bearing		
14	2				1134- 0052- 00	Lagerdistans	Bearing spacer		
15	1				9997- 1040- 16	Skruv	Screw		
16	1				9699- 0035- 02	Planbricka	Flat washer		
17	1				1134- 9079- 01	Drivrem	Drive belt	= 9585- 0139- 01	
18	1				1134- 5231- 01	Spännarm	Tension arm		
19	1				1134- 6329- 01	Spännrulle	Tension roller		
20	1				1134- 4619- 01	Distans	Spacer		
21	1				9997- 1060- 12	Skruv	Screw		
22	1				9731- 1031- 22	Mutter	Nut		
23	1				1134- 6314- 01	Spännarmsfäste	Attachment		
24	1				9997- 0640- 12	Skruv	Screw		
25	1				9747- 0631- 02	Låsmutter	Lock nut		
26	1				1134- 4619- 01	Distans	Spacer		
27	1				9930- 1050- 12	Skruv	Screw		
28	1				9699- 0035- 02	Planbricka	Flat washer		
29	1				9731- 1031- 22	Mutter	Nut		
30	1				1134- 4708- 02	Fäste	Bracket		
31	2				9945- 0816- 16	Skruv	Screw		
36	1				1131- 1507- 00	Fjäder	Spring		
40	1				1134- 5037- 01	Bygel	Bracket		
41	1				1134- 1769- 03	Centrumremskiva kpl	Centre pulley assy		
42	1				1134- 0051- 09	• Distans	• Spacer		
43	2				9549- 0019- 00	• Kullager	• Ball bearing		
44	1				1134- 1839- 02	Mellanaxel	Shaft		
45	1				9699- 0035- 02	Planbricka	Flat washer		
46	1				9739- 1031- 22	Mutter	Nut		
47	1				9997- 1070- 12	Skruv	Screw		
48	1				1134- 5541- 01	Kopplingsarm	Clutch lever		
49	1				1134- 1565- 10	Distans	Spacer		
50	1				9997- 0860- 16	Skruv	Screw		
51	1				9699- 0056- 02	Planbricka	Flat washer		
52	1				9739- 0831- 22	Mutter	Nut		
53	1				1134- 9027- 02	Spännrulle- grå	Tension roller- grey		
54	1				1134- 1795- 01	Rembygel	Belt stirrup		
55	1				9997- 1040- 16	Skruv	Screw		
56	2				9699- 0035- 02	Planbricka	Flat washer		
57	1				9739- 1031- 22	Mutter	Nut		
58	1				1134- 9078- 01	Drivrem	Drive belt		
59	1				1134- 4164- 03	Bromsklots	Brake pad		
60	1				9959- 0820- 16	Skruv	Screw		
61	1				9699- 0090- 02	Planbricka	Flat washer		
62	1				9747- 0831- 02	Mutter	Lock nut		
63	2				9959- 0820- 16	Skruv	Screw		
64	2				9739- 0831- 22	Mutter	Nut		
65	1				9699- 0056- 02	Planbricka	Flat washer		
66	1				1131- 1506- 00	Fjäder	Spring		
67	1				9997- 0860- 16	Skruv	Screw		
68	2				9739- 0831- 22	Mutter	Nut		