



[www.stiga.com](http://www.stiga.com)

# Illustrated Parts List

**for model:**

**Park Compact 2 WD**

- Use GLOBAL GARDEN PRODUCT genuine spare parts specified in the parts list for repair and/or replacement.
- Then contents described in the parts list may change due to improvement.
- The drawings of the spare part are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.









© Copyright 2014 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.


THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.

[www.ggp-group.com](http://www.ggp-group.com)








Utgåva Issue 2014-11		Bildnr Picture No 1638D		PARK 2WD MONTERINGSDETALJER		PARK 2WD ASSEMBLY PARTS		Sida Page 2	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
2	1				1134-6113-01	Batteriskruvar .....	Battery screws .....		
4	2				9595-0262-00	Spännstift.....	Locating pin .....		
5A	1				9699-0103-02	Shims .....	Flat washer .....		0.5 mm
5B	1				9699-0114-02	Shims .....	Flat washer .....		1.0 mm
6	2				1134-4185-01	Ansatsbricka .....	Flange washer .....		
7	2				9959-0820-16	Skruv.....	Screw.....		
8	2				1134-4481-01	Vingmutter .....	Wing nut.....		
9	4				9699-0056-02	Planbricka.....	Flat washer .....		
10	2				1134-4734-01	Tändningsnyckel.....	Ignition key .....		
12	2				9997-0820-16	Skruv.....	Screw.....		
13	1				1134-5512-01	Dragplåt .....	Towing plate.....		
14	2				9959-0820-16	Skruv.....	Screw.....		
15	2				9739-0831-22	Mutter .....	Nut.....		
18	2				9898-1035-16	Skruv.....	Screw.....		
19	2				9739-1031-22	Mutter .....	Nut.....		
31	1					Bruksanvisning.....	Owners manual .....		As PDF



Utgåva Issue 2014-11		Bildnr Picture No 1658B		PARK 2WD KAROSS		PARK 2WD BODY WORK		Sida Page 4	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-5263-02	Motorhuv-gul.....	Engine hood-yellow .....		Sats 3 st/kit of 3
2	7				9838-9530-12	Skruv.....	Screw.....		
3	1				1134-9028-01	Gummistropp-sats .....	Rubber strap kit.....		
4	1				9632-0516-00	Popnit.....	Pop rivet.....		
5	1				9699-0120-02	Bricka .....	Washer.....		
6	1				1134-5264-01	Motorlucka-grå.....	Engine cover-grey .....		
7	1				1134-5308-01	Stänkskärm vä-grå.....	Mud guard LH-grey .....		
8	1				1134-5308-02	Stänkskärm hö-grå.....	Mud guard RH-grey .....		
9	4				9893-0616-16	Skruv.....	Screw.....		
10	4				1134-4176-01	Clips.....	Clips .....		
11	2				1137-0088-01	Stödplåt.....	Support plate .....		
12	6				9945-0816-16	Skruv.....	Screw.....		
13	4				9699-0056-02	Planbricka .....	Flat washer .....		
14	1				1134-5306-01	Stötfångare, front-vä.....	Bumper, front-LH .....		
15	1				1134-5306-02	Stötfångare, front-hö.....	Bumper, front-RH .....		
16	2				9893-0616-16	Skruv.....	Screw.....		
18	1				1134-5305-01	Front-nedre .....	Front plate-lower.....		
19	2				9893-0616-16	Skruv.....	Screw.....		
20	1				1134-5320-02	Front-övre .....	Front-upper .....		
21	2				9946-0525-16	Skruv.....	Screw.....		
22	1				1134-6241-01	Huvstöd.....	Hood support.....		
23	3				9893-0616-16	Skruv.....	Screw.....		
24	1				1134-3970-05	Kantlist-vä, grå .....	Moulding-LH, grey .....		
25	1				1134-3970-02	Kantlist-hö, grå .....	Moulding-RH, grey.....		
26	2				9893-0616-16	Skruv.....	Screw.....		
27	2				9699-0060-02	Planbricka .....	Flat washer .....		
28	2				9747-0631-02	Låsmutter.....	Lock nut .....		
29	2				9897-0616-16	Vagnsbult .....	Carriage bolt.....		
99	1				1134-6440-02	Dekalsats.....	Label kit .....		




Utgåva Issue 2014-11		Bildnr Picture No 1669D		PARK 2WD RAM		PARK 2WD FRAME		Sida Page 6	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1137-0388-01	Ram-främre.....	Frame-front .....		Inkl. pos 2-5  Rak/straight 90°
2	1				1134-3963-02	Midjegaffel .....	Clevis .....		
3	1				1134-0031-00	Ledaxelstopp.....	Pivot shaft stop.....		
4	1				9595-0262-00	Spännstift.....	Locating pin .....		
5A	1				9501-0500-00	Smörjnippel .....	Grease joint .....		
5B	1				9501-0504-01	Smörjnippel .....	Grease joint .....		
6	1				1134-2171-01	Fjäder.....	Spring .....		
7	1				1134-6466-02	Ram-bakre .....	Frame-rear.....		
8	1				1134-5705-01	Distans .....	Spacer.....		
9	2				9547-0001-00	Ledlager.....	Bearing .....		
10	2				9501-0500-00	Smörjnippel .....	Grease joint .....		
11	1				1134-5988-01	Centrumaxel .....	Centre shaft .....		
13	2				9699-0035-02	Planbricka .....	Flat washer .....		
14	2				9959-1025-16	Skruv.....	Screw.....		
16	1				1134-6586-01	Durk.....	Floor plate .....		
17	1				1134-6372-04	Durkmatta.....	Floor mat.....		
18	2				9893-0616-16	Skruv.....	Screw.....		
19	2				9403-0048-70	Täckpropp.....	Plug .....		
20	2				9945-0816-16	Skruv.....	Screw.....		
21	2				9959-0820-16	Skruv.....	Screw.....		
22	2				9739-0831-22	Mutter .....	Nut.....		
28	1				1134-4975-01	Gummibuffert .....	Rubber block.....		
29	1				9950-0570-12	Skruv.....	Screw.....		
30	2				9739-0531-22	Mutter .....	Nut.....		
31	1				1134-5337-02	Stötfångare-bak, grå .....	Bumper-rear, grey .....		
32	2				1134-0240-00	Ansatsskruv .....	Shoulder screw .....		
33	2				1134-4242-01	Distansbricka .....	Spacer washer .....		
34	2				9665-0002-00	Brickfjäder.....	Bowed washer .....		
35	2				9747-0831-02	Mutter .....	Lock nut .....		
36	2				9943-0516-16	Skruv.....	Screw.....		
37	2				1134-5345-01	Stag .....	Attachment .....		
38	1				1134-5344-01	Batterihylla .....	Battery shelf.....		
39	4				9945-0816-16	Skruv.....	Screw.....		








Utgåva Issue 2014-11		Bildnr Picture No 1023D		PARK 2WD PEDALLYFT		PARK 2WD PEDAL LIFT		Sida Page 8	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-4117-01	Fäste.....	Bracket .....		
2	2				1134-2684-01	Lager.....	Bearing .....		
3	1				1134-4945-01	Lyftspärr kpl .....	Lift catch assy .....		
7	1				9404-0027-01	O-ring .....	O-ring .....		
8	1				9650-0039-04	Seegersäkring .....	Lock ring .....		
9	1				9595-0276-01	Spännstift.....	Locating pin .....		
10	1				9997-0640-12	Skruv.....	Screw.....		
11	1				9747-0631-02	Låsmutter.....	Lock nut .....		
13	1				9897-0820-16	Skruv.....	Screw.....		
14	1				9747-0831-02	Mutter .....	Lock nut .....		
15	1				1134-4860-01	Lyftgaffel .....	Lift fork .....		
16	2				1134-0240-00	Ansattsskruv .....	Shoulder screw.....		
17	1				1134-4938-01	Lyftpedal.....	Lift pedal .....		
18	2				9997-0625-16	Skruv.....	Screw.....		
19	2				9739-0631-22	Mutter .....	Nut.....		
20	1				4231-0013-00	Fjäder.....	Spring.....		




Utgåva Issue		Bildnr Picture No		PARK 2WD SITS		PARK 2WD SEAT		Sida Page	
2014-11		1657B						10	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
2	1				1134-6444-01	Sits .....	Seat.....		
3	1				1134-5301-01	Sitsplatta .....	Seat plate.....		
4	2				1134-0240-00	Ansatssskruv .....	Shoulder screw.....		
5	2				9747-0831-02	Mutter .....	Lock nut .....		
6	1				1134-5454-01	Spärr .....	Catch .....		
7	1				9675-0012-02	Starlock.....	Locking washer.....		
10	4				9893-0616-16	Skruv.....	Screw.....		
11	1				1134-5300-01	Bakstycke-gul.....	Rear plate-yellow.....		
12	1				1134-5296-04	Sitskonsol-gul.....	Seat bracket-yellow.....		
13	1				1134-4256-01	Sitsfjäder.....	Seat spring.....		
14	1				9924-1235-19	Skruv.....	Screw.....		
15	1				9747-1231-02	Låsmutter.....	Lock nut .....		
16	1				9997-0840-12	Skruv.....	Screw.....		
17	1				1134-1565-06	Distans .....	Spacer.....		
18	1				1134-5302-01	Fjäder.....	Spring.....		
19	1				1134-5299-01	Tryckplatta.....	Push plate .....		
20	1				9699-0090-02	Planbricka.....	Flat washer .....		
21	1				9747-0831-02	Mutter .....	Lock nut .....		
22	1				1134-3156-02	Brytare (grå) .....	Switch (grey).....		
26	2				9897-0880-12	Skruv.....	Screw.....		L = 80 mm
27	2				1134-1565-08	Distans .....	Spacer.....		
28	4				9897-0820-16	Skruv.....	Screw.....		L = 20 mm
29	6				9747-0831-02	Mutter .....	Lock nut .....		



Utgåva Issue 2014-11		Bildnr Picture No 1664A		PARK 2WD STYRNING		PARK 2WD STEERING		Sida Page 12	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-6380-02	Kedja.....	Chain.....		83 länk
2	1				1134-9084-01	Styrwire kpl (vä+hö).....	Steering cable assy.....		Sats vä+hö/kit L+R
4	2				1134-2824-02	Kedjelås.....	Chain lock.....		
5	2				1134-3817-01	Tryckfjäder.....	Compression spring.....		L = 58 mm
6	2				9699-0090-02	Planbricka.....	Flat washer.....		
7	2				9747-0831-02	Mutter.....	Lock nut.....		
8	4				1134-2816-01	Kedjehjul.....	Sprocket.....		
9	4				1134-0041-02	Linhjulshylsa.....	Idler wheel bush.....		
10	4				9699-0035-02	Planbricka.....	Flat washer.....		
11	2				9997-1050-16	Skruv.....	Screw.....		
12	2				9897-1040-12	Skruv.....	Screw.....		
13	4				9739-1031-22	Mutter.....	Nut.....		
14	2				1134-9025-01	Linhjul-sats.....	Steering pulley-kit.....		Sats 2 st/kit of 2
15	2				1134-0041-01	Linhjulshylsa.....	Bushing.....		
16	2				1134-0046-00	Linhållare.....	Wire clamp.....		
17	2				9997-1030-16	Skruv.....	Screw.....		
18	2				9739-1031-22	Mutter.....	Nut.....		
19	1				1134-5349-01	Styrkonsol-gul.....	Steering console-yel.....		
20	4				9897-0820-16	Skruv.....	Screw.....		
21	4				9739-0831-22	Mutter.....	Nut.....		
22	1				1134-1305-05	Rattrör-nedre.....	Steering column-lower.....		
23	2				1134-1901-01	Lager.....	Bearing.....		
24	2				9893-0616-16	Skruv.....	Screw.....		
25	1				1137-0079-02	Rattstång.....	Steering rod.....		
26	1				1134-2837-01	Distans.....	Spacer.....		
27	1				1134-5496-03	Ratt.....	Steering wheel.....		









Utgåva Issue 2014-11		Bildnr Picture No 1670B		PARK 2WD HANDREGLAGE		PARK 2WD HAND CONTROLS		Sida Page 14	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-6301-01	Aggregatsspak .....	Engagement lever.....		
2	1				1134-2551-01	Reglageknopp .....	Knob.....		
3	1				1134-3790-02	Lager.....	Bearing .....		
4	1				9699-0090-02	Planbricka .....	Flat washer .....		
5	1				4231-0013-00	Fjäder .....	Spring .....		
6	1				1134-5368-01	Panel .....	Dashboard .....		
7	1				9400-0360-01	Mikrobrytare .....	Micro switch .....		
8	4				9946-0525-16	Skruv.....	Screw.....		
9	1				1134-3573-05	Reglagewire.....	Control cable.....		
20	1				1134-5465-02	Gasreglage .....	Throttle lever.....		
21	1				1134-4078-01	Knopp .....	Knob.....		
22	1				1134-5464-01	Fäste.....	Bracket .....		
23	1				1134-0240-00	Ansattsskruv .....	Shoulder screw.....		
24	2				1134-4242-01	Distansbricka .....	Spacer washer .....		
25	1				9694-0001-00	Fjäderbricka .....	Washer.....		
26	1				9747-0831-02	Mutter .....	Lock nut .....		
27	1				1134-4197-03	Gaswire .....	Throttle cable .....		
28	1				9500-9991-00	Wireklämma .....	Cable clamp .....		
29	1				9943-0516-16	Skruv.....	Screw.....		









Utgåva Issue 2014-11		Bildnr Picture No 2026A		PARK 2WD FOTREGLAGE		PARK 2WD FOOT CONTROLS		Sida Page 16	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-5655-01	Broms/kopplingspedal.....	Brake/clutch pedal .....		Sats 4 st/kit of 4
2	1				1134-9024-01	Lager.....	Bearing.....		
3	1				1134-5677-02	Distans.....	Spacer.....		
4	1				9997-1070-12	Skruv.....	Screw.....		
5	1				9699-0030-02	Planbricka.....	Flat washer.....		
6	1				9739-1031-22	Mutter.....	Nut.....		
7	1				1134-6005-01	Wire.....	Cable.....		
8	1				4231-0013-00	Fjäder.....	Spring.....		
9	1				1134-6467-01	Wirefäste.....	Cable holder.....		
10	2				9959-0820-16	Skruv.....	Screw.....		
11	1				9739-0831-22	Mutter.....	Nut.....		
12	1				9739-0831-22	Mutter.....	Nut.....		
13	1				1134-6353-01	Drivpedal.....	Drive pedal.....		
14	2				1134-6313-01	Lager.....	Bearing.....		
15	2				1134-2700-01	Fäste.....	Bracket.....		
16	2				9959-0820-16	Skruv.....	Screw.....		
17	2				9739-0831-22	Mutter.....	Nut.....		
18	1				9997-0835-16	Skruv.....	Screw.....		
19	1				9739-0831-22	Mutter.....	Nut.....		
22	1				1134-2766-05	Reglagewire.....	Speed control cable.....		
23	2				9570-0001-00	Vinkellänk.....	Elbow link.....		
24	2				9739-0531-22	Mutter.....	Nut.....		
25	2				9747-0531-02	Mutter.....	Nut.....		
26	1				1134-6317-01	Wirefäste.....	Cable holder.....		
28	2				9959-0620-16	Skruv.....	Screw.....		
29	2				9739-0631-22	Mutter.....	Nut.....		
30	1				1134-3395-01	Fäste.....	Attachment.....		
31	2				9959-0820-16	Skruv.....	Screw.....		
32	2				9739-0831-22	Mutter.....	Nut.....		
33	1				1134-2021-01	Växelwirefäste.....	Clamp.....		
34	1				1134-5353-01	Bromsstång.....	Brake rod.....		
35	1				1134-2786-01	Plastknopp.....	Plastic knob.....		
36	1				1131-1497-01	Fjäder.....	Spring.....		
37	1				1134-4002-01	Fäste.....	Brake rod attachment.....		
38	3				9838-9516-12	Skruv.....	Screw.....		



Utgåva Issue 2014-11		Bildnr Picture No 1671G		PARK 2WD ELUTRUSTNING		PARK 2WD EL. EQUIPMENT		Sida Page 18	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6102 6103	6100							
1	1	1		1134-4804-01	Batteri .....	Battery .....			
2	1			1134-5769-01	Kablage.....	Harness.....			
2		1		1137-0455-01	Kablage.....	Harness.....			
2A	1	1		9400-0327-01	Säkringshållare .....	Fuse holder.....		Inkl. pos 2B 20A	
2B	1	1		1134-3496-06	Säkring.....	Fuse .....			
3	1	1		1134-5343-01	Batterikonsol.....	Battery bracket.....			
4	3	3		9852-8013-16	Skruv.....	Screw.....			
5	2	2		9699-0060-02	Planbricka.....	Flat washer .....			
6	1	1		1134-2962-01	Solenoid kpl.....	Solenoid assy .....		nkl. pos 8	
7	2	2		9852-8013-16	Skruv.....	Screw.....			
8	2	2		9794-5131-02	Mutter .....	Nut.....			
9	1	1		1134-4093-01	Tändningslås.....	Ignition switch .....			
10	1	1		1134-4749-01	Mutter .....	Nut.....			
11	1	1		1134-5245-01	Batterirem.....	Battery strap .....			
12	1			1134-2167-01	Kabel.....	Cable .....			
12		1		1134-2167-02	Kabel.....	Cable .....			
13	1	1		1134-0234-02	Batterikabel ( + ).....	Battery cable ( + ) .....			
14	1	1		1134-2310-01	Batteriskydd.....	Guard cap .....			
15	1	1		9795-3531-02	Mutter .....	Nut.....		1/4" UNC	
16	15	15		9579-0003-00	Buntband.....	Cable holder .....			
25	1	1		1134-3399-02	Brytare .....	Switch .....			
26	2	2		9997-0520-16	Skruv.....	Screw.....			
27	2	2		9747-0531-02	Mutter .....	Nut.....			
28		1		1134-6454-01	Jordplåt .....	Ground plate.....			
29		2		9959-0612-16	Skruv.....	Screw.....			
30		2		9739-0631-22	Mutter .....	Nut.....			
32		1		1137-0441-01	Fäste.....	Bracket .....			
33		2		9945-0816-16	Skruv.....	Screw.....			




Utgåva Issue 2014-11		Bildnr Picture No 1672E		PARK 2WD MOTOR B&S		PARK 2WD ENGINE B&S		Sida Page 20	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6103	6102							
1	4	4		9955-3725-16	Skruv.....	Screw.....		3/8" UNC x 25 mm	
3A		1		1134-5370-01	Ljuddämpare.....	Muffler.....			
3A	1			1134-7784-01	Ljuddämpare.....	Muffler.....			
4	1	1		1134-0433-00	Ljuddämparpackning.....	Muffler gasket.....			
5	2	2		1134-4930-01	Skruv.....	Screw.....			
6	1	1		9959-0820-16	Skruv.....	Screw.....			
7	1	1		9739-0831-22	Mutter.....	Nut.....			
8	1	1		1134-5390-01	Dragkroksbalk.....	Tow bar bracket.....			
9	4	4		9945-0816-16	Skruv.....	Screw.....			
14	1	1		1137-0082-01	Motorremskiva.....	Engine pulley.....			Ø = 139 mm Ø = 85 mm L = 2 1/2"
15	1	1		1137-0007-01	Motorremskiva.....	Engine pulley.....			
16	1	1		9600-0251-01	Kil.....	Key.....			
17	1	1		1134-5017-01	Bricka.....	Washer.....			
18	1	1		9987-5332-16	Skruv.....	Screw.....			
19	1	1		1134-6618-01	Bränsletank.....	Fuel tank.....			
20	1	1		1134-5532-01	Tanklock.....	Fuel tank cap.....			
21	1	1		1134-3224-01	Bensinkran.....	Fuel shut-off valve.....			
22	1	1		1134-3225-01	Gummibussning.....	Grommet.....			
23	0,52	0,52		9505-0001-01	Bensinslang (meter).....	Fuel line (metre).....			Per meter
24	1	1		9578-0023-02	Slangklämma.....	Hose clamp.....			
25	1	1		1134-6627-01	Tankkonsol.....	Fuel tank bracket.....			
26	2	2		9959-0820-16	Skruv.....	Screw.....			
27	2	2		9739-0831-22	Mutter.....	Nut.....			
28	2	2		1134-5346-01	Tankbygel.....	Fuel tank loop.....			
29	2	2		9747-0631-02	Låsmutter.....	Lock nut.....			
30	1	1		9579-0003-00	Buntband.....	Cable holder.....			
40	1	1		9578-0023-02	Slangklämma.....	Hose clamp.....			
41	1	1		1134-5827-01	Oljeavtappning kpl.....	Oil drain assy.....		Inkl. pos 42 - 45	
42	1	1		1134-5825-01	Nippel.....	Nipple.....			
43	1	1		9578-0023-04	Slangklämma.....	Hose clamp.....			
44	1	1		1134-3499-02	Slangklämma.....	Hose clamp.....			
45	1	1		1134-5826-01	Plugg.....	Plug.....			






**STIGA**  
2902  
SPARE PARTS

Utgåva Issue 2014-11		Bildnr Picture No 2902		PARK 2WD MOTOR HONDA		PARK 2WD ENGINE HONDA		Sida Page 22	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6100								
1	2				9987-5132-12	Skruv.....	Screw.....		Engine part
2	2				9699-0056-02	Bricka .....	Washer.....		
3	2				9997-0845-12	Skruv.....	Screw.....		
4	2				9747-0831-02	Mutter .....	Nut.....		
5	1				1137-0444-01	Ljuddämpare.....	Muffler .....		
6						Ljuddämparpackning.....	Muffler gasket.....		
7	2				9935-0820-16	Skruv.....	Screw.....		
8	1				9959-0820-16	Skruv.....	Screw.....		
9	1				9739-0831-22	Mutter .....	Nut.....		
10	1				1134-5390-01	Dragkroksbalk .....	Tow bar bracket.....		
11	4				9945-0816-16	Skruv.....	Screw.....		
12	1				1137-0445-01	Distans .....	Spacer.....		
13	1				1137-0206-01	Motorremskiva .....	Engine pulley .....		
14	1				1137-0208-01	Motorremskiva .....	Engine pulley .....		
15	1				9600-0251-01	Kil .....	Key.....		
16	1				1134-50174-01	Bricka .....	Washer.....		
17	1				9987-5332-16	Skruv.....	Screw.....		
18	1				1134-6618-01	Bränsletank .....	Fuel tank.....		
19	1				1134-5532-01	Tanklock .....	Fuel tank cap .....		
20	1				1134-3224-01	Bensinkran .....	Fuel shut-off valve .....		
21	1				1134-3225-01	Gummbussning.....	Grommet .....		
22	0,52				9505-0001-01	Bensinslang.....	Fuel line .....	Per meter	
22	2				9578-0023-02	Slangklämma .....	Hose clamp.....		
23	1				1134-6627-01	Tankkonsol .....	Fuel tank bracket.....		
24	2				9959-0820-16	Skruv.....	Screw.....		
25	2				9739-0831-22	Mutter .....	Nut.....		
26	2				1134-5346-01	Tankbygel .....	Fuel tank loop .....		
27	2				112154510/0	Mutter .....	Nut.....		
30	1				1137-0095-01	Fäste-bränslepump.....	Bracket-fuel pump .....		
31	2				9939-0820-16	Skruv.....	Screw.....		
32	1				1137-0114-01	Bränslepump.....	Fuel pump .....		
33	2				9893-0616-16	Skruv.....	Screw.....		
34	4				9578-0023-07	Slangklämma .....	Hose clamp.....		
35	1				1137-0103-01	T-rör .....	Joint pipe.....		
36	0,04				9505-0001-01	Bensinslang.....	Fuel hose .....	Per meter	
37	2				9578-0023-02	Slangklämma .....	Hose clamp.....		
38	1				1134-5827-05	Oljeavtappning kpl .....	Oil drain assy .....		
39	1				1134-5825-01	Nippel .....	Nipple.....		
40	1				9578-0023-04	Slangklämma .....	Hose clamp.....		
41	1				1134-3499-02	Slangklämma .....	Hose clamp.....		
42	1				1134-5826-01	Plugg.....	Plug .....		
43	1				1137-0415-01	Adapter .....	Adapter.....		
50	2				1137-0442-01	Fäste .....	Bracket .....		






Utgåva Issue 2014-11		Bildnr Picture No 1668B		PARK 2WD TRANSMISSION		PARK 2WD TRANSMISSION		Sida Page 24	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6103 6102	6100							
1	1	1		1134-4000-02	Spännarm.....	Tension arm.....			
2	1	1		1134-3459-01	Spännrulle.....	Tension roller.....			
3	1	1		9924-1035-16	Skruv.....	Screw.....			
4	1	1		9799-1031-02	Mutter.....	Nut.....			
5	1	1		1134-9058-01	Drivrem.....	V-belt.....			
6	1	1		9997-0625-16	Skruv.....	Screw.....			
7	1	1		9739-0631-22	Mutter.....	Nut.....			
7A	1	1		9747-0631-02	Låsmutter.....	Lock nut.....			
8	1	1		1134-3377-02	Reglagestång.....	Control rod.....			
9	1	1		4231-0013-00	Fjäder.....	Spring.....			
10	1	1		1134-4171-01	Ledtapp.....	Pivot pin.....			
11	1	1		1134-4183-01	Tryckfjäder.....	Compression spring.....			
12	2	2		1134-3456-01	Bussning.....	Bushing.....			
13	1	1		9747-0631-02	Låsmutter.....	Lock nut.....			
14	1	1		1134-1565-08	Distans.....	Spacer.....			
15	1	1		9997-0870-16	Skruv.....	Screw.....			
16	1	1		9699-0056-02	Planbricka.....	Flat washer.....			
17	1	1		9747-0831-02	Mutter.....	Lock nut.....			
18	1	1		1134-6414-01	Fjäder.....	Spring.....			
19	1	1		9699-0060-02	Planbricka.....	Flat washer.....			
20	1	1		1137-0123-01	Transaxel kpl.....	Transaxle assy.....			
21	4	4		9960-0860-12	Skruv.....	Screw.....		Kanzaki K46CI	
22	4	4		9747-0831-02	Mutter.....	Lock nut.....			
23	1	1		1134-3913-01	Reaktionsstag.....	Strut.....			
24	1	1		9959-0825-16	Skruv.....	Screw.....			
25	1	1		9997-0845-12	Skruv.....	Screw.....			
26	1	1		9699-0090-02	Planbricka.....	Flat washer.....			
27	2	2		9747-0831-02	Mutter.....	Lock nut.....			
28	1	1		9747-0631-02	Låsmutter.....	Lock nut.....			
29	1	1		1134-2765-02	Oljetank.....	Oil tank.....			
30	1	1		1134-2777-02	Tanklock.....	Filler cap.....			
31	1	1		1134-3734-01	Luftningsplugg.....	Vent plug.....			
32	1	1		1134-2778-01	Fästband.....	Retainer strap.....			
33	2	2		9852-8013-16	Skruv.....	Screw.....			
34	2	2		9699-0099-02	Bricka.....	Washer.....			
35	2	2		9578-0035-01	Slangklämma.....	Hose clamp.....		14,6-17,8	
36	1			1134-2779-07	Slang.....	Tube.....		L = 140 mm	
36		1		1134-2779-12	Slang.....	Tube.....		L = 205 mm	
40	1	1		1134-4015-01	Dragstång.....	Pull rod.....			
41	1	1		1134-4014-01	Plastknopp.....	Plastic button.....			
42	1	1		1134-4713-01	Vinkel.....	Bracket.....			
42	1	1		1134-2790-01	Gummihylsa.....	Rubber grommet.....			
44	1	1		9959-0820-16	Skruv.....	Screw.....			
45	1	1		9739-0831-22	Mutter.....	Nut.....			
46	1	1		9675-0009-02	Starlock.....	Starlock.....			
51	1	1		1134-3289-02	Remstyrning.....	Belt guide.....			
52	1	1		9959-0820-16	Skruv.....	Screw.....			
53	1	1		9699-0056-02	Planbricka.....	Flat washer.....			
54	1	1		9739-0831-22	Mutter.....	Nut.....			
55		2		1134-3376-01	Mellanlägg.....	Space plate.....			



Utgåva Issue		Bildnr Picture No		PARK 2WD HJUL		PARK 2WD WHEEL		Sida Page	
2014-11		1346E						24	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6102	6103 6100							
1	2	2		1134-0075-00	Framaxeltapp .....	Front axle .....			
2	2	2		9595-0258-00	Spännstift .....	Locating pin .....			
3	2	2		1134-4844-05	Hjulnav kpl .....	Wheel hub Assy .....			
3A	1	1		9501-0500-00	Smörjnippel .....	Grease joint .....			
4	1	1		1134-9026-01	Lagerbussning .....	Bearing bush kit .....		Sats 4 st/kit of 4	
5		2		1134-4558-01	Fälg .....	Rim .....			
5	2			1134-5255-01	Fälg .....	Rim .....			
6		2		9545-0116-00	Däck .....	Tyre .....		16 x 7.50 - 8	
6	2			9545-0126-01	Däck .....	Tyre .....		16 x 6.00 - 8	
7	2	2		9545-0500-00	Ventil .....	Valve .....			
8	6	6		9731-1031-22	Mutter .....	Nut .....			
10	4	4		1134-0341-01	Bricka .....	Washer .....		20,5 x 36 x 1,5 mm	
11	2	2		9599-0080-02	Saxsprint .....	Cotter pin .....			
12	2	2		1134-4844-02	Hjulnav .....	Wheel hub .....			
13		2		1134-4558-01	Fälg .....	Rim .....			
13	2			1134-5255-01	Fälg .....	Rim .....			
14		2		9545-0116-00	Däck .....	Tyre .....		16 x 7.50 - 8	
14	2			9545-0126-01	Däck .....	Tyre .....		16 x 6.00 - 8	
15	2	2		9545-0500-00	Ventil .....	Valve .....			
16	6	6		9731-1031-22	Mutter .....	Nut .....			
18	2	2		1134-4796-01	Navkapsel .....	Hub cap .....			
19	2	2		9947-0540-19	Skruv .....	Screw .....			
20	2	2		1134-2471-01	Kil .....	Key .....		L = 58 mm	
21	2	2		1134-0341-01	Bricka .....	Washer .....		20,5 x 36 x 1,5 mm	
22	2	2		9653-0001-04	Spärryttare .....	Lock ring .....			
26	2	2		9699-0042-02	Planbricka .....	Flat washer .....		20 x 36 x 3,0 mm	
45	1	1		13-0992-61	Snabbfäste kpl .....	Quick connections .....		Inkl. pos 11,26,46-51	
46	1	1		1134-7465-01	Fästen kpl, vä+hö .....	Attachment kit, LH+RH .....		Inkl. pos 50-51	
47	2	2		1137-0077-01	Låssprint .....	Locking pin .....			
48	2	2		9548-0026-01	Glidlager .....	Bearing .....			
50	2	2		9898-1035-16	Skruv .....	Screw .....			
51	2	2		9739-1031-22	Mutter .....	Nut .....			
99				9545-0203-00	Innerslang .....	Inner tube .....		Reservdel/spare part	



Utgåva Issue		Bildnr Picture No		PARK 2WD KRAFTUTTAG		PARK 2WD PTO		Sida Page	
2014-11		1030E						24	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6100	6103	6102						
1	1				1134-5548-01	Distans .....	Spacer .....		
2	1				1134-5109-01	Spännhjulssarm .....	Tension wheel arm .....		
3	1				1137-0128-01	Spännrulle kpl. ....	Tension roller assy .....		Inkl. pos 3A-3B
3A	1				9549-0019-00	Kullager .....	Ball bearing .....		
3B	1				9651-0040-04	Låsring .....	Retaining ring .....		
4	1				1134-1888-04	Distans .....	Spacer .....		
5	1				1134-5111-01	Fjäder .....	Spring .....		
6	1				9699-0056-02	Planbricka .....	Flat washer .....		
7	1				9739-0831-22	Mutter .....	Nut .....		
8	1				9997-0855-12	Skruv .....	Screw .....		
10	1				1137-0004-01	Centrumremskiva kpl .....	Centre pulley assy .....		Inkl. pos 11-12
11	1				1134-0051-09	Distans .....	Spacer .....		
12	2				9549-0019-00	Kullager .....	Ball bearing .....		
13	1				1134-5112-01	Fjäderfäste .....	Spring attachment .....		
14	2				9945-0816-16	Skruv .....	Screw .....		
15	1				1134-5110-01	Hake .....	Hook .....		
16	2				9893-0616-16	Skruv .....	Screw .....		
18	1				1134-2018-02	Spännarm .....	Tension arm .....		
19	1				1134-9027-02	Spännrulle-grå .....	Tension roller-grey .....		
20	1				1134-9071-01	Drivrem .....	V-belt .....		9585-0129-01
21	1				9997-1030-16	Skruv .....	Screw .....		
22	1				9799-1031-02	Mutter .....	Nut .....		
23	1				1134-4111-01	Bromsarm .....	Brake arm .....		
24	1				1134-4164-03	Bromsklots .....	Brake pad .....		
25	1				9897-0825-16	Skruv .....	Screw .....		
26	1				9747-0831-02	Mutter .....	Lock nut .....		
27	1				1134-4162-01	Bromsstång .....	Brake rod .....		
28	1				9675-0008-02	Starlock .....	Locking washer .....		
29	1				1134-4170-01	Nippel .....	Nipple .....		
30	1				9699-0025-02	Planbricka .....	Washer .....		
31	1				9747-0631-02	Låsmutter .....	Lock nut .....		
32	1				4231-0013-00	Fjäder .....	Spring .....		
33	1				1134-4231-01	Dragfjäder .....	Spring .....		
34	1				1134-1565-10	Distans .....	Spacer .....		
35	1				9997-0860-12	Skruv .....	Screw .....		
36	1				9699-0056-02	Planbricka .....	Flat washer .....		
37	1				9739-0831-22	Mutter .....	Nut .....		
38	1				1134-4163-01	Ansatsskruv .....	Shoulder bolt .....		
39	1				9731-1031-22	Mutter .....	Nut .....		
40	1				1134-3958-01	Remstyrning .....	Belt guide .....		
41	2				9893-0616-16	Skruv .....	Screw .....		
42	1				1134-0041-03	Hylsa .....	Collar .....		
43	1				9997-1070-12	Skruv .....	Screw .....		
44	1				9739-1031-22	Mutter .....	Nut .....		
45	1				1134-3654-01	Fingerskydd .....	Finger guard .....		
46	2				9959-0612-16	Skruv .....	Screw .....		
47	2				9739-0631-22	Mutter .....	Nut .....		
48	1				9699-0090-02	Planbricka .....	Flat washer .....		
49	2				9699-0035-02	Planbricka .....	Flat washer .....		