



www.stiga.com

Illustrated Parts List

for model:

Villa Classic Gear

- Use GLOBAL GARDEN PRODUCT genuine spare parts specified in the parts list for repair and/or replacement.
- Then contents described in the parts list may change due to improvement.
- The drawings of the spare part are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

© Copyright 2014 Global Garden Products









All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.

THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.

www.ggp-group.com




21




12


(x 2)





Utgåva Issue 2014-11		Bildnr Picture No 2196A		VILLA MONTERINGSDETALJER		VILLA ASSEMBLY PARTS		Sida Page 2	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2715	2733							
1	1				9595-0262-00	Spännstift.....	Locating pin		
2A	1				9699-0103-02	Shims	Flat washer		
2B	1				9699-0114-02	Shims	Flat washer		
3	2				1134-4185-01	Ansatsbricka	Flange washer		
5	4				9699-0056-02	Planbricka	Flat washer		
6	2				1134-4481-01	Vingmutter.....	Wing nut.....		
7	1				1134-4627-01	Dragögla	Tow bar		
8	2				9959-0820-16	Skruv.....	Screw.....		
9	4				9997-0820-16	Skruv.....	Screw.....		
10A	1				1134-4734-01	Tändningsnyckel.....	Ignition key		
10B	1				1134-6125-01	Tändningsnyckel.....	Ignition key		
11	1				1134-5245-01	Batterirem.....	Battery strap.....		
12	1				1134-6113-01	Batteriskruvar	Battery screws.....		
13	2				9898-1035-16	Skruv.....	Screw.....		
14	2				9739-1031-22	Mutter	Nut.....		
21	1					Bruksanvisning.....	Owner´s manual		as PDF




Utgåva Issue 2014-11		Bildnr Picture No 1641A		VILLA KAROSS		VILLA BODY WORKS		Sida Page 4
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2715	2733						
1	1	1		1134-5283-02	Motorhuv-gul.....	Engine hood-yellow		
2	7	7		9838-9530-12	Skruv.....	Screw.....		
3	1	1		1134-5284-02	Motorlucka-grå.....	Engine cover-grey		
3		1		1134-5284-03	Motorlucka-svart	Engine cover-black		
4	1			1134-5307-01	Stänkskärm-vä, grå	Mud guard-LH, grey		
4		1		1134-5307-03	Stänkskärm-vä, svart	Mud guard-LH, black.....		
5	1			1134-5307-02	Stänkskärm-hö, grå.....	Mud guard-RH, grey.....		
5		1		1134-5307-04	Stänkskärm-hö, svart	Mud guard-RH, black		
6	2	2		1137-0088-01	Stödplåt.....	Support plate		
7	4	4		9699-0056-02	Planbricka	Flat washer		
8	6	6		9945-0816-16	Skruv.....	Screw.....		
9	4	4		1134-4176-01	Clips.....	Clips		
10	4	4		9893-0616-16	Skruv.....	Screw.....		
11	1	1		1134-5306-01	Stötfångare, front-vä.....	Bumper, front-LH		Grey
11		1		1134-5306-03	Stötfångare, front-hö.....	Bumper, front-LH		Black
12	1			1134-5306-02	Stötfångare, front-hö.....	Bumper, front-RH		Grey
12		1		1134-5306-04	Stötfångare, front-hö.....	Bumper, front-RH		Black
13	1			1134-5305-01	Front-nedre	Front plate-lower		
14	6	6		9893-0616-16	Skruv.....	Screw.....		
15	1	1		1134-5304-01	Front-övre	Front-upper		
16	2	2		9946-0525-16	Skruv.....	Screw.....		
17	2	2		1134-4790-02	Styrning	Hood guide.....		
18	2	2		9838-9530-12	Skruv.....	Screw.....		
19	2	2		9699-0060-02	Planbricka	Flat washer		
99	1	1		1134-6426-01	Dekalsats.....	Label kit		Villa 12




Utgåva Issue 2014-11		Bildnr Picture No 1642B		VILLA RAM		VILLA FRAME		Sida Page 6	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2715	2733							
1	1	1		1134-6635-01	Ram.....	Frame			
2	1			1134-5293-01	Durk.....	Floor plate			
2		1		1134-5293-02	Durk.....	Floor plate			
3	2	2		9893-0616-16	Skruv.....	Screw.....			
4	1			1134-5338-03	Durkmatta.....	Floor mat			
4		1		1134-5338-02	Durkmatta.....	Floor mat			
5	1			1134-5453-03	Stötfångare-bak, grå	Bumper-rear, grey			
5		1		1134-5453-01	Stötfångare-bak, svart.....	Bumper-rear, black.....			
6	1	1		1134-6630-01	Stag-vä.....	Attachment-LH			
7	1	1		1134-6630-02	Stag-hö.....	Attachment-RH			
8	2	2		1134-0240-00	Ansattsskruv	Shoulder screw			
9	2	2		1134-4242-01	Distansbricka	Spacer washer			
10	2	2		9694-0001-00	Fjäderbricka	Washer.....			
11	2	2		9747-0831-02	Mutter	Lock nut			
12	2	2		9943-0516-16	Skruv.....	Screw.....			
13	2	2		9959-0820-16	Skruv.....	Screw.....		L = 20 mm	
14	2	2		9959-0825-16	Skruv.....	Screw.....		L = 25 mm	
15	1	1		9739-0831-22	Mutter	Nut.....			
16	3	3		9739-0831-22	Mutter	Nut.....			



Utgåva Issue 2014-11		Bildnr Picture No 1151C		VILLA REDSKAPSLYFT		VILLA LIFTING DEVICE		Sida Page 8	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2733	2715							
1	1				1134-4117-01	Fäste.....	Bracket		
2	2				9959-1025-16	Skruv.....	Screw.....		
3	2				9739-1031-22	Mutter	Nut.....		
4	2				1134-2684-01	Lager.....	Bearing		
5	1				1134-4945-01	Lyftspärr kpl	Lift catch assy		
9	1				9404-0027-01	O-ring	O-ring		
10	1				9650-0039-04	Seegersäkring	Lock ring		
11	1				9595-0276-01	Spännstift.....	Locating pin		
12	1				9997-0640-12	Skruv.....	Screw.....		
13	1				9747-0631-02	Låsmutter.....	Lock nut		
15	1				9897-0820-16	Skruv.....	Screw.....		
16	1				9747-0831-02	Mutter	Lock nut		
17	1				1134-4860-01	Lyftgaffel	Lift fork		
18	2				1134-0240-00	Ansattsskruv	Shoulder screw.....		
19	1				1134-4938-01	Lyftpedal.....	Lift pedal		
20	2				9997-0625-16	Skruv.....	Screw.....		
21	2				9739-0631-22	Mutter	Nut.....		
22	1				4231-0013-00	Fjäder.....	Spring.....		




Utgåva Issue 2014-11		Bildnr Picture No 1652A		VILLA SITS		VILLA SEAT		Sida Page 10	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2715	2733							
1	1			1134-5506-01	Sits	Seat.....			
1		1		1134-5534-01	Sits	Seat.....			
3	1	1		1134-5301-01	Sitsplatta	Seat plate			
4	2	2		1134-0240-00	Ansattsskruv	Shoulder screw.....			
5	2	2		9747-0831-02	Mutter	Lock nut			
6	1	1		1134-5454-01	Spärr	Catch			
7	1	1		9675-0012-02	Starlock.....	Locking washer.....			
12	1	1		1134-5296-04	Sitskonsol-gul	Seat bracket-yellow.....			
12		1		1134-5296-05	Sitskonsol-svart	Seat bracket-black.....			
13	1	1		1134-4256-01	Sitsfjäder.....	Seat spring.....			
14	1	1		9924-1235-19	Skruv.....	Screw.....			
15	1	1		9747-1231-02	Låsmutter.....	Lock nut			
16	1	1		9997-0840-12	Skruv.....	Screw.....			
17	1	1		1134-1565-06	Distans	Spacer.....			
18	1	1		1134-5302-01	Fjäder.....	Spring.....			
19	1	1		1134-5299-01	Tryckplatta.....	Push plate			
20	1	1		9699-0090-02	Planbricka.....	Flat washer			
21	1	1		9747-0831-02	Mutter	Lock nut			
22	1	1		1134-3156-02	Brytare (grå)	Switch (grey).....			
28	4	4		9959-0820-16	Skruv.....	Screw.....		L = 20 mm	
29	2	2		9959-0825-16	Skruv.....	Screw.....		L = 25 mm	
30	2	2		9699-0056-02	Planbricka.....	Flat washer			
31	6	6		9739-0831-22	Mutter	Nut.....			




Utgåva Issue 2014-11		Bildnr Picture No 2199A		VILLA STYRNING		VILLA STEERING		Sida Page 12	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2733								
1	3				1134-0041-01	Linhjulshylsa	Bushing		
2	3				1134-0046-00	Linhållare.....	Wire clamp		
3	1				1134-9025-01	Linhjul-sats	Steering pulley-kit.....		
4	3				9997-1040-16	Skruv.....	Screw.....		
5	2				9739-1031-22	Mutter	Nut.....		
6	1				1134-9154-01	Styrwire	Steering cable.....		
7	1				1134-1310-01	Tryckfjäder	Compression spring		
8	1				9699-0056-02	Planbricka.....	Flat washer		
9	1				9747-0831-02	Mutter	Lock nut		
11	1				1134-5349-03	Styrkonsol-grå	Steering console-grey.....		
12	4				9897-0820-16	Skruv.....	Screw.....		
13	4				9739-0831-22	Mutter	Nut.....		
15	1				1134-1305-05	Rattrör-nedre.....	Steering column-lower.....		
16	2				1134-1901-01	Lager.....	Bearing.....		
17	2				9893-0616-16	Skruv.....	Screw.....		
18	2				9699-0060-02	Planbricka.....	Flat washer		
19	1				1134-5495-01	Rattstång	Steering rod		
20	1				1134-1933-01	Styrrulle	Steering pulley		
21	1				9595-0262-00	Spännstift.....	Locating pin		
22	1				1134-5496-01	Ratt	Steering wheel.....		
32	1				1134-3047-01	Distans	Spacer.....		
33	2				9699-0104-02	Bricka	Washer.....		
36	2				1134-3047-01	Distans	Spacer.....		
37	1				1134-0041-05	Hylsa.....	Bushing		
38	1				1134-0046-00	Linhållare.....	Wire clamp		
39	1				1134-9025-01	Linhjul-sats	Steering pulley-kit.....		
40	1				9997-1060-12	Skruv.....	Screw.....		

Sats 2 st/kit of 2
L = 40 mm


Sats 2 st/kit of 2
L = 60 mm







Utgåva Issue 2014-11		Bildnr Picture No 1654A		VILLA HANDREGLAGE		VILLA HAND CONTROLS		Sida Page 14
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2715	2733						
1	1			1134-5286-01	Reglagepanel-vä	Control panel-LH		Grey Black
1		1		1134-5286-02	Reglagepanel-vä	Control panel-LH		
2	2	2		1134-5531-01	Dämpare	Absorber		
3	3	3		9893-0616-16	Skruv	Screw		
4	1	1		1134-5357-01	Fäste	Bracket		
5	2	2		9838-9516-12	Skruv	Screw		
6	1	1		1134-4077-01	Gasreglage	Throttle control		
7	1	1		1134-4078-01	Knopp	Knob		
8	1	1		1134-0240-00	Ansatssskruv	Shoulder screw		
9	1	1		9694-0001-00	Fjäderbricka	Washer		
10	2	2		1134-4242-01	Distansbricka	Spacer washer		
11	1	1		9747-0831-02	Mutter	Lock nut		
12	1	1		1134-1597-13	Gaswire	Throttle cable		
13	1	1		9500-9991-00	Wireklämma	Cable clamp		
14	1	1		9943-0516-16	Skruv	Screw		
15	1	1		9579-0003-00	Buntband	Cable holder		
20	1	1		9997-0812-02	Skruv	Screw		
21	1	1		1134-5274-02	Distans	Spacer		
22	3	3		1134-3047-01	Distans	Spacer		
23	1	1		1134-5271-01	Reglagefäste	Control bracket		
24	1	1		1134-5275-01	Växelspak	Gear shift lever		
25	1	1		1134-5535-01	Fjäder	Spring		
26	1	1		9997-0890-12	Skruv	Screw		
27	1	1		9747-0831-02	Mutter	Lock nut		
28	1	1		1134-5268-01	Stag	Shifter rod		
29	1	1		9675-0009-02	Starlock	Starlock		
30	1	1		1134-5271-01	Reglagefäste	Control bracket		
31	1	1		1134-5276-01	Reglagespak	Control lever		
32	1	1		9997-0890-12	Skruv	Screw		
33	1	1		9747-0831-02	Mutter	Lock nut		
34	1	1		1134-5356-01	Stag	Strut		
35	1	1		9747-0831-02	Mutter	Lock nut		
36	2	2		9400-0360-01	Mikrobrytare	Micro switch		
37	4	4		9840-7716-16	Skruv	Screw		
38	1	1		1134-5358-01	Brytarfäste	Switch bracket		
39	2	2		9943-0516-16	Skruv	Screw		
40	1		1	1134-5285-01	Reglagepanel-hö	Control panel-RH		
			1	1134-5285-03	Reglagepanel-hö	Control panel-RH		
41	2	2		1134-5531-01	Dämpare	Absorber		
42	4	4		9893-0616-16	Skruv	Screw		
43	2	2		1134-2551-01	Reglageknopp	Knob		
44	1	1		1134-3573-06	Kraftuttagwire	PTO cable		
45	1	1		1134-1242-02	Fjäder	Spring		
50	1	1		1134-4093-01	Tändningslås	Ignition switch		
51	1	1		1134-4749-01	Mutter	Nut		





Utgåva Issue 2014-11		Bildnr Picture No 1644B		VILLA FOTREGLAGE		VILLA FOOT CONTROLS		Sida Page 16	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2733								
1	1				1134-4802-01	Pedal	Pedal.....		
2	2				1134-4624-01	Lager.....	Bearing.....		
3	4				9897-0640-12	Skruv.....	Screw.....		
4	4				9739-0631-22	Mutter	Nut.....		
5	1				1134-4795-01	Kopplingsstång.....	Clutch rod.....		
6	1				1134-2138-01	Skruvögla.....	Eye bolt.....		
7	1				9739-1031-22	Mutter	Nut.....		
8	1				9731-1031-22	Mutter	Nut.....		
9	1				9739-0831-22	Mutter	Nut.....		
10	1				9747-0831-02	Mutter	Lock nut.....		
11	1				9595-0208-00	Spännstift.....	Locating pin.....		
14	1				1134-4777-01	Bromsstag.....	Brake rod.....		
15	1				1134-4617-01	Fjäder.....	Spring.....		
16	2				1134-2138-01	Skruvögla.....	Eye bolt.....		
17	2				9699-0035-02	Planbricka.....	Flat washer.....		
18	4				9595-0208-00	Spännstift.....	Locating pin.....		
19	2				9739-0831-22	Mutter	Nut.....		
20	1				9747-0831-02	Mutter	Lock nut.....		
26	1				1134-5353-01	Bromsstång.....	Brake rod.....		
27	1				1134-2786-01	Plastknopp.....	Plastic knob.....		
28	1				1131-1497-01	Fjäder.....	Spring.....		
29	1				1134-4002-01	Fäste.....	Brake rod attachment.....		
30	3				9838-9516-12	Skruv.....	Screw.....		
31	1				1134-4714-01	Fästvinkel.....	Angle bracket.....		
32	2				9959-0820-16	Skruv.....	Screw.....		
33	2				9739-0831-22	Mutter	Nut.....		
34	1				1134-4715-01	Triangel.....	Triangular plate.....		
35	1				1134-0240-00	Ansattsskruv.....	Shoulder screw.....		
36	1				9694-0001-00	Fjäderbricka.....	Washer.....		
37	1				9699-0036-02	Planbricka.....	Flat washer.....		
38	1				9747-0831-02	Mutter	Lock nut.....		
39	1				1134-4717-03	Gångstång.....	Threaded rod.....		Peerless
40	2				9570-0004-00	Vinkellänk.....	Elbow link.....		
41	2				9747-0631-02	Låsmutter.....	Lock nut.....		
42	2				9739-0631-22	Mutter	Nut.....		
43	1				1134-4722-01	Växelarm.....	Shift lever.....		
44	1				9987-5016-16	Skruv.....	Screw.....		
45	1				9699-0060-02	Planbricka.....	Flat washer.....		
46	1				9675-0009-02	Starlock.....	Starlock.....		
51	1				1134-4793-01	Stopplåt.....	Stop plate.....		
52	1				4231-0013-00	Fjäder.....	Spring.....		
53	2				1134-4779-01	Plastbussning.....	Plastic bushing.....		
58	1				9747-0831-02	Mutter	Lock nut.....		




A





Utgåva Issue 2014-11		Bildnr Picture No 1650D		VILLA ELUTRUSTNING		VILLA EL. EQUIPMENT		Sida Page 18	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2733	2715							
1	1				1134-4804-01	Batteri	Battery		
8	1				1134-2042-02	Kabel-svart	Cable-black		L = 350 mm
9	1				9838-9516-12	Skruv.....	Screw.....		
10	1				9747-0831-02	Mutter	Lock nut		
11	1				9739-0631-22	Mutter	Nut.....		M6
12	3				9579-0003-00	Buntband.....	Cable holder		
22	1				9699-0060-02	Planbricka	Flat washer		
26	1				1134-2962-01	Solenoid kpl	Solenoid assy		
27	2				9794-5131-02	Mutter	Nut.....		
28	1				1134-0234-02	Batterikabel (+).....	Battery cable (+)		L = 395 mm
29	1				1134-2310-01	Batteriskydd.....	Guard cap		
30	1				1134-4702-02	Kabel-röd.....	Cable-red.....		L = 480 mm
32	1				1134-7218-01	Kablage.....	Harness.....		
32A	1				1134-3496-06	Säkring.....	Fuse		20A







Utgåva Issue 2014-11		Bildnr Picture No 2519		VILLA MOTOR		VILLA ENGINE		Sida Page 20	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2733	2715							
3	4			9955-3725-16	Skruv.....	Screw.....		3/8" x 25"	
5	1			1134-6626-01	Bränsletank	Fuel tank.....			
6	1			1134-5532-01	Tanklock	Fuel tank cap.....			
7	1			1134-3224-01	Bensinkran	Fuel shut-off valve			
8	1			1134-3225-01	Gummibussning.....	Grommet			
9	0,26			9505-0001-01	Bensinslang (meter).....	Fuel line (metre).....		Per meter	
10	2			9578-0023-02	Slangklämma	Hose clamp.....			
12	1			1134-4808-01	Tankbygel	Tank clamp.....			
13	1			9699-0060-02	Planbricka	Flat washer			
14	1			9747-0631-02	Låsmutter	Lock nut			
15	1			1134-4807-02	Tank/batterihylla.....	Tank/battery shelf.....			
16	4			9838-8822-19	Skruv.....	Screw.....			
19	1			1134-0433-00	Ljuddämparpackning	Muffler gasket			
22	2			1134-4930-01	Skruv.....	Screw.....			
23	1			1134-6623-01	Ljuddämpare.....	Muffler			
24	1			1134-6634-01	Grenrör	Exhaust pipe.....			
25	2			9893-0616-16	Skruv.....	Screw.....			
26	1			1134-6699-01	Värmeskydd.....	Heat guard.....			
27	4			9893-0616-16	Skruv.....	Screw.....			
99	1			118550439/0	Motor kpl.....	Engine assy			



Utgåva Issue 2014-11		Bildnr Picture No 1643B		VILLA TRANSMISSION		VILLA TRANSMISSION		Sida Page 22	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2733	2715							
1	1				1137-0205-01	Motorremskiva	Engine belt pulley		
4	1				1134-6637-01	Remstyrning	Belt guide		
5	1				9699-0056-02	Planbricka	Flat washer		
6	1				1134-4519-01	Spännarm	Tension arm		
7	1				1134-9091-01	Spännrulle	Tension roller		
8	1				1134-4614-01	Ansats	Shoulder spacer		
9	1				9997-1040-16	Skruv	Screw		
10	1				9699-0035-02	Planbricka	Flat washer		
11	1				9739-1031-22	Mutter	Nut		
12	1				1134-9027-02	Spännrulle-grå	Tension roller-grey		
13	1				1134-1795-01	Rembygel	Belt stirrup		
14	1				9997-1040-16	Skruv	Screw		
15	2				9699-0035-02	Planbricka	Flat washer		
16	1				9739-1031-22	Mutter	Nut		
17	1				1134-9164-01	Drivrem (Kevlar)	Drive belt		
18	1				1134-1565-08	Distans	Spacer		
19	1				9997-0870-16	Skruv	Screw		
20	2				9699-0056-02	Planbricka	Flat washer		
21	1				9739-0831-22	Mutter	Nut		
22	1				1134-5214-01	Fjäder	Spring		
23	1				1134-4847-01	Transaxel kpl	Transaxle assy		Peerless
24	4				9960-0860-12	Skruv	Screw		
25	4				9747-0831-02	Mutter	Lock nut		
26	1				1134-4687-01	Momentstag	Strut		
27	1				9945-0816-16	Skruv	Screw		
28	1				1137-0006-01	Remskiva	Belt pulley		Ø = 154 mm
30	1				9650-0016-04	Spårring	Lock ring		
31	1				1134-4707-01	Remstyrning	Belt guide		
32	1				9942-0820-16	Skruv	Screw		
41	1				1134-2138-01	Skruvögla	Eye bolt		
42	1				1134-4779-01	Plastbussning	Plastic bushing		
43	1				9739-0831-22	Mutter	Nut		
44	1				9747-0831-02	Mutter	Lock nut		



Utgåva Issue 2014-11		Bildnr Picture No 1646B		VILLA HJUL		VILLA WHEELS		Sida Page 24	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2733								
1	1				1134-6703-01	Bakaxel	Rear axle		
2	2				9501-0500-00	Smörjnippel	Grease joint		
3	1				1134-5009-02	Spindel-vä.....	Spindle-LH		
4	1				1134-5009-01	Spindel-hö.....	Spindle-RH		
5	2				9699-0088-02	Planbricka.....	Flat washer		
6	2				9650-0020-04	Spärring	Circlip		
7	1				1137-0090-01	Styrskiva	Steering pulley		
8	1				1134-5575-01	Distans	Spacer		
9	1				1134-9024-01	Lager.....	Bearing.....	Sats 4 st/kit of 4	
10	1				9699-0104-02	Bricka	Washer.....		
11	1				9997-1680-12	Skruv.....	Screw.....		
12	2				1134-3247-05	Styrstag.....	Tie rod		
13A	2				9997-0825-16	Skruv.....	Screw.....	L = 25 mm	
13B	1				9997-0835-12	Skruv.....	Screw.....	L = 35 mm	
14	2				9699-0090-02	Planbricka.....	Flat washer		
15	3				9747-0831-02	Mutter	Lock nut		
16	2				1134-4706-01	Fälg	Rim.....		
17	1				1134-9026-01	Lagerbussning.....	Bearing bush kit	Sats 4 st/kit of 4	
18	2				9545-0117-00	Däck.....	Tyre	13 x 5.00 - 6	
19	2				9545-0500-00	Ventil.....	Valve		
20	2				1134-0341-01	Bricka	Washer.....		
21	2				9650-0020-04	Spärring	Circlip		
22	2				1134-4344-01	Navkapsel	Hub cap		
25	1				9501-0500-00	Smörjnippel	Grease joint		
26	1				9699-0088-02	Planbricka.....	Flat washer		
27	1				9650-0020-04	Spärring	Circlip		
28	2				1134-5255-01	Fälg	Rim.....		
29	2				9545-0126-01	Däck.....	Tyre	16 x 6.00 - 8	
30	2				9545-0500-00	Ventil.....	Valve		
32	6				9731-1031-22	Mutter	Nut.....		
33	2				1134-2471-03	Kil	Key		
34	2				9653-0001-04	Spärryttare	Lock ring		
35	2				1134-0341-01	Bricka	Washer.....		
36	2				1134-4844-02	Hjulnav	Wheel hub		
37	2				1134-4845-02	Navhylsa.....	Hub sleeve.....		
38	2				1134-4981-01	Bricka	Washer.....		
50	2				1134-6274-01	Redskapsfäste kpl.....	Attachment assy		
51	1				1134-9026-01	Lagerbussning.....	Bearing bush kit	Sats 4 st/kit of 4	
52	1				9501-0502-00	Smörjnippel	Grease joint		
98					9545-0204-00	Innerslang	Inner tube	Reservdel/spare part	
99					9545-0203-00	Innerslang	Inner tube	Reservdel/spare part	



Utgåva Issue 2014-11		Bildnr Picture No 1512F		VILLA KRAFTUTTAG		VILLA POWER TAKE-OFF		Sida Page 26	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2733								
1	1				1137-0081-01	Motorremskiva	Engine belt pulley		
2	1				1134-5017-01	Bricka	Washer		
3	1				9987-5332-16	Skruv	Screw		
4	1				1134-5058-01	Remstyrning	Belt guide		
5	1				1134-5057-01	Remstyrning	Belt guide		
6	1				9600-0251-01	Kil	Key		
7	2				9699-0056-02	Planbricka	Flat washer		L = 2 1/2"
8	1				1134-4650-01	Monteringsbygel	Pulley bracket		
9	2				9945-0816-16	Skruv	Screw		
10	1				1137-0003-01	Mellanremskiva kpl	Intermediate pulley		Inkl. pos 11-12
11	1				1134-0051-12	Distans	Spacer		
12	2				9549-0019-00	Kullager	Ball bearing		
14	2				1134-0052-00	Lagerdistans	Bearing spacer		
15	1				9997-1040-16	Skruv	Screw		
16	1				9699-0035-02	Planbricka	Flat washer		
17	1				1134-9079-01	Drivrem	Drive belt		=9585-0139-01
18	1				1134-5231-01	Spännarm	Tension arm		
19	1				1134-6329-01	Spännrulle	Tension roller		
20	1				1134-4619-01	Distans	Spacer		
21	1				9997-1060-12	Skruv	Screw		
22	1				9747-1031-02	Låsmutter	Lock nut		
23	1				1134-6314-01	Spännarmsfäste	Attachment		
24	1				9997-0640-12	Skruv	Screw		
25	1				9747-0631-02	Låsmutter	Lock nut		
26	1				1134-4619-01	Distans	Spacer		
27	1				9930-1050-12	Skruv	Screw		
28	1				9699-0035-02	Planbricka	Flat washer		
29	1				9747-1031-02	Låsmutter	Lock nut		
30	1				1134-4708-02	Fäste	Bracket		
31	2				9945-0816-16	Skruv	Screw		
32	1				9699-0035-02	Planbricka	Flat washer		
36	1				1131-1507-00	Fjäder	Spring		
40	1				1134-5037-01	Bygel	Bracket		
41	1				1137-0209-01	Centrumremskiva kpl	Centre pulley assy		Inkl. pos 42-43
42	1				1134-0051-09	Distans	Spacer		
43	2				9549-0019-00	Kullager	Ball bearing		
44	1				1134-1839-02	Mellanaxel	Shaft		
45	1				9699-0035-02	Planbricka	Flat washer		
46	1				9739-1031-22	Mutter	Nut		
47	1				9997-1070-12	Skruv	Screw		
48	1				1137-0144-01	Kopplingsarm	Clutch lever		
49	1				1134-1565-10	Distans	Spacer		
50	1				9997-0860-12	Skruv	Screw		
51	1				9699-0056-02	Planbricka	Flat washer		
52	1				9739-0831-22	Mutter	Nut		
53	1				1134-9027-02	Spännrulle-grå	Tension roller-grey		
55	1				9997-1035-16	Skruv	Screw		
56	2				9699-0035-02	Planbricka	Flat washer		
57	1				9739-1031-22	Mutter	Nut		
58	1				1134-9146-01	Drivrem	Drive belt		=9585-0204-01
59	1				1134-4164-03	Bromsklots	Brake pad		
60	1				9959-0820-16	Skruv	Screw		
61	1				9699-0090-02	Planbricka	Flat washer		
62	1				9747-0831-02	Mutter	Lock nut		
63	2				9959-0820-16	Skruv	Screw		
64	2				9739-0831-22	Mutter	Nut		
65	1				9699-0056-02	Planbricka	Flat washer		
66	1				1131-1506-00	Fjäder	Spring		
67	1				9997-0860-12	Skruv	Screw		
68	2				9739-0831-22	Mutter	Nut		